



## **Foreword**



Dear users.

Thank you for choosing an AION Y Plus - We value your trust in us.

We hope to bring you more driving fun with the best product and services.

Please read this manual thoroughly before driving to familiarize yourself with the functions and precautions of the vehicle.

When you are to resell this vehicle, please hand over this manual together with the vehicle to the new owner.

If you have any suggestions or comments to this manual, please call the GAC AION's customer service hotline.

Wish you a happy journey!

GAC Aion New Energy Automobile Co., Ltd. June 2023

GAC Aion New Energy Automobile Co., Ltd. All Rights Reserved!

No information contained in this manual is allowed to be reprinted or duplicated without the written permission of GAC Aion New Energy Automobile Co., Ltd.

All Rights Reserved!

Note: The model and illustration on the cover are for reference only.



Introduction to the Owner's Manual	How does a pregnant woman confasten the seat belt?	
	Seat belt reminder	16
Notices to users1	Airbag	. 17
How to read this manual 2	Introduction to airbag	17
Preparations before use	SRS warning lamp	19
Preparations before driving 3	Airbag deployment	20
Pre-drive check 3	Child safety	22
Unlocking of vehicle	Notices for children	22
	Child safety lock	24
Key4	ISOFIX child restraint system	24
Smart key 4	LATCH child restraint system	24
Unlocking outside the vehicle 6	Applicability of child seats	25
Locating of vehicle6	Sitting in front/rear seats	28
Unlocking outside the vehicle 6	Switch-on/off of vehicle power	
Trunk loading	supply	28
Opening of liftgate7	Seat adjustment	29
Opening liftgate 7	Adjustment of exterior rearview mirror	31
Closing of liftgate9	Adjustment of interior rearview mirror	31
Closing of liftgate9	Window control	32
Entering the vehicle	Sunroof control	33
Opening of doors10	Steering wheel control	35
Door opening from outside 10	Steering wheel adjustment	36
Interior lighting11	Locking doors from inside of	0-
Interior lighting11	vehicle	
Riding	Ride comfort	
	A/C control	
Seat belt 12	Storage space	40
Introduction to seat belt12	Safety handrail	42
Correct sitting posture 13	Sun visor	43
Correct use of seat belts14		



Vanity mirror and vanity mirror	Intelligent driving71
lamp	Forward collision warning system* 71
12V power outlet	Autonomous emergency braking (AEB)*72
Multimedia46	Cruise control74
Bluetooth connection	Adaptive cruise control* 76
MirrorLink*46	Integrated cruise assist *82
Precautions for multimedia use 47	Lane departure assist system * 86
Driving	Lane keeping assist (LKA) system *90
Instruments49	Driving in special weather 92
Indicator lamps on instrument	Driving in fog92
panel	Driving in rain92
Instrument panel warning lamps 52	Driving in hot seasons93
Instrument panel	Driving in cold seasons94
Information display55  Tire pressure monitoring system 57	Parking
Pulling out59	Parking assist96
Vehicle start59	Reverse tilt-down*96
Switching of driving modes 59	Reversing parking aid (RPA) 96
Gearshifting61	Surround view monitor (SVM) 97
Speed control 62	Get-off
Pedal 62	Preparation before getting off
Brake assist control system 63	the vehicle100
Acoustic vehicle alerting system of	Electric park brake (EPB) 100
electric vehicle running at low speed65	Closing all windows 102
AUTO HOLD66	Closing sunroof103
Light control 67	Follow Me Home103
Light control67	Unlocking inside the
Wiper control 69	vehicle 104
Wiper control 69	Unlocking doors inside the vehicle104
	Opening doors inside the



vehicle 104	A/C maintenance 131
After getting off the vehicle 105	A/C filter131
Safety notes before getting off the	Fuse replacement 132
vehicle 105	Checking and replacing fuse 132
Vehicle locking	Battery maintenance 134
Locking outside the vehicle 106	Low voltage battery
Locking outside the vehicle 106	maintenance134
Exterior rearview mirror folding 106	Maintenance of traction battery 135
Anti-theft alarm system 108	Emergency treatment
Body anti-theft 108	<b>Emergency treatment by</b>
Leaving	owner 138
	Emergency unlocking/locking 138
Charging 109	Window initialization140
Charging instructions 109	Initialization of sunroof141
AC charging112	Turning on hazard warning lamp. 141
DC charging114	Wearing reflective vest 142
Maintenance and cleaning	Setting up warning triangle 142
Vehicle cleaning116	Introduction to driver's tools 143
External cleaning116	Tire inflation143
Internal cleaning118	Tire repair145
Vehicle maintenance 120	Tire rotation148
External maintenance 120	Jump start149
Internal maintenance	Emergency start of vehicle 150
Tire maintenance	Emergency poweroff of vehicle 151
Corrosion protection measures 125	Roadside service152
Long-term storage of vehicle 126	Getting out of a trap152
Adding oils and fluids 127	Vehicle towing152
Opening and closing hood 127	Road accident rescue 155
Adding windshield washer fluid 128	Rescue in case of driving through
Checking coolant129	water155
Checking brake fluid 130	Rescue in case of battery





Technical information
Vehicle information 157
Vehicle identification number (VIN)157
Vehicle nameplate and sticker 158
Technical parameters 160
Technical parameters of vehicle 160
Technical parameters of motor 161

Technical parameters of brake system ...... 164

fluids ...... 165

Type and dosage of vehicle

Rescue in case of vehicle fire..... 156

	A Smarter	Companio
--	-----------	----------



#### **Notices to users**

#### Configurations and options

This manual covers all the standard and optional configurations currently available for this product series. Therefore, some of the configurations and features described herein are not available on your vehicle. For specific configuration information of your vehicle, please refer to related sales materials or consult GAC AION sales store when buying a vehicle.

#### Accessories, parts and modifications

Please use the genuine accessories and parts of GAC AION for replacement.

If accessories and parts not genuine to GAC AION are used for modification of the vehicle, we will refuse to provide warranty and bear any responsibilities and obligations arising therefrom. In addition, vehicle damage and performance degradation caused by the use of accessories and parts not genuine to GAC AION are not covered by the warranty.

#### Scrapping of vehicle

Airbags contain explosive chemicals, and if they are not properly handled before vehicle scrapping, fire or other accident may occur. Always contact the GAC AION sales store or other qualified third party for dismantling and scrapping of the vehicle

#### Event data recorder (EDR)

This vehicle is equipped with an event data recorder (EDR), which mainly records vehicle data at the time of collision for assistance in accident analysis. But, the data may not be recorded sometimes, depending on the severity and type of collision.

The data specially recorded by the EDR of this vehicle include:

- ♦ Vehicle speed
- ♦ Longitudinal acceleration
- Vehicle identification number

These data allows us to better understand the situation of collision and injury or damage caused therefrom.

### **NOTE**

The EDR will record data only when a collision of certain degree occurs to the vehicle, that is to say, the EDR will not record data during normal driving.

#### FDR data disclosure

- We will not disclose the data recorded in the EDR to third parties except:
  - when a consent is obtained from the owner or lessee.
  - when an official request for disclosure is issued from the police, courts or other government agencies.
- However, we may apply the EDR data to the research and development of vehicle safety performance when necessary.

How to obtain EDR data reading tool

 Special technical equipment is required to read EDR data. For more information, please contact GAC AION sales store.

#### Time-based effectiveness of the Manual

Due to continuous improvement and upgrade of vehicle, this manual may be updated irregularly without notice.

The screenshots of center console display contained in this manual are only applicable to the current version, and the display or process may change due to software update in the future.



#### How to read this manual

#### Fast lookup

This manual is divided into several chapters in a logical way, and in order to help you find the desired information quickly, a navigation column is provided on the right margin of the odd page.

And, the "Table of Contents" which is edited in the sequence of chapters and the alphabetical index at the end of this Manual can also help you quickly find the desired information.

#### Symbols in the Manual

Symbol	Meaning
*	It is only applicable to some models or to some optional parts/features of some models.
<u> </u>	DANGER: Text with this symbol contains information about a high risk which, if ignored, will cause serious injury or even death.
<b>A</b>	WARNING: Text with this symbol contains information about a medium risk which, if ignored, is likely to cause serious injury or even death.
•	CAUTION: Text with this symbol contains information about a low risk which, if ignored, is possible to cause vehicle damage.
i	NOTE: Text with this symbol contains additional useful information.
43	Environment: Text with this symbol contains information on environmental protection.

#### Illustrations in the Manual

The illustrations in this manual are for reference only.

Unless otherwise specified, the directions of the vehicle (front, rear, left and right) referred to in this manual are based on the traveling direction of the vehicle.



### **Pre-drive check**

Before driving, it is recommended to check the following:


- ♦ Tires
- ♦ Lamps
- ♦ Rearview mirrors
- ♦ Obstacles around the vehicle
- ♦ Fluid leakage at the bottom of vehicle
- ♦ Activated alarm or alert



### **Smart key**

The smart key is a physical key, which can realize common functions including locking/unlocking and vehicle startup.

#### Introduction to buttons on smart key



- 1 Locking button
- 2 Remote power-on button
- 3 Liftgate unlocking button
- 4 Charger unlocking button
- ⑤ Unlocking button

### **CAUTION**

- Never expose the smart key to direct sunlight, high temperature or high humidity for a long time.
- Prevent the smart key from dropping from height.
- Neither wet the smart key, nor wash it in the ultrasonic cleaning machine.
- Do not disassemble the smart key without authorization.
- To avoid scratch, do not put the smart key and sharp objects together.
- When taking a plane with a smart key, never press any button on it, otherwise, it will cause interference to the flying of plane.
- Do not place the smart key near an object that can produce a magnetic field, such as TV set, AV unit, induction cooker or electronic medical device.
- If the smart key is lost, the vehicle will be at risk of theft. In this case, immediately go to the GAC AION sales store for treatment.



- The smart key will not work after the vehicle enters the driving ready status.
- If the smart key malfunctions, it is recommended to press any button on it 3 times quickly in the vicinity of the vehicle. If the smart key cannot be recovered, please contact the GAC AION sales store for inspection.
- Some functions of the intelligent may become unstable or fail under the following situations:
  - when the battery of smart key runs out.
  - when the smart key is operated in or near TV tower, charging station, power plant, airport and other places involving radio waves.
  - when the user carries the portable radio, mobile phone or other wireless communication devices.
  - when the smart key is in contact with metal objects or covered by other foreign bodies.
  - when there are other smart keys in use nearby.
- As time goes, the battery of smart key may run out if any one of the following situations occurs:
  - The remote control function of smart key fails.
  - The effective operation range of the smart key becomes smaller.
  - The indicator lamp on the smart key is off. If this occurs, please replace the battery.
- The battery of smart key will run out if it is not used for a long time, and if this occurs, please get the battery replaced in the GAC AION sales store.



### Locating of vehicle

After you are in the vicinity of vehicle, press the locking button on the smart key 2 times quickly, and after this, the vehicle will give audible and visible alarms to remind you of the location of the vehicle.

# Unlocking outside the vehicle

#### Unlocking by smart key button

With the vehicle locked, press the unlocking button within the effective range of the smart key to unlock the vehicle.

#### Intelligent active unlocking

When the intelligent active unlocking function is switched on in the center console display and you walk to the locked vehicle with smart key in hand, the vehicle will be automatically unlocked.

- The horn alarm for vehicle locking/ unlocking can be switched on/off in the center console display.
- If no operation is made within a certain period after the vehicle is unlocked, the door will lock automatically.
- The door(s) to be unlocked by the smart key (namely all doors or driver door only) can be set in the center console display.




### **Opening liftgate**

#### Unlocking liftgate by smart key

With the smart key within the effective range, press and hold the liftgate unlocking button to unlock the liftgate.

#### Unlocking liftgate by micro switch



When you press the liftgate micro switch with smart key in hand or after the vehicle is unlocked, the liftgate will be unlocked.

#### DANGER

- Check that the liftgate is properly closed before driving. Otherwise, the liftgate may open accidentally and knock into the objects nearby, or the objects in the trunk may be thrown out, causing an accident thereafter.
- Prevent the children from playing in the trunk. Otherwise, they may be locked in the trunk by accident and suffer heatstroke, suffocation or other injuries thereafter.
- Prevent the children from operating the liftgate. Otherwise, the liftgate may be opened unexpectedly, or the children may be pinched by the closing liftgate.
- Do not take a ride in the trunk. otherwise serious injury or even death may be caused in the event of emergency braking or collision.

### WARNING

- Before opening or closing the liftgate, please thoroughly check the surrounding area for the sake of safety.
- Remove all loads such as snow and ice on the liftgate before opening the liftgate. Otherwise, your body may be injured by the suddenly opened liftgate.
- Before accessing to the trunk, check that the liftgate is fully opened and secured. Otherwise, your body may be injured by the suddenly closed liftgate.
- Do not install any accessories on the liftgate. Otherwise, they will exert extra weight on the liftgate, causing unexpected closing of liftgate after opening and thereafter personal injury.
- Place loads evenly in the trunk and as near as possible to the rear seat back.
- Secure all loads in the trunk.
- Never load the trunk in such a way that the allowed axle load is exceeded.
- Never place fragile, flammable and explosive articles in the trunk.
- Ensure that container of fluids placed in the trunk will not leak.
- Be careful not to get your fingers or other body parts pinched when closing the liftgate.



### **CAUTION**

- Prevent the liftgate from scratching loads in the trunk when closing the liftgate, otherwise, the liftgate or concerning load may be damaged.
- Fill the trunk in a reasonable way, and if it is overfilled, do not close the liftgate forcibly, otherwise, the liftgate or loads in it may be damaged.

- The trunk lamp will come on for illumination when the liftgate is opened. If the liftgate is closed, the trunk lamp will go out automatically.
- ♦ If the liftgate is not completely closed, the trunk lamp may stay on.



## **Closing of liftgate**


The manual closing method of the liftgate is as follows:



- 1. Pull the liftgate closing handle to lower the liftgate appropriately.
- 2. Press the liftgate from the outside until the liftgate is locked securely.



### Door opening from outside



Unlock the vehicle, and after the flush-fit door handle extends automatically, pull the handle to open the door.

### WARNING

 Prevent hand pinching by door handle when locking the vehicle.

### **CAUTION**

- Do not press the extended door handle forcibly, otherwise, the door handle will be damaged.
- Stow the flush-fit door handle before washing the vehicle, so as to avoid water entry into the inside of door handle during washing and thereafter vehicle damage.



### Interior lighting

#### Intelligent ambient light (IAL)

If the IAL function is switched on in the center console display, the interior ambient light will come on after the ignition switch is set to ON, providing for driver a slightly bright and comfortable driving environment, alleviating driving fatigue and enhancing driving experience.

The brightness, on/off of drive mode following mode and color of ambient light can be set on the center console display.

## **NOTE**


- The ambient light is automatically turned off when the rest mode is activated, and turned on when the rest mode is deactivated. In the rest mode, the ambient light can be turned on again on the center console display.
- Drive mode following mode of ambient light
  - When the drive mode following mode is activated, the ambient light will automatically switch colors following the drive modes.

Ambient light color	Ambient light color
ECO	Green
NORMAL	White
SPORT	Red
I-PEDAL	Ice blue


#### Automatic on/off of reading lamp

Click the button on the center console display to enter the quick control interface, and set the reading lamp to DOOR position, so the reading lamp will be turned on/off automatically according to the status of door and vehicle power supply.

#### Manual on/off of reading lamp



Press a front reading lamp to turn on/off the front reading lamp of concerning side.



When you press the rear reading lamp switch on both sides, the rear reading lamp of concerning side will be turned on/off.



### Introduction to seat belt

Seat belt is a main safety protection device, which can effectively reduce personal injury in an accident when being used together with the airbag. Therefore, be sure to fasten the seat belt before driving.

### **▲** WARNING

- Each seat belt is for one person only.
   Do not share a seat belt with other persons (including children).
- Passengers in rear seat are also required to fasten the seat belt properly; otherwise, they may be thrown out when an accident occurs, and then they will be injured seriously and even cause serious personal injury to other passengers and the driver.
- Put the child in a rear seat, and use a suitable child restraint system.
- Take the correct sitting posture, so as to ensure that the seat belt will play to its full for safety protection in case of emergency braking or accident.
- Do not use a faulty seat belt until it is repaired.
- Never install, remove, modify, disassemble or dispose of a seat belt without authorization.

### **CAUTION**

- Prevent the seat belt and its tongue from being pinched by the door, otherwise, the seat belt may be damaged.
- Check the seat belts regularly.
- If the seat belt assembly does not work properly, it is recommended to contact GAC AION sales store for repair or replacement immediately.
- Always replace the seat belt system (including its bolts) if it is used during an serious collision accident, even though no obvious damage is found.



### **Correct sitting posture**

#### Correct sitting posture of the driver



- Adjust the seat position so that the pedal is easily accessible and the elbow is slightly bent when you hold the steering wheel.
- Adjust the seat back so that you can operate the steering wheel when you sit up straight without leaning forward.
- Adjust the headrest so that the center of the headrest is flush with the upper end of ears.
- 4. Fasten the seat belt correctly.

# Correct sitting posture of the passengers

- Adjust the position of front passenger's seat to keep an appropriate distance from the instrument panel.
- Adjust the front passenger's seat back so that your back is straight up and fits the seat back closely.
- 3. Adjust the headrest to ensure that the center of the headrest is flush with the upper end of the passenger's ears.
- 4. Fasten the seat belt correctly.

### **M** WARNING

- During driving, maintain a correct sitting posture, and keep your back fitting the seat back closely, otherwise serious injury may occur in case of emergency braking or accident.
- The driver should keep a proper distance from the steering wheel.
- Do not place a back cushion on the seat.


- ◆ The driver's seat can be adjusted longitudinally by 220mm, and the standard longitudinal seat position is 40mm in front of the rearmost position; the standard angle of the seat back is a backward inclination of 25° (the seat back can be adjusted forward from the standard position by 20° and backward by 66°); the driver's seat can be adjusted vertically by 55.6mm, and the standard vertical seat position is 26.8mm above the lowest position.
- ◆ The front passenger's seat can be adjusted longitudinally by 220mm, and the standard longitudinal seat position is 40mm in front of the rearmost position; the standard angle of the seat back is a backward inclination of 25° (the seat back can be adjusted forward from the standard position by 20° and backward by 66°).



#### Correct use of seat belts


#### Fastening the seat belt correctly

1. Adjust the sitting posture correctly.



- Gently pull out the seat belt, route it across the chest and hip, and insert the tongue into the buckle until you hear and feel the latch engage.
- Pull the seat belt in the opposite direction, confirming that the seat belt is locked securely.
- 4. Adjust the position of the seat belt.
  - Always route the shoulder belt over your shoulder. The belt should be away from your neck, but not falling off your shoulder.
  - The lap belt should be worn low across the pelvis.

#### Unfastening the seat belt



- Hold the seat belt and press the red button next to the seat belt buckle, so the tongue will spring up automatically.
- Slowly retract the seat belt back into the retractor.

### 1

#### DANGER

- Do not place the shoulder belt under the arm.
- The lap belt should be worn as low as possible across the pelvis, and if it is worn too high or is not properly tensioned, the occupant may suffer personal injury or even death due to body movement in the event of collision or other accident.

### **▲** WARNING

- Never unfasten the seat belt when the vehicle is running or before the vehicle comes to a complete stop.
- After the tongue springs up, guide the seat back to retract slowly with hand, so as to prevent personal injury due to quick retraction of seat belt.



### WARNING (Cont'd)

- For patients and disabled persons. please follow the doctor's advice, and be sure to wear the seat belt
- Do not place any item between the body and the seat belt.

### **CAUTION**

- If the seat belt cannot be retracted smoothly, check it for twist or deflection. If the seat belt assembly does not work properly, it is recommended to contact GAC AION sales store for repair or replacement immediately.
- Buckles of rear seat belts are placed in grooves of rear seats. Rear seat occupants can take them out when necessary to wear seat belts. Buckles of seat belts should be put into the grooves after use.

### How does a pregnant woman correctly fasten the seat belt?



For pregnant women, wearing a seat belt correctly can effectively reduce the injuries suffered by her and her fetus in case of collision or sudden stop.

The shoulder belt should be worn across the shoulder, and the lap belt should be worn low across the pelvis and away from the abdominal area. The seat belt must be worn smoothly, without exerting stress to the lower body of pregnant women.

### 1 DANGER

- The pregnant occupant should consult her physician to fasten the seat belt correctly.
- Be sure to wear the seat belt correctly. otherwise the pregnant woman and her fetus will be seriously injured or killed in case of emergency braking or collision.



### WARNING

Do not place any item between the body and the seat belt.



### Seat belt reminder

If the driver or passenger does not fasten the seat belt after the vehicle is started, the indicator lamp 🙏 or 🐴 on the instrument panel will flash or stay on.

### **NOTE**

◆ If the driver or front passenger does not fasten the seat belt at a certain vehicle speed, the buzzer will sound, and a corresponding warning text message will be shown in the instrument.




### Introduction to airbag

In the event of a serious collision, the airbag will inflate and deploy quickly to reduce the risk of serious injury to the passenger inside the vehicle together with the seat belt.

#### Layout of airbags

The supplemental restraint system (SRS) consists of driver's airbag (in the steering wheel trim cover), front passenger's airbag (in the instrument panel in front of the front passenger), side airbag (in the front seat) and side curtain airbag (in the left and right roofs), and all the arrangement positions of airbags are identified with the "AIRBAG" marking.



- Driver's airbag
- 2 Front passenger's airbag
- ③ Front side airbag
- 4 Side curtain airbag

### DANGER

- The driver and all passengers in the vehicle must fasten the seat belt correctly.
- The airbag will produce a great impact force during deployment, and will cause serious personal injury or even death when the passenger is sat too close to the airbag.
- The infants and babies may be seriously injured or even killed by the deployed airbag if not properly protected. When the baby is too small to use the seat belt, it is required to apply an appropriate child restraint system for protection.
- Do not place, install or paste any objects on the instrument panel, steering wheel, or other places where the airbag is installed. Otherwise, those objects will be ejected when the driver's airbag or front passenger's airbag deploys, causing serious injury or even death.
- Never use seat accessories that will cover the front side airbag; otherwise, such accessories may hinder the deployment of front side airbag, causing system failure or unexpected deployment of front side airbag, and thereafter serious injury or even death of passengers.
- Never install or paste any object on windshield, door window, side pillar, roof, etc.
- Do not attach coat hanger or other hard objects to the roof or safety handrail. Otherwise, they will be ejected when the side curtain airbag deploys, causing serious injury or even death of passengers.



#### DANGER (Cont'd)

- Never install, remove, modify, disassemble or dispose of the SRS without authorization.
- Before scrapping the vehicle, it is recommended to contact the GAC AION sales store or other qualified third party for dismantling and scrapping of the airbag.

### WARNING

- Maintain a correct sitting posture and fasten the seat belt properly when the vehicle is traveling.
- Adjust the front seat to such a position that it is enough far away the instrument panel or steering wheel, and adjust the seat back straight up as much as possible.
- Never allow a child to take the front passenger's seat.
- Do not sit on the edge of the seat or lean on the instrument panel.
- Do not lean on the door and side pillar.
- Never place any object on the leg when the vehicle is traveling.
- Ask passengers not to kneel on the seat towards the door or stretch any body part out of the vehicle.
- Immediately after the airbag is deployed, do not touch any related parts for fear of scalding.
- If you feel breathless after the airbag is deployed, open the door or window for ventilation, and leave the vehicle provided the safety is ensured, and rinse away the residues on the body.
- The airbag is designed for deployment by one time only, and if it is deployed, always replace it with a new one.

### **CAUTION**

- Neither hit nor exert a great force to the area where the airbag component is located or the front door, otherwise it may cause failure or unexpected deployment of airbag.
- Check the SRS regularly. If any of the following conditions occur. it is recommended to contact GAC AION sales store for inspection or replacement of SRS as soon as possible:
  - when any airbag is deployed.
  - when the front part of the vehicle. the door or the area around the door is damaged or deformed. or the vehicle incurs an accident that is not sufficient to deploy the airbag.
  - when the airbag is scratched, cracked or otherwise damaged.

- The driver is required to keep a distance of about 25cm from the driver's airbag. If the distance is less than 25cm after sitting, please adjust the seat position. Ensure that the driver's seat is such adjusted that the brake pedal, steering wheel and control switches are easily accessible to ensure effective control
- When the vehicle is resold, keep the new owner informed of the arrangement and replacement record of airbags on the vehicle.




### **SRS** warning lamp

After the vehicle is started, the SRS warning lamp 🧩 will be on for several seconds, and then go out when no problem is found after self-test. If the warning lamp does not go out after self-test, or goes on again during driving, it indicates that the SRS is faulty, and in this case, please contact the GAC AION sales store for inspection or replacement.



### Airbag deployment

The deployment of airbag depends on the vehicle speed, collision angle, accident type, obstacle and other factors at the time of collision.



The airbag may deploy under the following situations:

- 1 Nose-down to the ground when the vehicle crosses a deep groove.
- 2 Hitting a roadside protrusion, curb, etc.
- 3 Nose-down to the ground when the vehicle runs down a steep slope.

The airbag may not deploy under the following situations:

- 4 A collision with concrete pillars, trees or other elongated objects.
- 5 A rear-end collision with lower end of a truck.
- 6 A rear-end collision by another vehicle.
- 7 A rollover.
- A collision with a wall or another vehicle, other than frontal collision.



- When the airbag deploys:
  - The deployment (inflation) speed is very high, which may cause minor scratch, scalding or other injury.
  - It will produce large noise and a small amount of smoke.
  - The airbag and the area around it will be very hot.
  - The windshield may be broken.
  - The vehicle will automatically cut off the high-voltage power supply.
  - The hazard warning lamp will be turned on automatically.



### **Notices for children**



Please follow the warning label on the sun visor: Do not install a child restraint system on the front passenger's seat.

### 

- Do not place a rear-facing child seat on the seat with frontal airbag. Otherwise, the child may be seriously injured or even killed by the impact force produced by sudden inflation of front passenger's airbag when an accident occurs.
- Always install the child seat in strict accordance with the installation instructions provided by the manufacturer of the child restraint system. Otherwise, the child may be seriously injured or even killed in case of emergency braking, emergency steering or accidents.
- It is not recommended to hold the child for protection, because the child may bump into the windshield or be crushed in the event of an accident.
- Never leave the child alone in the vehicle, and ask the child not to use the smart key.
- Do not allow the child to lean on the airbag deployment area such as door and side pillar even if he/she is well protected in the child seat. Otherwise, the child may be seriously injured or even killed by the impact force produced by airbag deployment.
- The installation of a child seat on a rear seat may affect the use of seat belt of adjacent seat.
- Prevent the child from playing with the seat belt. Otherwise, when the seat belt is entangled around the child's neck, suffocation, or other serious injury and even death may be caused. If this happens and the seat belt cannot be unbuckled, it is recommended to cut the seat belt with a pair of scissors.



### WARNING

- Please choose a child seat suitable for the age, height and weight of the child.
- Before driving, please apply the child safety lock and lock the window of concerning side, so as to prevent the child from opening the door or door window unexpectedly.
- To install the child seat on a rear seat, please adjust the front seat to such a position that the access of child and the use of child seat will not be affected.
- If the driver's seat position causes inconvenience to the use and installation of child seat, please install the child seat on the right rear seat.
- Always use the child seat in strict accordance with the operation instructions provided by the manufacturer of the child restraint system.
- Please restrain the child on the seat properly even if the child restraint system is not used. Do not place a child seat in the vehicle without proper securing.

### **CAUTION**

The child restraint system may incur hardly-detectable damage when the vehicle is heavily collided in an accident, and thus after a serious collision, please stop using the child restraint system.

- Always remember and abide by the precautions and regulations related to the child restraint system.
- Not all child seats are suitable for this vehicle. Therefore, please confirm the suitability of the child seat to be used or bought.
- The child seat has high restraint and inclusion effect, and thus it is recommended to apply the child seat from the time when the baby is born to make him/her be accustomed to the child seat, and intermittent use may stimulate his/her dislike to the child seat.



### **Child safety lock**




When a child takes a rear seat, please move the switch to locking position ① before closing the door. At this time, the door cannot be opened from inside, so as to prevent the child from opening the door unexpectedly.

To unlock the child safety lock, open the door from outside, and move the switch to unlocking position ②.

# ISOFIX child restraint system

ISOFIX interface is an anchorage interface for hard connection with the child seat which supports the ISOFIX system.



There are four ISOFIX anchorages ① provided between the rear seat back and the rear seat cushion for installation of child seat. Label ② is used to indicate the position of ISOFIX anchorage.

# LATCH child restraint system

LATCH interface is an anchorage interface for flexible connection with the child seat which supports the LATCH system.



The LATCH anchorage is located on the back of rear outboard seat.



### Applicability of child seats

Please select an appropriate child seat and install it in the correct position according to the table below.

Information about the applicability of different seating positions for child seats

	Seating position			
Weight group	Front passenger's seat	Rear outboard seat	Rear center seat	
Group 0 (0~10kg)	X	U	X	
Group 0+ (0~13kg)	X	U	X	
Group I (9~18kg)	X	U/UF/L	X	
Group II (15~25kg)	X	UF	X	
Group III (22~36kg)	X	UF	X	

The meanings of letters in the table are as follows:

U = Suitable for general category child restraint system approved for this weight group.

UF = Suitable for general category forward-facing child restraint system approved for this weight group.

X = Not suitable for child restraint system of this weight group

L = Suitable for the listed special child restraint systems, which may be for special vehicles, or of restricted or semi-general categories.



For some child safety seats, a size class is specified. Be sure to check the size class according to the manufacturer's instructions, packaging, and child safety seat label. For guidance on proper installation, please refer to the instructions of the child safety seat.



## Information about the applicability of different ISOFIX positions for ISOFIX child seats

			Seating position		
Weight group	Size class	Fixture module	Front passenger's seat	Rear outboard seat	Rear center seat
Corny cot	F	ISO/L1	X	X	Х
Carry-cot	G	ISO/L2	X	Х	Х
Group 0 (0~10kg)	Е	ISO/R1	X	IUF/IL	Х
	С	ISO/R3	X	IUF/IL	Х
Group 0+ (0~13kg)	D	ISO/R2	X	IUF/IL	Х
	Е	ISO/R1	X	IUF/IL	Х
	Α	ISO/F3	X	IUF/IL	Х
	В	ISO/F2	X	IUF/IL	Х
Group I (9~18kg)	B1	ISO/F2X	X	IUF/IL	Х
	С	ISO/R3	X	IUF/IL	Х
	D	ISO/R2	X	IUF/IL	Х
Group II (15~25kg)	1	1	X	IUF	Х
Group III (22~36kg)	1	1	X	IUF	Х

The meanings of letters in the table are as follows:

IUF = Suitable for general category forward-facing ISOFIX child restraint system approved for this weight group.

IL = Suitable ISOFIX child restraint system recommended for this vehicle.

X = ISOFIX positions are not suitable for ISOFIX child restraint system of this weight group/size class.



For some child safety seats, a size class is specified. Be sure to check the size class according to the manufacturer's instructions, packaging, and child safety seat label. For guidance on proper installation, please refer to the instructions of the child safety seat.



Size class and description of corresponding child seat

Size class	Description of corresponding child seat
Α	Full-height front-facing child seat for toddler
В	Height-reduced front-facing child seat for toddler
B1	Height-reduced front-facing child seat for toddler
С	Full-size rear-facing child seat for toddler
D	Size-reduced rear-facing child seat for toddler
E	Rear-facing child seat for infant
F	Left-facing child seat for infant (carry-cot)
G	Right-facing child seat for infant (carry-cot)



### Switch-on/off of vehicle power supply

#### Switching on the vehicle power supply

After the vehicle is unlocked and either front door is opened, the center console display will go on, and the vehicle power supply will be switched on automatically.

#### Switching on the vehicle power supply by remote control

To switch on the vehicle power supply by remote control, press the locking button on the smart key within the effective range of the smart key, and then press and hold the power-on button \(\bigcap\) on the smart key quickly until the turn signal lamps flash, indicating that the vehicle power supply is switched on successfully by remote control.

#### Entering driving ready status

When you close the doors, fasten the seat belt, depress the brake pedal, and set the shift lever to the desired position, the

**READY** indicator lamp on the instrument panel will come on, indicating that the vehicle is ready for driving.

#### Switching off the vehicle power supply

After driving, stop the vehicle and set the shift lever to "P" position. After the driver and front passenger get off the vehicle and lock it, the vehicle power supply will be switched off automatically.

The vehicle power supply can also be switched off through the drop-down menu of the center console display.

#### Power holding

When the driver needs to leave the vehicle temporarily with on-board electrical equipment not switched off (for example, keep the A/ C working when there is an elderly person or a child in the rear seat), please stop the vehicle in a safe place, set the shift lever to "P" position, and enable the power holding function through the drop-down menu of the center console display. Then after you get off the vehicle, the vehicle power supply will not be switched off, and on-board electrical equipment will keep working.


### **M** NOTE

- If the front passenger's seat is still occupied by a person after the driver gets off the vehicle, the vehicle power supply will not be switched off automatically, and the on-board electrical consumers will keep working.
- ◆ If the battery SOC drops below 10% with the power holding function activated, the vehicle power supply will be switched off automatically for power saving.
- After the power holding function is activated, the anti-theft alarm and intelligent active locking/unlocking function are disabled, and the vehicle can be locked with the smart key.
- The vehicle power supply will be switched on automatically when the front door is opened, and if the driver's seat and front passenger's seat are not occupied, the vehicle power supply will be switched off automatically after a certain period of time for power saving.
- After driving, stop the vehicle and set the shift lever to "P" position. After the driver and front passenger get off the vehicle but do not lock it, the vehicle power supply will not be switched off automatically. But when the battery SOC is too low, the vehicle power supply will be switched off automatically.
- If you press and hold the remote poweron button \(\hat{\rm}\) on the smart key with vehicle locked after the vehicle power supply is switched on by remote control, the vehicle power supply can be switched off by remote control.
- If no operation is performed on the vehicle after the vehicle power supply is switched on by remote control, the vehicle power supply will be switched off automatically after a certain period of time



## Seat adjustment

#### Headrest adjustment



Pull the headrest up in place.

Press the headrest button while pressing the headrest down in place, and then release the button.


#### Power seat adjustment



- Push the seat position adjusting switch

   forward and backward to adjust the front and rear positions of the seat.
- 2. Turn the tip of the seat position adjusting switch ① up and down to adjust the seat height.
- Turn the seat back reclining switch @ forward and backward to adjust the tilt angle of the seat back.

### Manual seat adjustment



- Pull up the middle of the seat position adjusting lever ①, slide the seat to the required position, and release the adjusting lever.
- Pull up the seat back reclining handle
   tilt the seat back forward or backward by the back pressure to adjust the seat back to the desired angle, and then release the handle.

#### Rear seat folding

1. Adjust the rear seat headrest to the lowest position.



- Pull the folding handles ① on the left and right of rear seat to unlock the rear seat.
- Pull the rear seat back forward to make it come into contact with the seat cushion, and fold the rear seat back.



Push the rear seat back in contact with the seat cushion backward to the locking position to restore the rear seat back.

#### DANGER

- It is forbidden to adjust the seat during driving. Otherwise, the seat may move unexpectedly, causing the driver to lose control of the vehicle.
- It is forbidden to tilt the seat back excessively. Otherwise, the lap belt may slip over the hip and directly strangle the abdomen, or the shoulder belt may touch the neck, thus increasing the risk of serious injury or even death in case of accident.
- During driving, never sit in a folded seat or in the trunk.

## WARNING

- Please take care not to hurt other passengers when adjusting the seat position.
- Make sure there is enough space for feet, for fear of pinch injury.
- Do not place hands under the seat or near moving parts, for fear of pinch injury.
- For manual adjustment of the tilt angle of the seat back, make sure that the body back gets close to the seat back to prevent unnecessary injury caused by fast folding of the seat back.
- After the seat is adjusted, try pushing the seat and seat back forward and backward to make sure that the seat and seat back are firmly locked.

## **CAUTION**

- When front seat backs are laid flat, it is forbidden to ride or place heavy objects on the seat backs. Otherwise. the seats may be damaged.
- Rear seat backs shall be folded and unfolded slowly to avoid damage or abnormal function of the rear seat helts

- For some models, the driver's seat can be adjusted through the center console display.
- The power seat cannot be adjusted a period of time after the collision.
- Rear seat backs adopt 4/6 split folding design. When a single seat back needs to be folded, pull up the folding handle of the rear seat back on the corresponding side.



## **Adjustment of exterior** rearview mirror


On the exterior rearview mirror adjustment interface in "My Car" on the center console display, adjust the exterior rearview mirror to a suitable angle.

#### /I DANGER

- It is forbidden to adjust exterior rearview mirrors during driving.
- Object images reflected by exterior rearview mirrors are smaller than real objects, and the actual distance between the object and the vehicle will be closer than it looks. Never misestimate the distance from the following vehicle, for fear of accidents.

## **Adjustment of interior** rearview mirror

Before driving, it is required to adjust the interior rearview mirror to the appropriate angle.



Adjust the interior rearview mirror up and down, left and right to the best rear view position.

When the lamplight of the rear approaching vehicle is dazzling, pull the flip handle ① at the lower end of the interior rearview mirror for mitigation.




### DANGER

♦ It is forbidden to adjust interior rearview mirror during driving.



## Window control

#### Introduction to driver side power window buttons



- 1 Driver side power window button
- 2 Front passenger side power window button
- 3 Left rear power window button
- 4) Right rear power window button
- 5 Passenger side window lock button

#### Driver side window adjustment

Press or pull the corresponding window button gently and hold it to adjust the window to the desired position and then release the button.

Press or pull the corresponding window button beyond the pressure point and release it, to allow the window to automatically open or close completely. (Express-up & down)

During express-up & down of windows, the windows can be held in current positions by operating the buttons.

#### Passenger side window locking

Press the passenger side window lock button (5) to disable the passenger side window button.

Press the passenger side window lock button 5 again to restore the passenger side window button.

#### Window anti-pinch function

If the window glass is hindered when it automatically rises, it will stop rising and immediately descend for a certain height.

#### WARNING

- The driver is responsible for the operation of all power windows. including the operation by passengers. Never allow children to operate the power windows, for fear that the power windows may pinch children or other passengers.
- When there are children in the vehicle, it is recommended that the passenger side window locking function be activated.
- During operation on windows, make sure that no part of the driver and passenger's bodies will be pinched.
- ♦ It is forbidden to test the anti-pinch function intentionally in any way.
- The anti-pinch function may not work when the window is about to close completely.

# **CAUTION**

- It is forbidden to operate 2 or more windows at the same time. Otherwise. the vehicle may be damaged.
- It is prohibited to operate the same window in opposite directions by pressing the left front power window button and other passenger side power window buttons at the same time. Otherwise, the power window may stop working.
- Continuous express-up & down operation for many times in a short time may lead to temporary failure of express-up & down function.



## (cont'd)


- Triggering the window anti-pinch function several times in a short time will lead to the failure of the window anti-pinch function.
- When the window express-up & down or anti-pinch function fails, initialization is required to restore the function. (For details, refer to "Emergency treatment - Owner emergency - Window initialization")

## **NOTE**

- For some models, the opening and closing of windows can be controlled through the center console display.
- Passenger side windows are operated in the same way as the driver side window
- After the driver leaves the vehicle, if any window is open, when the vehicle detects rain, the four windows will be automatically closed at once. (if available).
- With the vehicle stationary and the shift knob in "P" position, when the left front door is opened, if any window is open at this time, the buzzer on the instrument panel will sound and a relevant text prompt will be displayed.
- ◆ Before leaving the vehicle, please check that windows are closed

## Sunroof control

#### **Description of sunroof buttons**



- Sunshade opening button
- 2 Sunshade closing button
- Sunroof opening button
- 4 Sunroof closing button

#### Opening sunshade

Press the sunshade opening button ① to open the sunshade, and release the button to stop the sunshade.

Press and hold the sunshade opening button ①, and then release the button to enable the sunshade to open fully automatically. During opening, press the sunshade opening or closing button again to stop the sunshade.

#### Closing sunshade

Press the sunshade closing button ② to close the sunshade, and release the button to stop the sunshade.

Press and hold the sunshade closing button ②, and then release the button to enable the sunshade to close fully automatically. During opening, press the sunshade opening or closing button again to stop the sunshade.



#### **Opening sunroof**

Press the sunroof opening button 3 to tilt the sunroof. Press the button again to open the sunroof. And release the button to stop the sunroof.

Press and hold the sunroof opening button 3 to enable the sunroof to open fully automatically. During opening, press the sunroof opening or closing button again to stop the sunroof.

#### Closing sunroof

Press the sunroof closing button 4 to close the sunroof. And release the button to stop the sunroof.

Press and hold the sunroof closing button 4 . and then release the button to enable the sunroof to close fully automatically. During opening, press the sunroof opening or closing button again to stop the sunroof.

#### Sunroof/sunshade anti-pinch function

If the sunroof/sunshade is hindered when it automatically closes, it will stop at the hindered position and immediately open for a certain distance.

#### DANGER

 During driving, do not stretch any body part out of the sunroof; otherwise, severe personal injury and even death may occur due to scratching by outside objects or during emergency braking.

## WARNING

- The driver is responsible for the operation of the sunroof by all occupants. To prevent accidental operation (especially by children). do not allow children to operate the sunroof; otherwise, the sunroof may pinch children or other passengers.
- During operation on the sunroof, make sure that no part of the occupants' bodies will be pinched.
- Do not activate the anti-pinch function by pinching any part of body intentionally.
- The anti-pinch function may not work when any object is pinched by the sunroof, which is about to close completely.

### **CAUTION**

- Please close the sunroof: otherwise there will be a risk of water ingress on rainy days.
- If the sunroof or sunshade automatic opening and closing function fails, learning may be performed on the sunroof or sunshade according to initialization procedure to restore the automatic opening and closing function. (For details, refer to "Emergency treatment - Owner emergency - Window initialization")
- If the sunroof anti-pinch function fails, learning may be performed on the sunroof according to the initialization procedure to restore the anti-pinch function. (For details, refer to "Emergency treatment - Owner emergency - Window initialization")



## **NOTE**

- The sunshade closes together with the sunroof.
- The sunroof opens together with the sunshade.
- With the vehicle stationary and the shift knob in "P" position, when the driver's side door is opened, if the sunroof is open at this time, the buzzer on the instrument panel will sound and a relevant text prompt will be displayed.
- After the driver leaves the vehicle, if the sunroof is open, when the vehicle detects rain, the sunroof will be automatically closed at once. (if available).
- ♦ Before leaving the vehicle, please check that the sunroof is closed.

## Steering wheel control



Left buttons on steering wheel

Switching the display information on instrument panel

VIEW Switching themes of the instrument panel

Resetting the driving information on the instrument panel, switching alarm information

Restoring/increasing the cruising speed

Decreasing the cruising speed

Adjusting the following distance for cruise control

2 Right buttons on steering wheel



Waking up mobile phone voice recognition function after the mobile phone is connected (via CarPlay or Android Auto)

Answering/ hanging up/ making a Bluetooth call

Press this button to switch sound sources/ press and hold this button to pause playback
Shortcut key (customizable in

the center console display)

→ / — Volume control





- 3 Horn sign
  - Press this area to sound the horn, and release it to mute the horn.

## **NOTE**

- Depending on the configuration, buttons on the steering wheel may vary. For specific buttons, the configuration of the actual vehicle shall prevail.
- Some buttons of the steering wheel can only work when certain conditions are met.

## Steering wheel adjustment

Before driving, adjust the steering wheel to the appropriate position so as to drive the vehicle more comfortably and safely.



- 1. Unlock the steering wheel by pulling the steering wheel locking handle down.
- 2. Adjust the steering wheel to the desired position.
- 3. Pull back the steering wheel locking handle to lock the steering wheel.

# A

#### DANGER

- It is forbidden to adjust the steering wheel during driving. Otherwise, the driver may misoperate the vehicle and cause accidents, resulting in serious injuries and even death.
- After the steering wheel is adjusted, make sure the steering wheel is firmly locked. Otherwise, the steering wheel may suddenly move and cause accidents, resulting in serious injuries and even death.



## Locking doors from inside of vehicle



When doors are closed, press the locking end of the central locking switch inside the vehicle to lock all the doors.

## WARNING

 For driving safety, please lock the doors before driving.

- Do not frequently operate the central locking switch in a short time. Otherwise, the central locking switch may temporarily fail. In this case, after the door lock motor cools down, the central locking can be used again.
- ◆ When any door is ajar, there will be a door ajar prompt on the instrument panel.



#### A/C control

#### A/C quick control area



The A/C quick control area below the center console display interface can be operated to quickly turn on the A/C. After A/C is turned on, quick control on temperature, air supply mode and recirculation/fresh air mode can be achieved

#### Turning on and off the A/C

When the A/C is turned off, click the "Turn on A/C" button in the quick control area of the center console display to turn on the A/C.

When the A/C is turned on, click the button in the A/C control interface on the center console display to turn off the A/C.



 AUTO mode will exit when the fan speed or air supply mode is adjusted.

#### A/C settings

In any interface of the center console display, click the temperature numbers in the A/C quick control area below the center console display to enter the A/C control interface to set the A/C.



- Temperature control area for temperature control of A/C
- ② Air volume control area for air volume control of A/C
- 3 Air direction control area for outlet air direction control of A/C
  - Turning on or off the A/C compressor
  - AUTO Turning on the auto A/C
  - U Turning on or off the A/C
  - Switching the A/C recirculation/ fresh air mode
  - Turning on the front windshield defrost/defog function
  - Turn on the exterior rearview mirror defrost/defog function
  - Turn on A/C ECO mode



### Quick heating or cooling

To achieve quick heating or cooling of cabin, select the quick cooling or heating scene in the A/C scene interface.

#### Distribution and operation of air outlets

Front air outlet




- Pull the front air outlet fork up and down, left and right to adjust the air direction of the front air outlet.
- Pull the air outlet fork left and right to the limit positions to control the air outlet to the maximum opening or close the air outlet

## NOTE

◆ The control mode of the front air outlets is generally the same. Here, the front central air outlet is introduced as an example.

#### Rear air outlet



- Pull the rear air outlet fork up and down, left and right to adjust the air direction of the rear air outlet.
- Pull the air outlet fork left and right to the limit positions to control the air outlet to the maximum opening or close the air outlet.

## **MARNING**

- Long-term activation of recirculation mode will cause accumulation of carbon dioxide in the cabin, which is bad for keeping the driver clearheaded.
- Activation of the recirculation mode in cold or rainy days can cause the windows to mist up, affecting the driver's visibility.
- The front windshield defrost/defog function may cause the outer surface of front windshield to mist up, affecting the driver's visibility.
- When the front windshield defrost/ defog function is active at ambient temperature above 0°C, if the A/C compressor is turned off, the front windshield may mist up, affecting the driver's visibility.




## **NOTE**

- In AUTO mode, when the outlet air is at high temperature, most of the air comes out through the floor outlets; when the outlet air is at low temperature, most of the air comes out through the panel outlets.
- When the A/C is on, click the A/C button in the center console display to make the A/C system exit the cooling mode and blow natural air.
- The temperature shown in the center console display is the target value of the temperature setting, rather than the measured inside temperature.
- To ensure the best air distribution effect, make sure that all air outlets in the cabin are open.
- For some models, the self-drying function with an evaporator can be turned on through the center console display to prevent the A/C system from damp and mold.

## Storage space

#### Storage box on door interior trim panel



The storage box on door interior trim panel can be used to store maps, beverage bottles, etc.



 When storing drinks in the storage box on door interior trim panel, ensure that the drinks are sealed to prevent liquid spill during driving.

#### Front central armrest box




Pull up the central armrest as arrowed, and open the central armrest box.



## **⚠** WARNING

 During driving, make sure that the central armrest box is closed.

#### Front cup holder



The front cup holder is used for storing cups or beverage bottles.



When placing a cup or beverage bottle, ensure that it is sealed to prevent liquid spill during driving.

#### Console storage slot



Storage slot under console is for placing mobile phone and the similar.


## Console storage box



Press the area indicated by the arrow on the console storage box to open it.

Press the console storage box cover until it is locked for closing.

#### Storage box under console




The storage box under the console is used to store other items.

## WARNING

Do not place items in the storage box that may protrude from the edge of the storage box.



#### Glove box



Press the glove box switch to open the glove box.

Push the glove box upward until it is latched and close the glove box.



Make sure the glove box is closed during driving.

## Safety handrail



When the vehicle is running fast or on a bumpy road, the safety handrails can be used to keep the body balanced.

## **CAUTION**


- Do not pull the safety handrail when getting on or off the vehicle or getting up from the seat.
- It is forbidden to hang any heavy objects on the safety handrails.



### Sun visor



Sun visors are located above the driver's seat and front passenger's seat. Turn down the sun visor to block the dazzling light from the front.



After the sun visor is turned down, disengage the fastening hook 1 and turn the sun visor to the side window to block the dazzling light from the side.

## Vanity mirror and vanity mirror lamp

The vanity mirror and vanity mirror lamp are located on the sun visor. Turn down the sun visor and lift the vanity mirror cover to use the vanity mirror and vanity mirror lamp.



- Vanity mirror lamp
  - Open the vanity mirror lamp cover, so the vanity mirror lamp comes on automatically.
- 2 Vanity mirror

## NOTE

 With the vanity mirror lamp on, if the vehicle is powered off or locked, the vanity mirror lamp will automatically go out after several minutes.



## 12V power outlet



Enter the vehicle, lift the 12V power outlet cover and connect an electrical consumer at the same time to use the 12V power supply.

## **▲** WARNING

- When there is nobody in the vehicle, it is forbidden to leave the 12V power outlet in use.
- Never allow children to use or play with the 12V power outlet.
- The power outlet has the output voltage of 12V and the maximum output power of 120W. It is forbidden to connect electrical consumers of more than 120W to the power outlet.

## **CAUTION**


- When starting or powering off the vehicle, the electrical consumers connected with the 12V power outlet should be disconnected to avoid damaging the electrical consumers due to voltage fluctuation.
- It is forbidden to insert foreign matters into the 12V power outlet.
- It is forbidden to spill water or other liquids in the 12V power outlet.
- It is forbidden to disassemble or modify the 12V power outlet.

## **USB** port

#### Arrangement of USB ports




Front USB port



Rear USB port





Interior rearview mirror USB port

## **CAUTION**

- It is forbidden to insert foreign matters into USB ports.
- It is forbidden to spill water or other liquids in USB ports.
- It is forbidden to disassemble or modify USB ports.

## **MOTE**

The front USB port can be used for charging and reading data, while the rear USB port and the interior rearview mirror USB port can only be used for charging.



### **Bluetooth connection**

#### **Bluetooth connection**

This vehicle supports functions such as Bluetooth call and Bluetooth music, which can be used after successful Bluetooth connection. Operation steps of Bluetooth quick connection are as follows:

- 1. Turn on Bluetooth on the mobile phone.
- Click on the Bluetooth icon in the system status bar in the upper right corner of the center console display to enter the Bluetooth connection setting interface.
- Click on the Bluetooth switch turn on Bluetooth. After the Bluetooth is turned on, the on-board unit will automatically search for nearby Bluetooth devices.
- Click on the Bluetooth device icon to be connected and complete Bluetooth connection according to the prompts.

#### Bluetooth call

Answer or hang-up

- When there is an incoming call, press the button on the steering wheel to answer the call; press and hold the button on the steering wheel to decline the call
- At the end of the call, press and hold the button → on the steering wheel to hang up the call.

#### Make a call

After Bluetooth connection, enter the Bluetooth call interface, and then dial a number directly, click the contact number to make a call or search a contact to make a call

#### MirrorLink\*

#### CarPlay

Apple CarPlay allows you to use iPhone in the vehicle intelligently and safely, and enables the vehicle multimedia system to share the functions of mobile phones such as navigation, music, call, etc.

- Connection of mobile phone and onboard unit
- Connect the mobile phone with the onboard unit with a USB cable.
- 2. Select "Allow" in the pop-up dialog on the mobile phone.
- 3. Turn on Apple CarPlay on the on-board unit.
- Exit method
  - CarPlay in-car system may be exited by either of following ways:
    - Unplug the USB cable or disconnect the WIFI.
    - Shut down the CarPlay in the mobile phone.

## **NOTE**

 The specific functions of CarPlay depends on the actual condition, and generally include navigation, music, call, etc.

#### **Android Auto**

Android Auto enables the vehicle multimedia system to share the functions of mobile phones such as navigation, music, call. etc.

- Downloading of mobile phone application
  - Android Auto may be downloaded from the APP Store on the mobile phone.
- Connection of mobile phone and onboard unit
- Connect the mobile phone with the onboard unit with a USB cable.
- 2. Run Android Auto.



# Precautions for multimedia use

Read and observe the following when using the multimedia system.

## WARNING

- Be sure to pay full attention during driving, and do not operate or check the multimedia system too frequently. Otherwise, the driver is prone to distraction, causing serious traffic accidents.
- During driving, reduce the multimedia volume in the cabin to listen to the warning sound outside. Otherwise, traffic accidents may occur.
- During route navigation through the navigation system, please drive according to actual traffic rules. Completely following the route planned by the navigation system during driving may violate traffic rules sometimes, which can cause traffic accidents.
- Do not operate the multimedia system in no-parking areas. Otherwise, traffic accidents may occur.
- It is forbidden to disassemble, modify or destroy the multimedia system without authorization. Otherwise, problems such as system failure, fire and electricity leakage may occur.
- Keep the multimedia system dry, and avoid liquid ingress. Otherwise, multimedia system may fail and even fire can occur.
- If the multimedia system fails, do not repair it without authorization. Stop using it and contact the GAC AION sales store for repair.
- Do not use the center console display in a faulty state without images or sounds.

## **CAUTION**

- When cleaning the screen, please turn off the multimedia system first, and then clean it with a soft dry cloth. Do not use hard cloth, chemical cloth or organic solvent (benzene, ethanol, paint thinner, etc.) to clean the screen. Otherwise, the screen may be damaged.
- Do not knock or press the center console display hard when operating it. Otherwise, the screen may be damaged.
- Do not use sharp or angular hard objects to operate the center console display. Otherwise, the screen may be damaged.
- Do not plug and unplug USB devices repeatedly in a short time. Otherwise, USB devices may be damaged.
- The amount of time for identifying a USB device is affected by the type, capacity, or stored file format of the USB device.
- Do not store too many unnecessary files in USB devices. Otherwise, the recognition speed will be affected.
- If heat is generated during charging with USB ports, charging performance may be reduced or failure may occur.
- SD type USB memory stick, CF type USB memory stick, or other USB devices used to connect the adapter may not be recognized.
- USB devices may not be recognized by a common USB cable or extension cable. Please connect the USB devices directly to the USB port for use.
- Vehicle vibration may cause poor contact of USB devices.



## **CAUTION** (cont'd)

- During media playing with USB devices, the opening time of different video and image files may vary. For example, image files that occupy more storage space, and high-resolution video and audio files take more time to open. That it takes too long time to open a file may cause the system to restart.
- Fast forward and rewind of video are based on addressing by frames. The data formats of converted video files may not be standard. There may be irregular fast forward, rewind and even seizure during video playing. Or, some key frames are lost after conversion, which may lead to seizure and restart.

## **MOTE**

- Do not dismantle, modify or destroy the multimedia system without authorization. Otherwise, the product warranty may be invalidated.
- As USB devices may have compatibility problems, the multimedia system cannot recognize all USB devices. In such cases, please replace the USB devices and try again.
- The multimedia system of this vehicle only supports USB devices with FAT16/32 file type.
- As the multimedia system features video playback limitation during driving, it is impossible to watch video during driving. The video playback limitation can be disabled through the center console display. For driving safety, please keep this function enabled during driving.



# Indicator lamps on instrument panel

Name	Icon	Description
Left turn signal indicator lamp	<b>—</b>	The indicator lamp comes on if the left turn signal lamp is turned on
Right turn signal indicator lamp	-	The indicator lamp comes on if the right turn signal lamp is turned on
Position lamp indicator lamp	ED 05	The indicator lamp comes on if the position lamps are turned on
Rear fog lamp indicator lamp	<b>()</b> ‡	The indicator lamp comes on if the rear fog lamp is turned on
High beam indicator lamp	<b>≣</b> D	The indicator lamp comes on if the high beam is turned on
READY indicator lamp	READY	If the indicator lamp comes on, it indicates that the vehicle has started and gears can be shifted
Driver's seat belt warning lamp	Ä	The indicator lamp comes on to remind the driver to fasten the seat belt
Front seat belt warning lamp	<b>4</b> 2	The indicator lamp comes on to remind the front passenger to fasten the seat belt
Charger on indicator lamp	5=	If the indicator lamp comes on, it indicates that the charger is successfully connected with the vehicle charging inlet
AUTO HOLD status indicator lamp	(P)	If the indicator lamp comes on, it indicates that the AUTO HOLD is activated
Electric park brake (EPB) status indicator lamp	<b>(P)</b>	If the indicator lamp comes on, it indicates that EPB is applied



Name	lcon	Description
Cruise control indicator lamp		The indicator lamp comes on when the cruise control function is activated
	(6)	If the indicator lamp comes on, it indicates that the vehicle is in cruise control state
ACC indicator lamp (no vehicle ahead)	S	If the indicator lamp comes on, it indicates that ACC is ready and there is no target vehicle ahead
	S	If the indicator lamp comes on, it indicates that ACC is active and there is no target vehicle ahead
ACC indicator lamp (vehicle ahead)	ÊSÍ	If the indicator lamp comes on, it indicates that ACC is ready and there is a target vehicle ahead
	<b>ি</b>	If the indicator lamp comes on, it indicates that ACC is active and there is a target vehicle ahead
Lateral control indicator lamp		If the indicator lamp comes on, it indicates that ICA is ready
		If the indicator lamp comes on, it indicates that the lateral control of ICA is activated
Hands Off indicator lamp	<i>y</i> •	If the indicator lamp flashes, it indicates that the driver's hands are detected to be off the steering wheel
FCW status indicator lamp	<u>%</u>	If the indicator lamp flashes, it indicates that FCW is activated
Lane departure assist system status indicator lamp		If the indicator lamp comes on, it indicates that the lane departure assist system is in ready state
		If the indicator lamp comes on, it indicates that the lane departure assist system is active



- Refer to the corresponding sections for the detailed functional status of some indicator lamps on the instrument panel.
- Some indicator lamps on the instrument panel are only displayed on vehicles with relevant configurations. Please refer to the actual vehicle.



# Instrument panel warning lamps

Name	lcon	Description
ABS indicator lamp	(ABS)	If the indicator lamp comes on, it indicates that the ABS is faulty.
SRS warning lamp	<b>X</b>	If the indicator lamp comes on, it indicates that the SRS is faulty.
ESP indicator lamp	<b>A</b>	If the indicator lamp comes on, it indicates that the ESP is faulty.
Low voltage battery fault warning lamp	==	If the indicator lamp comes on, it indicates that the 12V low voltage system is faulty.
Low battery indicator lamp		If the indicator lamp comes on, it indicates that the traction battery is too low
EPS indicator lamp	<b>⊘!</b>	If the indicator lamp comes on, it indicates that the EPS system is faulty (the red indicator lamp comes on for some models).
EPB fault indicator lamp	P	If the indicator lamp comes on, it indicates that the EPB is faulty.
Lateral control indicator lamp		If the indicator lamp comes on, it indicates that the ICA system is faulty.
FCW status indicator lamp	ॐं€	If the indicator lamp comes on, it indicates that the FCW system is faulty.
Lane departure assist system status indicator lamp		If the indicator lamp comes on, it indicates that the lane departure assist system is faulty
Cruise control fault indicator lamp	<b>%!</b>	If the indicator lamp comes on, it indicates that the ACC system is faulty.




Designation	lcon	Description
Electric power system fault indicator lamp	$\Leftrightarrow$	If the indicator lamp comes on, it indicates that the electric power system is faulty.
Parking brake and brake system indicator lamp		If the indicator lamp comes on, it indicates that the brake fluid level in the front compartment is low. If the indicator lamp stays on, it indicates that the EBD system is faulty.
Reduced-power indicator lamp		If the indicator lamp comes on, it indicates that the powertrain of the vehicle is overheated or faulty, and the vehicle is running at reduced power
TPMS indicator lamp	(!)	If the indicator lamp comes on, it indicates that the TPMS is faulty.

- ◆ Self-test will be carried out when the vehicle starts, and some instrument panel warning lamps will come on for a short time and then automatically go out. If some warning lamps on the instrument panel are still on after the vehicle starts, please contact the GAC AION sales store for repair in time according to the actual situation.
- ♦ Some warning lamps on the instrument panel are only displayed on vehicles with relevant configurations. Please refer to the actual vehicle.



## Instrument panel



- 1 Left information display
- 2 Vehicle speed information
- 3 Right information display
- 4 Ambient temperature information
- 5 Time information

- 6 Gear information
- Power information
- 8 Drive mode information
- 9 Driving range
- Battery SOC information

## **NOTE**

♦ The instrument panel has many display styles. Please refer to the actual vehicle.



### Left information display

This area shows information such as power consumption and charging condition.

#### Vehicle speed information



 According to laws and regulations, the speed indicated on the instrument panel is generally greater than the actual speed.

### Right information display

This area shows information such as navigation and music synchronized with the center console display.

#### Power information

This area shows current power output or energy recovery condition.

#### Drive mode information

This area shows the current drive mode of the vehicle.

#### **Battery SOC information**

This area shows the current SOC of the battery.

## Information display

Information shown on the left information display includes power consumption, alarm, mileage, door status, tire pressure monitoring, driving assistance (if configured), charging, radar alarm, etc. Please switch the corresponding display information according to the actual vehicle.

The information display on the right side shows information such as navigation and music synchronized with the center console display. Please refer to the actual vehicle.

# Adjusting buttons on left information display of instrument panel



- Paging button
- VIEW theme switching button
- 3 OK button

# How to switch the left information display page of the instrument panel

Press the paging button on the steering wheel to switch the left information display page of the instrument panel.

- Driving assistance information page (if available)
  - Information related to driving assistance (e.g., ACC, FCW) like pedestrian, vehicle and target obstacle in front of the vehicle is displayed. Please refer to the actual vehicle



- ♦ Charging information page
  - When the vehicle is being charged, the charging information is displayed. This page can only be viewed when the vehicle is being charged.
- - This page displays the radar alarm information. This page is displayed only when an obstacle is detected around the vehicle

#### How to switch the instrument panel display theme

Press the VIEW theme switching button on the steering wheel to switch the instrument panel display theme. For specific display style, please refer to the actual vehicle.

#### How to reset the accumulated mileage

- 1. Switch the left information display page of the instrument panel to the mileage information page.
- 2. Press and hold the OK button on the steering wheel to reset the accumulated mileage value.

## **M** NOTE

◆ The total mileage of the vehicle cannot be reset.

#### How to view alarm messages

- 1. When an alarm message appears, the alarm message pops up on the instrument panel. After confirmation, press the OK button on the steering wheel, so the alarm message is transferred to the alarm center.
- 2. Press the page turning button on the steering wheel to switch the left information display page to the alarm center.
- 3. On the alarm center page, press the OK button on the steering wheel to switch to and view different alarm messages.

## **MOTE**

On the alarm center page, other information on the left information display can be switched and viewed by pressing the page turning button on the steering wheel.

#### How to set the volume, units and brightness of the instrument panel

As for the setting items of the center console display, set the volume, units and brightness of the instrument panel.

### WARNING

- During operation on the instrument panel information display during driving, special attention should be paid to the safety of surrounding areas of the vehicle
- During driving, do not keep looking at the information display on the instrument panel. Otherwise, you may not see pedestrians and objects on the road in front of the vehicle. resulting in accidents.

## **CAUTION**

If the information display is abnormal, stop the vehicle immediately in a safe way, and contact the GAC AION sales store for repair.



# Tire pressure monitoring system

The vehicle is equipped with a tire pressure monitoring system, which can monitor and issue alarms about the tire pressure.

#### Tire pressure monitoring system alarm

The tire pressure monitoring system issues an alarm when any of the following conditions occurs:

- ♦ Tires leak rapidly due to a puncture, etc.
- Tires leak slowly for a long time.
- One or more tires are underinflated.
- The road condition is too poor or the vehicle is driven unconventionally for a long time.

#### How to view TPMS alarm messages

When the TPMS indicator lamp (!) comes on, you can switch the instrument panel information display page to the tire pressure monitoring information page via the page turning button on the steering wheel, so as to view the detailed information.

# Initialization of tire pressure monitoring system

To ensure normal operation of tire pressure monitoring system, the tire pressure monitoring system shall be initialized when any of the following conditions occurs:

- One or more tires/wheels are replaced, reinstalled or subjected to dynamic balancing again.
- ♦ Tire rotation
- It has been more than a year since the last initialization.

The difference between the current ambient temperature and the ambient temperature during the last initialization is great.

# How to initialize the tire pressure monitoring system

- Adjust all the tire pressure to the standard value.
- Press the page turning button on the steering wheel to switch the instrument panel information display page to the tire pressure monitoring page.
- Press and hold the OK button on the steering wheel for a long time to initialize the TPMS

- After initialization of TPMS, a relevant warning message will be displayed on the instrument panel.
- ♦ In case of initialization failure, contact the GAC AION sales store for repair.
- After successful initialization, the TPMS can work properly only after the vehicle is driven for a certain distance normally.



#### Precautions for tire pressure monitoring system

Read and observe the following precautions when using the TPMS.

## **▲ WARNING**

- Do not rely entirely on the tire pressure monitoring system. Check the tire status regularly to ensure that the tire pressure is normal and tires are free of damage, e.g. puncture, cut and crack.
- If the indicator lamp of the tire pressure monitoring system comes on, be sure to slow down the vehicle immediately, avoid sharp turns and emergency braking, stop the vehicle safely nearby, and check the tire status as soon as possible.
- The initialization of TPMS is prohibited in the non-standard tire pressure status; otherwise, tread cracking, tire burst or other faults may occur due to too low tire pressure, thus affecting the driving safety.

### **CAUTION**

If the TPMS fault occurs repeatedly, contact the GAC AION sales store for repair.

## **MOTE**

- If the tire pressure is higher than the standard value, the TPMS may be unable to give an alarm.
- The TPMS will not display the actual tire pressure.
- Only tire pressure adjustment without initialization cannot eliminate the tire pressure alarm.



## Vehicle start

Normally, the vehicle may be started as follows:

- Carry the smart key with you and enter the vehicle. Then close all doors and fasten the seat belt.
- Depress the brake pedal without release.
- 3. Rotate the rotary shifter to the desired gear.
- 4. Release the brake pedal after the READY indicator lamp READY in the instrument panel comes on and the vehicle is started and ready for driving. Then the vehicle will drive in the selected gear.

## **NOTE**

 Lock all doors before starting the vehicle and never open any door during driving.

## **Switching of driving modes**

This vehicle allows multiple driving modes, which can be switched according to specific application scenarios.

#### Switching of driving modes

After the vehicle power supply is switched on, switch the driving modes through the center console display.

- - Smooth dynamic response and higher range.
- ♦ NORMAL mode
  - Moderate dynamic response, high ride comfort and moderate range.
- ♦ SPORT mode
  - Fast dynamic response, greater driving pleasure and maximum acceleration
- ♦ I-PEDAL mode
  - I-PEDAL mode refers to an integrated pedal mode, where acceleration, deceleration and braking operation may be carried out by depressing, lifting and completely releasing the accelerator pedal. In I-PEDAL mode , energy recovery rate is high and the range of vehicle can be significantly improved. This mode is especially suitable for urban driving cycle.

#### **CREEP mode\***

After the I-PEDAL mode is activated, the CREEP mode can be activated or deactivated through the center console display. After the CREEP mode is activated, start the vehicle, switch to drive position, release the parking brake and release the brake pedal. In this case, the vehicle can creep slowly without depressing the accelerator pedal.



#### Braking energy recovery\*

The braking energy recovery converts a part of kinetic energy during vehicle braking or coasting into the electric energy of traction battery, thus extending the range of vehicle.

The driver can set the braking energy recovery level through the center console display. The higher the energy recovery level, the greater the energy recovery rate, and the stronger the braking feel of releasing the accelerator pedal during driving.

In the ECO, NORMAL or I-PEDAL mode, the braking energy recovery level can be selected as needed. In the SPORT mode, the braking energy recovery level is unadjustable, and low by default.

## **MARNING**

- The speed reduction caused by the I-PEDAL mode cannot completely replace normal braking. In an emergency, please depress the brake pedal in time.
- When the vehicle runs on a steep slope, the CREEP function may not ensure slow driving. In this case, please depress the brake pedal to prevent sliding on the slope.
- If the vehicle slides on a slope, depress the brake pedal to stop the vehicle. The driver is responsible for paying attention to the state of the vehicle, otherwise a traffic accident may occur.
- After the vehicle is stopped through the I-PEDAL mode, the driver is strictly forbidden to leave the vehicle before the vehicle is parked safely.


## **▲ WARNING (Cont'd)**

- The I-PEDAL mode cannot be used for long-term parking. For long-term parking, set the gearshift lever to "P" position.
- The speed reduction caused by the energy recovery cannot replace normal braking. Depress the brake pedal during deceleration or parking.
- During driving on icy and snowy roads, use the energy recovery function cautiously to prevent vehicle slip caused by the energy recovery.

- In I-PEDAL or ECO mode, the power is limited and may not allow the vehicle to reach the highest speed.
- In some cases, the driving mode may be switched automatically. For example, in ECO mode, when the vehicle is climbing a steep slope or under insufficient power, the vehicle will automatically switch to NORMAL mode.



## Gearshifting



P: parking gear

R: reverse gear

N: neutral gear

D: drive gear

Switch on the vehicle power supply, close the doors, fasten the seat belt, depress the brake pedal, and rotate the rotary shifter to the desired gear. After the gearshifting, the current gear information will be displayed in the instrument panel.



After the vehicle comes to a full stop, press the "P" button to shift to "P" position. Then the EPB is automatically enabled.

## **▲** WARNING


- Never allow the vehicle to coast in neutral gear.
- During temporary stop in "N" gear, be sure to apply the parking brake or step on the brake pedal; otherwise the vehicle may slide, causing an accident.

## 1 NOTE

 For shifting from D or R to N, the rotary shifter shall be moved and held for no less than 2s. Otherwise, shifting to N will fail.



#### **Pedal**



- 1 Brake pedal
- 2 Accelerator pedal

## **M** WARNING

- Never place any items in the driver's footwell to prevent sliding into the pedal area, hindering the driver to operate the pedal, and thus resulting in a traffic accident
- Before driving the vehicle, be sure to check that all pedals can be depressed to the floor and released smoothly at any time.
- The driver must wear suitable shoes which are sensitive to pedal movement.
- Never rest your foot on the brake pedal while driving the vehicle; otherwise the brake temperature will rise abnormally and the brake linings will wear excessively, increasing the braking distance.
- Continuous application of the brake will cause brake overheating and result in braking performance degradation and even braking failure.

- In case of braking circuit failure, the brake pedal requires longer pedal travel to stop the vehicle.
- When the vehicle climbs down a long or steep slope, it is recommended to activate the I-PEDAL mode to brake with the drive motor and reduce the brake load.



## **Brake assist control system**

#### Service brake

# **CAUTION**

- If sharp metallic friction sound is emitted during braking, the brake linings may be close to the wear limit, and it is recommended to contact the GAC AION sales store for inspection in time.
- If the vehicle vibrates or buffets continuously during braking, it is recommended to contact the GAC AION sales store for inspection in time.

## **NOTE**

- ◆ Under certain driving and weather conditions, squeaks, screams, or other noises may be heard from brakes when the brake pedal is depressed for the first time or lightly stepped on, or braking noise during light or moderate braking, especially for new vehicles (as their brakes have not undergone running-in), which is normal, and does not constitute a failure symptom of braking system nor has effects on the braking safety and performance.
- Under normal driving conditions, the dust accumulation due to brake wear will not affect the braking performance.
- If rust and corrosion exist because the brake linings and brake discs are not used or used rarely, noise may be heard from brakes for the first use. This is normal. Safe areas and good road conditions are recommended for braking the vehicle several times to clean the brake linings and brake discs.

#### Anti-lock braking system (ABS)

ABS prevents wheel lockup when you apply the maximum braking force. Under most of the road conditions, the steering control performance of the vehicle can be improved during emergency braking.

During emergency braking, ABS continuously monitors the speed of each wheel and automatically adjusts brake pressure according to the lockup state.

During operation of ABS, you may perceive the brake pedal vibration, which indicates that ABS is working and is normal.

# **⚠** WARNING

◆ The driver should always maintain the safety distance from the vehicle ahead and master the dangerous situation during driving. Although ABS can improve the braking distance, it cannot go beyond the physical law, and also cannot prevent the danger due to tire slip (when the water layer between the road surface and the tire prevents direct contact between the tire and road surface).

#### Electronic brake force distribution (EBD)

During normal braking, the EBD balances the distribution of braking force on front and rear wheels according to the vehicle load, in order to achieve the shortest braking distance under the premise of stable braking. This improves the stability and operability of the vehicle during braking, especially during driving on poor or wet and slippery roads.

#### Electronic stability program (ESP)

The electronic stability program (ESP) determines the driving intention of the driver according to the steering wheel angle and the vehicle speed, and compares it with the actual driving condition of the vehicle continuously. In case of departure from normal driving route (such as in case



of sideslip), ESP makes correction by applying braking force and limiting torque output to the corresponding wheel to ensure the stability of the vehicle.

#### HHC

The hill-start hold control (HHC) is mainly used to help the driver to pull away successfully on a steep slope.

When the vehicle is stationary, the HHC detects whether the vehicle is on a slope through the longitudinal acceleration sensor. Subsequently, when the vehicle goes up the slope from the stationary state (through forward traveling or reversing), the HHC will automatically enter the working state. At start, when the driver releases the brake pedal, the HHC will maintain the previous brake pressure to ensure that the vehicle remains still and gradually reduce the brake pressure with the increase of driving torque to realize the effect that the vehicle does not slide in the opposite direction without application of parking brake, which greatly facilitates vehicle starting and pedal operation.

On the premise of meeting the following conditions, if the driver depresses the brake pedal with the vehicle stopped, the HHC is activated:

- ♦ The accelerator pedal is not depressed.
- ♦ The vehicle is stationary.
- ♦ The EPB is not applied.

#### Hydraulic brake assist (HBA)

HBA assists the driver in emergency braking. It determines whether full braking is required based on the speed at which the driver depresses the brake pedal. As long as the driver depresses the pedal to the floor all the time, the HBA will automatically increase the braking force to the threshold at which the ABS activates. If the driver releases the brake pedal, the HBA will reduce the braking force to the specified value.

#### Hydraulic boost failure compensation (HBC)

The hydraulic boost failure compensation (HBC) system controls the vehicle to achieve a large braking deceleration through active pressurization via the ESP in case of failure in the vacuum-assisted brake system.

#### Braking mode\*

The braking mode can be set in the center console display.

- Standard: moderate pedal effort during braking.
- Sport: greater moderate pedal effort and steady foot feel.

## WARNING

- Always adjust the vehicle speed according to weather, road and traffic conditions. Never risk driving merely by virtue of the additional safety functions provided by the brake assist control systems, so as to prevent accidents.
- Electronic stability program (ESP) cannot go beyond the physical limit of road adhesion; be careful during driving on a wet and slippery road or with a trailer coupled.
- The driver should adjust the driving style at any time according to the road and traffic conditions.



### **CAUTION**

- Improper operation or modifications (such as modifications to the brake system, wheels, tires and other components) of the vehicle will affect the function of ESP and ABS.
- Tires of specified specifications and size must be used. If the tire size is incorrect, or the size of the tires is inconsistent, the ABS may not function.

### **NOTE**

 In case of failure in ABS, the normal braking system can still work normally, but braking characteristics have changed.

# Acoustic vehicle alerting system of electric vehicle running at low speed

During driving at low speed, the acoustic vehicle alerting system sounds the warning chime to warn pedestrians and vehicles to improve driving safety.

The system sounds the warning chime when the vehicle runs forward at the speed of not more than 25 km/h or reverses.



### **AUTO HOLD**

AUTO HOLD can help you keep the vehicle stationary after the braking, without the need of setting the gear lever to "N" / "P" position or apply the parking brake. When you need to drive again, just depress the accelerator pedal.

### **Activation conditions**

When the following conditions are met, the AUTO HOLD function can be activated:

- The vehicle has been started.
- ♦ The driver has fastened the seat belt.
- ♦ The vehicle is stationary.

### Activating and deactivating the function

After the activation conditions of the function are met, click the AUTO HOLD button on the center console display to activate or deactivate the AUTO HOLD function. After the function is activated, the AUTO HOLD button turns green.

### **Use of AUTO HOLD**

With AUTO HOLD activated, after braking through depressing the brake pedal, the indicator lamp (P) in the instrument panel will come on, indicating that AUTO HOLD is working. At this time, if the brake pedal is released, the vehicle will remain stationary, and after the accelerator pedal is depressed, the vehicle will drive.

### **▲** WARNING

- When AUTO HOLD is in operation, opening the driver's door or unfastening the driver's seat belt will deactivate the function.
- When AUTO HOLD is in operation, operating the EPB manually will deactivate the function.

### **CAUTION**

 When driving into a mechanism such as a vehicle washing device that transports the vehicle with a conveyor belt, be sure to deactivate the AUTO HOLD



### **Light control**

### Activating auto headlamp

Switch on the vehicle power supply, click the AUTO headlamp button on the quick control interface of the center console display to automatically turn on the lamp.

If the auto headlamp function is activated, the position lamp and the low beam will be turned on or off automatically according to the ambient light.

### Turning on headlamp


The headlamp is an important illumination tool for nighttime driving. Please turn on the headlamp during nighttime driving.

The headlamp consists of a low beam and a high beam, which should be switched reasonably according to the actual road condition and the driving environment.

Switch on the vehicle power supply, click the low beam button on the quick control interface of the center console display to turn on the low beam.


If the auto headlamp function is activated, the low beam will be turned on or off automatically according to the ambient light.

### Headlamp leveling



According to the actual vehicle condition, the low beam height can be adjusted via the headlamp leveling roller.


### High/low beam switching



After the headlamp is on, push the light/ wiper control lever in the direction of arrow A to switch the headlamp to the high beam, and pull back the light/wiper control lever in the direction of arrow B to turn off the high beam

Repeatedly pull the light/wiper control lever in the direction of arrow B and reset it to switch between the high beam and the low beam in order to remind other traffic participants (such as when meeting, overtaking or crossing an intersection).

### Turn signal lamp



Turn signal: Move the light/wiper control lever to ① position to make the corresponding side turn signal lamp flash continuously.

Lane change signal: Move the light/wiper control lever to ② position slightly and release it. Then the light/wiper control lever will return to the original position automatically, and the corresponding side turn signal lamp will flash 3 times.



### Turning on fog lamp

After the headlamp is on, click the rear fog lamp button on the quick control interface of the center console display to turn on the rear fog lamp and the rear fog lamp indicator lamp :

### **Turning on position lamp**

If the auto headlamp function is activated, the position lamp and will be turned on or off automatically according to the ambient light.

Switch on the vehicle power supply, click the position lamp button on the quick control interface of the center console display to turn on the position lamp and the position lamp indicator lamp  $\mathfrak{D}\mathfrak{C}$ .

### **NOTE**

 When the vehicle is started and the headlamp is not on, only the rear position lamp is turned on.

### Daytime running lamp

The daytime running lamp is turned on automatically when the vehicle is started and the headlamp is not on, to enable other traffic participants to detect your vehicle easily.

### **▲** WARNING

- Please use the light reasonably according to the road condition and the driving environment.
- The high beam may cause dazzling to drivers of oncoming vehicles at close range, which may easily cause accidents. Therefore, please use the high beam reasonably.
- When the vehicle is passing a sharp turn, hill, arch bridge, crosswalk or intersection without traffic lights, the high beam and low beam should be turned on alternately for warning.


### **1** NOTE

- ♦ In some humid conditions (such as high air humidity, vehicle washing, etc.), the inside of the lamp may be covered with a layer of fog or even a small amount of water drops. This is caused by water mist that is generated due to that humid air enters the inside of the lamp through the vent hole, and the temperature of the lamp lens is relatively low, which is similar to the fogging of vehicle windows on rainy days. This is a normal physical phenomenon and will not affect the function and service life of the lamp.
- When the vehicle is in a dry environment or the lamps are turned on, the water vapor will gradually evaporate, and there may be residues only at the corners of the lamps, but the fogging phenomenon may appear repeatedly.
- If there are a lot of water drops or accumulated water in the lamps, please contact the GAC AION sales store for inspection and repair.
- If you forget to turn off the position lamp, it will automatically go out after the vehicle power supply is turned off for a while or the vehicle enters the anti-theft state, in order to save the battery power.
- If one turn signal lamp on the vehicle fails, other turn signal lamps on the corresponding side and the corresponding turn signal indicator lamp in the instrument panel will flash at a higher frequency.
- After a collision, all turn signal lamps and turn signal indicator lamps will flash at the same time.
- The windshield should be replaced together with the RLS.
- The automatic headlamp on/off function may not be activated in the haze environment, so please manually control the light in this case.



### Wiper control

### Operation of front wiper



Turn the wiper control knob up or down from the O position, so that the front wiper position icons are aligned with the wiper control knob position reference icons ① in turn, and the front wiper mode can be selected. The specific control is as follows:

- : the front wiper operates at a high speed.
- the front wiper operates at a low speed.
- : the front wiper operates intermittently.
- : the front wiper is turned off.
- -- : manual wiping. Set the wiper control lever to this position and hold it to achieve continuous operation of the front wiper. After being released, the wiper control lever returns to OFF position , and the front wiper stops.

### Front windshield washing




Press the front wiper washer button to have the front washer nozzle spray washer fluid. After the wiper control lever is released, the front washer nozzle stops spraying the washer fluid, the wiper operates several times, and then operates once after a period of time and stops.




### Replacing wiper blades

 Activate the wiper maintenance mode via the center console display. Then the front wiper blade will move to the highest position and then stop.



Pull up the wiper arm from the front windshield



- Press the wiper blade lock button

   , and remove the wiper blade as arrowed.
- 4. Install the wiper blade in reverse step.
- Gently put the wiper arm back into the windshield.
- Deactivate the wiper maintenance mode via the center console display. Then the front wiper blade will return to the original position automatically.

### WARNING

Check the wiper blades regularly. Check the rubber for cracks or local hardening. If these phenomena occur, the wiper blade should be replaced, otherwise, a stripe will be left after wiping or the windshield will not be wiped cleanly, affecting the driver's vision.

### **CAUTION**

- Do not open the hood when the front wiper arm is pulled up; otherwise the hood and the front wiper arm may be damaged.
- After the wiper blade is replaced, hold the wiper arm by hand and place it on the windshield slowly, so as to avoid damage to the windshield due to quick placement.
- After the wiper blade is removed, the wiper arm should be kept upright to avoid damage to the windshield due to fall of wiper arm.

### **NOTE**

- In cold days in winter or in hot days in summer, the wiper maintenance mode may be activated, and the front wiper should be lifted up from the front windshield.
- The automatic wiping function may be activated or deactivated via the center console display. If the function will be activated when the wiper control lever is set to AUTO position.



## Forward collision warning system\*

The forward collision warning system, abbreviated to FCW, timely reminds the driver to take measures to ensure driving safety in case of a potential collision risk by detecting the relative distance and speed with the vehicle ahead in the same path through the MMW radar sensor installed on the front of the vehicle and the LDW ECU in combination with the driver's other operations (such as depressing the brake pedal or accelerator pedal).

### Activation and deactivation

When the vehicle is started, the FCW will be activated automatically.

The FCW may also be activated or deactivated manually.

### Setting forward collision warning distance

After the FCW is on, "Far", "Medium" and "Near" settings may be achieved for the forward collision warning distance through the center console display.

### Alert mode

After the FCW is on, if there is a risk of front collision with the vehicle speed greater than 30 km/h, the instrument cluster will display a prompt image, accompanied by audible alarm.

- Distance warning
  - When the distance warning of FCW is triggered, the FCW system status indicator lamp in the instrument cluster flashes, accompanied by a prompt image.
- Proximity warning
  - When the early warning of the FCW is triggered, the forward collision warning system status indicator lamp
     in the instrument panel will flash, accompanied by the audible alarm and visual prompt.
- Brake jerk warning
  - When detecting a high risk of collision with the target lead vehicle, the FCW will trigger the brake jerk warning to remind the driver to carry out emergency braking immediately.



### **▲** WARNING

- The FCW is subject to the limitations of laws of physics, and thus shall never be used for risky driving.
- The FCW is not always effective under all circumstances. The driver must always be ready to control the vehicle. When the FCW gives alert, the driver must apply the brake to reduce the vehicle speed or avoid obstacles according to traffic conditions.
- ◆ The FCW is only a warning system to remind the driver to avoid collisions. It cannot replace the driver in providing the corresponding active brake assistance when an early warning is issued, so the driver must always keep control of the vehicle and take full responsibility for the speed of the vehicles

### **NOTE**

- The FCW alerts can be stopped by depressing the accelerator pedal or turning the steering wheel.
- In a complex driving environment (such as traveling on a circuitous road), the FCW may give a false alarm.

## Autonomous emergency braking (AEB)\*

The autonomous emergency braking, abbreviated to AEB, applies brake in case of a collision risk by detecting the relative distance and speed with the vehicle ahead in the same path through the MMW radar sensor installed on the front of the vehicle and the LDW ECU in combination with the driver's other operations (such as depressing the brake pedal or accelerator pedal). When detecting a vehicle or obstacle ahead and a risk of collision, the AEB will give a brake jerk warning and apply the brake. If you do not take braking measures, the AEB will increase the braking force to avoid or mitigate the collision. After giving a brake jerk warning, the AEB may not avoid an accident if you do not take braking measures and run the vehicle at a high speed.

### Activation and deactivation

When the vehicle is started, the AEB will be activated automatically.

The AEB may also be activated or deactivated manually through the center console display.

The AEB must be switched off under the following conditions:

- ♦ The vehicle is towed.
- The vehicle is on a chassis dynamometer. (such as during annual inspection)
- ♦ There is a RPA sensor fault indication in the instrument panel.



### **System limitations**

Under certain conditions including but not limited to the following, the AEB may not work:

- The vehicle passes an extremely tight turn.
- The accelerator pedal is depressed quickly.
- ♦ The transmission is not shifted to D.
- ♦ The driver's seat belt is not fastened.
- ♦ The radar sensors are dirty or covered.
- ♦ A narrow vehicle (such as a motorcycle) is traveling ahead.
- The vehicle meets a crossing approaching vehicle at a crossroad, etc.
- ♦ There is a stationary obstacle (such as a broken-down vehicle) in front.
- ♦ There is an oncoming vehicle.
- There is an oncoming or road-crossing animal.
- The detection performance is degraded due to interference by environmental factors (such as electromagnetic interference).

The AEB may not always be able to clearly identify objects and complex traffic conditions. In these cases, the AEB may:

- Issue a warning or apply braking when unnecessary.

### WARNING

- ◆ The AEB can improve the driving safety, but it is still subject to the limitations of laws of kinematics, and thus shall never be used for risky driving. The driver must always be ready to apply the brake to reduce the vehicle speed or avoid obstacles.
- The braking effect that can be realized by the AEB to reduce injuries due to collision is limited and it cannot work autonomously to prevent vehicle accidents or personal injuries. Therefore, when the AEB is working, the driver is still required to apply braking when necessary.
- When the AEB is activated, the driver shall keep controlling the vehicle during driving, and shall take full responsibility for the vehicle speed and the distance to other vehicles.
- The AEB is only effective to vehicles/ pedestrians detected by the radar sensor to mitigate injuries due to collision, and thus, it may respond after a certain delay. The driver shall apply the brake if necessary instead of waiting for the AEB to act.
- The driver shall not completely rely on the AEB. As the AEB is only a driver assistance system, the driver shall be fully responsible for keeping a proper distance from the vehicle ahead, controlling the speed and braking in time. The driver must always be ready for braking or steering.
- During AEB's intervention in braking, the AEB can be stopped by depressing the accelerator pedal or turning the steering wheel.



### **NOTE**

- When the AEB is activated, the vehicle will be braked, and the foot may feel hard or vibration from the brake pedal, which is normal.
- In a complex driving environment (such as traveling on a circuitous road), AEB may intervene in braking.
- When the AEB is negatively affected by the environmental factors (for example, electromagnetic interference or the target itself), the detection function will be interfered and the AEB performance will be degraded.

### **Cruise control**

The cruise control allows the vehicle to run at the set cruising speed without depressing the accelerator pedal.

### **Description of cruise control buttons**



- Cruise control resumption/acceleration button
- 2 Cruise control deceleration button

### **Activating CCS**

- Set the gearshift lever to "D" position, control and keep the vehicle speed higher than 40 km/h.
- Set the gearshift lever to "D" position twice. Then the green cruise control indicator lamp in the instrument panel will come on. After the accelerator pedal is released, the vehicle will cruise at the current speed.

### Increasing cruising speed

Press + button on the steering wheel to increase the cruising speed.

Press and hold + button on the steering wheel to increase the cruising speed continuously.



### Decreasing the cruising speed

Press button — on the steering wheel to reduce the cruising speed.

Press and hold button — on the steering wheel to reduce the cruising speed continuously.

### Canceling cruise control

When the vehicle is in cruise control mode (green cruise control indicator lamp is on), depress the brake pedal or set the gearshift lever to "R" position once to exit the cruise control

### **▲** WARNING

- When driving on high-traffic roads, slopes, multi-curve roads or wet and slippery roads, do not use the cruise control for fear of accidents.
- Set speed and distance from a lead vehicle must be adapted to the current traffic conditions. The cruise control system is only a driver assistance system and should be used provided that safety has been guaranteed.
- After exiting the cruise control mode, deactivate the cruise control in time.

### **NOTE**

- When the cruising speed is reduced to 40 km/h, the cruising speed can no longer be reduced via the button on the steering wheel.
- When the accelerator pedal is depressed for overtaking as needed, the vehicle will temporarily exit the cruise control mode and the power output will be controlled by the accelerator pedal. After the accelerator pedal is released, the vehicle will restore the cruise control. During overtaking, please pay attention to the driving environment and keep a safety distance.
- ♦ When the cruise control is deactivated, if the vehicle speed is greater than 40 km/h, the cruise control can be restored by pressing the button +○ on the steering wheel, to reach the last set cruising speed. The cruise control cannot be restored if the vehicle speed is lower than 40 km/h.



### Adaptive cruise control\*

The adaptive cruise control (ACC) applies the millimeter wave radar installed on the front of the vehicle and the intelligent front camera on the front windshield to detect the relative distance and speed of the ego vehicle with the lead vehicle on the same path, to control the ego vehicle to follow the lead vehicle automatically.

- ♦ When no lead vehicle is present, the ACC will control the ego vehicle to cruise at the set target speed.
- ♦ When a lead vehicle is present, the system will automatically control the ego vehicle to cruise according to the ego vehicle speed, the lead vehicle speed and the set safety distance.

### **Description of ACC buttons**



- Cruise control resumption/acceleration button
- 2 ACC distance control button
- 3 Cruise control deceleration button

### Instrument cluster display interface of ACC



- ACC indicator lamp
  - With the ACC in ready state, when there is no target vehicle ahead, the indicator lamp of comes on; when a target vehicle is detected, the indicator lamp  $\uparrow \gamma \gamma$  comes on, accompanied by an alert.
  - With the ACC activated, when there is no target vehicle ahead, the indicator lamp of comes on; when a target vehicle is detected, the indicator lamp ? comes on.
- ② Set cruising speed
- Set following distance for cruise control

### **Activating ACC**

Set the gearshift lever to "D" position once. Then the corresponding indicator lamp in the instrument cluster turns blue, and the vehicle enters the ACC mode. At this time, if the vehicle speed is higher than 15km/h, the current speed will be set as the cruising speed; if the vehicle speed is lower than 15 km/h, the cruising speed will be set at 15km/h.



### Increasing cruising speed

Press putton on the steering wheel to increase the cruising speed.

Press and hold  $+^{\circ}$  button on the steering wheel to increase the cruising speed continuously.

### Decreasing the cruising speed

Press button — on the steering wheel to reduce the cruising speed.

Press and hold button — on the steering wheel to reduce the cruising speed continuously.

### Adjusting the following distance for ACC

Press 
button on the steering wheel to adjust the following distance, which is displayed in the instrument panel. The distance is farthest when set to the 4th gear.

### Restoring ACC after following stop

In ACC mode, the ego vehicle will stop when the vehicle ahead stops. Depending on the stop time of the lead vehicle, when the lead vehicle drives off, the ACC of the ego vehicle will be in the following 2 states:

- ♦ In case of short-time stop of the lead vehicle, the blue indicator lamp will come on. In that case, if the lead vehicle drives off, the ACC of ego vehicle will be restored automatically.
- ♦ In case of long-time stop of the lead vehicle, the indicator lamp ★ will come on. In that case, if the lead vehicle drives off, the ACC of ego vehicle will be restored by depressing the accelerator pedal or pressing 

   button on the steering wheel.

### Canceling/resuming ACC


When the vehicle is in ACC mode, the

ACC will be canceled if the brake pedal is depressed or the gearshift lever is set to "R" position once. At that time, pressing + button on the steering wheel can restore the ACC.

### **System limitations**


ACC is subject to limitation of physical laws, and thus in some driving environments, the driver may find that the vehicle is not controlled as expected after the reaction of ACC, therefore, the driver must always be ready to control the vehicle. The following conditions will affect functions of the RPA sensor, so the driver must be particularly alert under these conditions:

Decelerating to stop. If a vehicle ahead is stopped by emergency braking, ACC will also decelerate your vehicle or send a hands-on operation request. The driver should actively intervene by braking according to the hands-on operation request to stop the vehicle completely.




Driving through a curve. During driving through a curve, the RPA sensor may fail to capture the vehicle ahead, or may respond to vehicles in adjacent lanes. In this case, the ACC may brake the vehicle, reduce the vehicle speed, or make no response to the vehicle ahead. At that time, step on the brake pedal or manually cancel ACC.







Driving out of a curve. During driving out of a long curve, as ACC will calculate the lane in advance, the radar may respond to the vehicles in adjacent lanes and apply the brake of your vehicle. This braking process can be interrupted by depressing the accelerator pedal.



♦ Narrow vehicles and Z-shaped traffic in front. The narrow vehicles and Z-shaped traffic in front can be detected by the radar sensor only when they enter the detection range of the radar sensor. That is to say, the system cannot identify vehicles out of the detection range of the sensor. ACC may be unable to identify narrow vehicles such as motorcycles, and has a risk of failing to accurately identify the distance from modified vehicles and vehicles involving non-standard transportation in front. so it is not recommended to take such vehicles as the target vehicle ahead.



♦ Lane change of other vehicles. When a vehicle in the adjacent lane goes into the ego lane, if it does not enter the detection range, it could not be detected by the RPA sensor, thus resulting in a response lag of ACC.



♦ If the target vehicle in front is driven out suddenly and a stationary vehicle appears at close range, the radar sensor and brake actuator will incur a response lag, causing delayed braking response.



- Influencing factors that may deteriorate the sensor function:
  - Driving under harsh operating conditions such as rainstorm, mist, ice, snow or sludge.
  - Driving in cold areas. (frosting or fogging of front windshield due to temperature difference or frost will block the camera)

Under the above condition, after the RPA sensor is affected, the warning message "ACC is currently out of service", "Please check the forward collision warning system" or "Please check the autonomous emergency brake" will appear in the instrument panel. At this time, the ACC, FCW and AEB do not work.

- ◇ Brake overheating. If the brake is overheated due to emergency braking or during traveling down a steep slope, the ACC will be deactivated automatically and temporarily, and meanwhile the following text message will appear in the instrument panel: "ACC is currently out of service". In that case, the ACC can no longer be activated, and it can be activated again only when the brake temperature drops to a reasonable value.
- The ACC should not be used in cities with traffic jams and poor visibility (night/backlighting/rain/snow/dense fog, etc.). The ACC may not take braking measures in face of people, animals, narrow vehicles such as bicycles, motorcycles or electromobiles, drop frame trailers, approaching or stationary vehicles, and low-speed or stationary trucks/small pickup trucks, so the driver should be particularly alert and always be ready to take over the vehicle.

### WARNING

- The ACC is not a safety system, obstacle detector, collision alarm or anti-collision system, but a comfort system, so the driver must always keep control of the vehicle and take full responsibility for the vehicle.
- The ACC must be used cautiously according to the visibility, weather conditions, road and traffic conditions at the time. The driver must always keep control of the vehicle and take full responsibility for the speed of the vehicle and the distance from other vehicles.
- The ACC cannot substitute for driver's attention and judgment. The driver should always be responsible for ensuring that the vehicle travels safely at an appropriate speed and maintains an appropriate distance from other vehicles.
- The ACC cannot address all driving scenarios and traffic, weather and road conditions.
- The ACC is only a driver assist system, and cannot replace your attention and judgment. It is your responsibility to maintain a safe distance and speed, and you must be ready to intervene if the ACC fails to maintain a proper speed or distance from the vehicle ahead.



### ▲ WARNING (Cont'd)

- The hands-on reminder of ACC only warns the driver of vehicles detected by its RPA sensor and camera, so ACC may not send an alarm, or may send an alarm after a certain delay. Therefore, the driver shall apply the brake in time as required instead of waiting for the alarm.
- Do not use ACC under conditions such as urban driving, traffic jams, multi-curve roads and poor road conditions (e.g. icing, fog, gravel, heavy rain, and phenomena prone to water skiing).
- ◆ The ACC is not a collision avoidance system. If your vehicle is getting closer and closer to the vehicle ahead at a speed higher than that of the vehicle ahead and the braking effect of ACC is unable to stop the vehicle safely before a collision with the vehicle ahead, the driver must depress the brake pedal to reduce the vehicle speed.
- Do not activate ACC during driving in roadless areas or on earth roads.
   ACC can only be activated on flat roads paved with pitch, cement, etc.
- The ACC will make no or limited response to the followings:
  - Large speed difference with the vehicle ahead.
  - Driving in different lanes, lane changes or driving on curves with small radius.
  - Pedestrians, animals, bicycles, stationary vehicles, unexpected obstacles, etc.
  - Approaching stationary obstacles such as broken-down vehicles.
  - A vehicle in the same lane approaching the ego vehicle.

### **▲ WARNING (Cont'd)**

- Complex traffic conditions.
- Oncoming traffic or cross traffic.
- Low trailers or trucks, and vehicles with irregular or non-standard characteristics.
- Metal objects such as tracks, metal plates, roadside obstacles such as concrete walls, dense grass and fences, as well as high voltage bridges, toll booths and tunnels can interfere with the normal operation of the RPA sensor and cause ACC system not to be triggered or to be mistakenly triggered. The driver needs to be alert and ready to take over the vehicle at all times.
- A vehicle in an adjacent lane rapidly moving in the lateral direction or traveling in close proximity to the ego vehicle may cause an incorrect determination of a target by ACC system, resulting in the vehicle braking and requesting the driver to take over it.
- Be sure to notice traffic conditions and respond accordingly. Do not wait for the system to identify the target or apply the brake, but apply the brake as needed.
- The ACC may not respond to people, animals and vehicles crossing or approaching the vehicle in the same lane.
- When driving through crossroads, speed bumps, steep roads and zebra crossings, or at changing lanes, highway access, ramps or construction sections, it is required to exit ACC for manual driving, lest the vehicle should be automatically accelerated to the set speed, causing traffic accidents.



### ⚠ WARNING (Cont'd)

- The ACC can automatically drive the vehicle out after a short stop or confirmation from the driver (control of buttons or accelerator pedal). During this period, the driver must ensure that there are no obstacles or other traffic participants such as pedestrians/bicycles ahead of the vehicle.
- The ACC can not identify a vehicle ahead that is already stationary or travels very slow (close to stopping), but it can stop with the moving vehicle that has been identified and selected as a target by the ACC. During following stop, the driver still needs to be ready to take over the vehicles at all times to guard against accidents.
- The ACC can only achieve limited braking force, not emergency braking.
- The vehicle is ready for driving, and the gearshift lever is in "D" position. After the ACC is activated, the stationary vehicle will enter the driving state, so it is necessary to operate carefully.
- After the vehicle enters ACC control state from the stationary state, the vehicle speed may increase suddenly. In this case, please ensure the safety around the vehicle to avoid accidents.

### **CAUTION**

- If the ACC fault indicator comes on, it indicates that ACC is faulty. It is recommended to contact the GAC AION sales store for inspection and repair.
- Do not bump the RPA sensor. If the sensor is misaligned due to bumps, it will deteriorate the system performance and even cause the system shutdown even through maintenance and correction are made.
- If the surface of the RPA sensor or camera is dirty or covered by rain, ice, snow, sludge, etc., ACC may not function, and the instrument cluster will display the prompt message reading "Please check ACC". After the dirt is cleaned off the sensor surface, ACC will return to normal.
- Do not spray the front bumper with vehicle paint without permission, otherwise the performance of the frontal radar may be degraded.
- If the ACC fails to function properly, stop using it, and contact the GAC AION sales store for inspection in time.

### **NOTE**

- ◆ The set cruising speed will be deleted after the vehicle is powered off.
- Prevent placing your foot on the accelerator pedal when not required; otherwise, the ACC cannot function for braking, as the depressing of accelerator pedal will cause excessive control of vehicle speed and distance.



### NOTE (Cont'd):

- When the ACC is activated, the ACC status displayed on the instrument cluster may be overwritten by other functions (for example, during a call).
- When the ACC brakes the vehicle automatically after activation, there will be a sound different from manual braking sound or the brake pedal will be depressed automatically, which is normal. Such sound and pedal action are caused by the operation of the brake system, so there is no need to worry.
- The accelerator pedal can be depressed when required to increase the vehicle speed. After the accelerator pedal is released, the ACC will readjust the vehicle speed to the previously set cruising speed.
- If the vehicle enters a tunnel, the radar and camera may be temporarily inactive, and the ACC may be turned off temporarily.
- In addition to depressing the brake pedal and setting the gearshift lever to position once to exit ACC, the following operations may also exit the ACC:
  - Operating the EPB button.
  - Opening the driver's door.
  - Unfastening the driver's seat belt.
  - Setting the gearshift lever to a position other than D.

### Integrated cruise assist \*

The integrated cruise assist, referred to as ICA, detects the relative distance and speed with the vehicle ahead in the same path and the lane markings according to the signals from the MMW radar installed on the front bumper and the IFC installed on the front windshield. The ICA can automatically adjust the distance from the vehicle ahead during cruise control and keep the vehicle traveling in the middle of the lane.

## Instrument cluster display interface of ICA



- Longitudinal control
  - When the vehicle is ready for cruise control, if there is no vehicle ahead, the indicator lamp comes on; if there is a vehicle ahead, the indicator lamp comes on.
  - When the vehicle is in cruise control, if there is no vehicle ahead, the indicator lamp comes on; if there is a vehicle ahead, the indicator lamp comes on.



- Lateral control and driver's hands off steering wheel
  - When ICA is ready, the indicator lamp comes on; when ICA lateral control is activated, the blue indicator lamp comes on; when it is detected that the driver's hands are off the steering wheel, the hands off warning lamp / lashes.
- 3 Set cruising speed
- 4 Set following distance for cruise control

### **Activating ICA**

Set the gearshift lever to "D" position twice quickly to activate the ICA.

### Canceling ICA

When the vehicle is in ACC mode, the ACC will be deactivated if the brake pedal is depressed or the gearshift lever is set to "R" position once.

### Lateral control

When ICA is activated, the lateral control function will be automatically activated if an effective lane marking is detected on both sides, so that the vehicle can keep traveling in the center of the lane.

The lateral control will be suppressed under the following conditions:

- High curvature or missing of lane marking.
- ♦ Violent driving.
- Hazard warning lamp on.
- Steering wheel turned by the driver.
- ♦ Hands-on reminder from the system.
- ACC deactivated.

### Longitudinal control

Refer to Adaptive Cruise Control (ACC) for ICA longitudinal control.

### Hands-on reminder

In the following cases, the ICA will issue a hands-on reminder accompanied by a sound alert

- When the ICA detects that the driver's hands are off the steering wheel for a long time.
- When the ICA requires the driver to intervene in braking. (The ICA can only use limited brake capacity of service brake system)

Please take over the vehicle immediately after the vehicle sends out the hands-on reminder



### **System limitations**

The ICA has limitations and may incorrectly detect lane markings or fail to detect lane markings, or may incorrectly detect target vehicles or fail to detect target vehicles ahead. Even if enabled and activated, TJA/ICA may be affected, malfunction or not function under the following conditions:

- Poor line of sight, such as snow, rain, fog or water spots.
- Dirty or foggy windshield, or obstruction in front of the windshield camera.
- Overtemperature around the camera due to direct sun exposure.
- Glare due to direct sunlight, light from oncoming traffic, reflected light from road water-logging, etc.
- Sudden changes in outdoor brightness, such as entering/exiting tunnels.
- Headlamp not turned on at night or when the lighting is dim in tunnels.
- No lane marking, or difficulty in distinguishing the lane marking color from the road color.
- Unobvious, too thin, worn, blurred or dirt/snow-covered lane markings.
- ♦ Too wide or narrow lanes.
- Increase or decrease in lanes, or complicated routing of lane markings.
- More than two lane markings on the left and right sides of the vehicle.
- Marks or objects similar to lane markings on roads.
- Isolation strips or other objects casting shadows on lane markings.
- ♦ Short-term change of lane marking, such as ramp or highway exit.
- Oriving on steep slopes or bumpy roads.
- Close distance from the lead vehicle or lane markings blocked by the lead vehicle.

Severe shaking of the vehicle.

The lateral control assist performance of ICA may be affected under the following conditions:

- The vehicle is overloaded.
- ♦ Abnormal tire pressure.
- ♦ Uneven road.
- Strong crosswinds.
- Vehicle control-related parts are modified by the driver.
- Vehicle control-related parts are replaced with non-genuine parts.
- Vehicle control-related parts are improperly assembled.



### WARNING

- ICA only provides a driving assistance function and cannot address all road, traffic and weather conditions. The driver always takes full responsibility for driving, and shall always check the road conditions and actively control the vehicle.
- The driver must hold the steering wheel all the time to actively control the vehicle. When the ICA system does not provide proper steering assist or appropriate headway, the driver shall intervene timely.
- Improper use of the ICA system or negligence may lead to accidents, so the driver should always control the vehicle, and maintain an appropriate speed and headway to keep the vehicle traveling correctly in the lane, even if using the ICA system.
- The ICA system is not a collision avoidance system. When the system does not take proper control, the driver must intervene.
- Under conditions such as urban traffic, intersections, water-logged or snowy roads, adverse weather, mountain roads, rough roads and highway access, it is recommended not to use ICA.
- The ICA system is not always able to identify the lane markings, and in some cases may mistakenly identify or even not identify a lane marking, so the ICA system may not generate lateral assist when needed, or may generate unnecessary lateral assist by mistake.

### ▲ WARNING (Cont'd)

- ◆ The ICA system can only use limited capability of steering system, so it cannot cope with all driving conditions. The driver must keep his hands on the steering wheel all the time and drive with care. The driver must hold the steering wheel or reduce the vehicle speed appropriately on highspeed curves.
- The ICA system cannot perform braking in face of pedestrians, animals, foreign objects, lowbed trailers or oncoming traffic.
- ◆ The ICA system cannot address all traffic conditions. For example, the lateral assist may suddenly exit under conditions such as high curvature of lane marking before a sharp curve, and roads without lane markings. The driver must hold the steering wheel all the time to actively control the vehicle.
- The driver shall immediately hold the steering wheel immediately after receiving the hands-on reminder. Don't panic or turn the steering wheel fiercely.

### **CAUTION**

 If the yellow indicator lamp comes on, it indicates that ICA is faulty. It is recommended to contact the GAC AION sales store for inspection.



### **NOTE**

- The condition that the driver's hands are lightly holding on the steering wheel may be misinterpreted by the ICA system as the steering wheel outof-hand
- If the ICA system is inhibited for some reason, it will automatically recover when the working conditions are met.
- When judging that the ICA system does not control the vehicle properly, the driver should hold the steering wheel firmly and control it properly, and the ICA function will be interrupted by the driver's operation.
- When the ICA system controls the steering wheel for assistance, the driver can still turn the steering wheel to control the vehicle. When the driver feels an implausible torque applied to the steering wheel by the system, the driver may take over control of the vehicle at any time to drive it at will.
- In addition to pressing the brake pedal and moving the lever to R position once, the following actions may also make the ICA exit:
  - Depressing the accelerator pedal quickly.
  - Unfastening the driver's seat belt.
  - Pressing the hazard warning lamp switch.

## Lane departure assist system \*

The lane departure assist system detects the vehicle ahead and lane marking via the MMW radar installed in the front of the vehicle and the IFC installed on the front windshield, and gives an alarm or intervention when the vehicle has a lane departure sign.

### Activation and deactivation

The lane departure assist system can be turned on or off via the center console display.

### Selecting lane departure assist mode

After the lane departure assist system is turned on, the lane departure assist mode can be selected as "Steering", "Warning" or "Steering and warning" in the center console display.

- When "Steering" is selected, the system only intervenes in turning of steering wheel for corrective steering adjustment.
- When "Warning" is selected, the system only issues a warning.
- When "Steering and Warning" is selected, the system will not only issue a warning but also intervene in turning of the steering wheel for corrective steering adjustment.

## Lane departure assist/corrective steering adjustment

After the lane departure assist system is turned on, the indicator lamp on the instrument cluster will come on, and the lane departure assist system will enter the ready state. When the following conditions are met, the lane departure assist system will be activated and the green indicator lamp will come on.

- ♦ The vehicle speed is higher than 60km/h.
- The system detects valid lane marking on at least one side.



When the lane departure assist system is activated, if the vehicle deviates from the lane, the system will send out an alert or make corrective steering adjustment according to the set lane departure assist mode.

When the lane departure assist system is activated, if the vehicle deviates from the lane under the following conditions, the system will not give an alarm or make corrective steering adjustment:

- ♦ The accelerator pedal is quickly depressed for acceleration.
- The brake pedal is slammed for deceleration.
- Corresponding turn signal lamp is turned on.
- ♦ Hazard warning lamp on.
- ♦ The steering wheel is turned quickly;
- The time interval from the last alarm is short:
- The car is running on or across the lane marking continuously;
- The system alerts the driver to take over the steering wheel.

### Hands-on reminder

When detecting that the steering wheel is out of the driver's hands for a long time, the lane departure assist system will issue a hands-on reminder. The instrument cluster will display the prompt message reading "Please take over the steering wheel immediately" and the buzzer will beep. (The condition that the driver's hands are lightly holding the steering wheel may be misinterpreted by the ICA system as the steering wheel out-of-hand.)

When the system sends out a hands-on reminder, please take over the vehicle to ensure driving safety.

### Other prompts

When the instrument cluster displays the prompt message reading "Lane

departure assist system is temporarily unavailable", it indicates that the IFC on the front windshield fails. Generally, this is because the front windshield is dirty or the IFC is directly exposed to sunlight. The lane departure assist system will not be damaged due to this and needs not to be inspected.

When the instrument cluster displays the prompt message reading "Please check the lane departure assist system" and the red status indicator lamp of lane departure assist system comes on, it indicates that there is a fault in the system. It is recommended to contact the GAC AION sales store for inspection.

### **System limitations**

The limitations include but are not limited to, the following situations where the system may become affected or inoperative:

- Poor line of sight, such as snow, rain, fog or water spots.
- Dirty or foggy front windshield, or obstruction in front of the IFC.
- Overtemperature around the IFC due to direct sunlight.
- Glare due to direct sunlight, light from oncoming traffic, reflected light from road water-logging, etc.
- Sudden changes in outdoor brightness, such as entering/exiting tunnels.
- ♦ Headlamp not turned on at night or when the lighting is dim in tunnels.
- No lane marking, or difficulty in distinguishing the lane marking color from the road color.
- Unobvious, too thin, worn, blurred or dirt/snow-covered lane markings.
- Too wide or narrow lanes.
- Increase or decrease in lane markings, or complicated routing of lane markings.
- ♦ More than two lane markings on the left



- and right sides of the vehicle.
- Marks or objects similar to lane markings on roads.
- ♦ Isolation strips or other objects casting shadows on lane markings.
- ♦ Short-term change of lane marking, such as ramp or highway exit.
- ♦ Driving on steep slopes or bumpy roads.
- Close distance from the lead vehicle or lane markings blocked by the lead vehicle
- ♦ Severe shaking of the vehicle.

Under the following conditions, the performance of the system may be affected while it intervening in turning of steering wheel for corrective steering adjustment:

- ♦ The vehicle is overloaded.
- Abnormal tire pressure.
- ♦ Uneven road.
- Strong crosswinds.
- Vehicle control-related parts are modified by the driver.
- Vehicle control-related parts are replaced with non-genuine parts.
- Vehicle control-related parts are improperly assembled.

### WARNING

- ◆ The lane departure assist system is just a driver assistance system and cannot actively control the vehicle to change lanes or keep it in the lane. The driver must always check the road conditions, hold the steering wheel and actively control the vehicle.
- Improper use of the lane departure assist system or negligence may cause an accident. Do not rely on the lane departure assist system completely or drive the vehicle at risk with the aid of the system.
- ◆ The lane departure assist system is not always able to identify a lane marking and a lane edge. The system may mistakenly identify or even don't identify a lane marking or a lane edge due to bad weather, poor night lighting, water or snow on road, damaged or blurry lane markings, or shade on roads. Therefore, the driver should concentrate on observing road and traffic conditions and drive carefully.
- Protect the IFC against strong impact, moisture or heat; and never remove and refit any part without authorization. Do not place reflective objects on the instrument panel, which are not only easy to dazzle the driver but also may reflect the light to the detection range of the IFC, affecting the normal operation of the system.



### WARNING (Cont'd)

- The system can only adjust limited steering angle, so it can't promise that the car will be driven back into the lane under any circumstances.
- The sound inside or the noise outside may prevent you from hearing the warning beep, so you may not notice the warning issued from the lane departure assist system under any circumstances.
- When detecting that the steering wheel is out of the driver's hands for a long time or the vehicle unintentionally deviates from the lane, the lane departure assist system will give a warning or intervene in turning of steering wheel for corrective steering adjustment. Do not panic, turn the steering wheel fiercely or shake the steering wheel unnecessarily.
- When the lane departure assist system intervenes in turning of the steering wheel for corrective steering adjustment, the driver can still turn the steering wheel to control the vehicle. When the driver feels an implausible torque applied to the steering wheel by the system, the driver may take over control of the vehicle at any time to drive it at will.

### **CAUTION**

- Do not color or coat the front windshield with any material not meeting the corresponding specifications. Any additional objects that negatively affecting the sight of the IFC may lead to improper operation of the system.
- Lane departure assist system with curb recognition uses signals from MMW RPA sensor. Avoid impact or modification to the bumper or vehicle body; otherwise the lane departure assist system may operate abnormally.

### **MOTE**

 When the system only detects a valid lane marking on one side, the function can be activated, but warning or corrective steering adjustment will be carried out only on that side.



## Lane keeping assist (LKA) system \*

The LKA system detects the lane markings in real time through the IFC on the front windshield, and when the driver is distracted and deviates from the lane, it corrects the traveling direction of the vehicle by controlling the EPS to assist the driver to keep the vehicle in the lane.

### **Activation and deactivation**

The LKA system can be turned on or off via the center console display.

### Alert mode

When the vehicle speed exceeds 60km/h, if the driver is distracted and deviates from the lane, the system will actively control the steering and sends out a reminder.

### **System limitations**

Due to unavoidable environmental factors and conditions, the system may also give an alarm when the alarm conditions are not met. Conditions in which a false alarm may be issued:

- Poor line of sight caused by snow, rain, fog, water spots, etc.
- Dirty or foggy windshield, or obstruction in front of the IFC;
- Overtemperature around the camera due to direct sun exposure;
- Glare due to direct sunlight, light from oncoming traffic, reflected light from road water-logging, etc.
- Sudden changes in outdoor brightness, such as entering/exiting tunnels;
- Headlamp not turned on at night or when the light is low in tunnels;
- No lane marking, or difficulty in distinguishing the lane marking color from the road color;
- Unobvious, too thin, worn, blurred or dirt/snow-covered lane markings;

- ♦ Too wide or narrow lanes;
- Increase or decrease in lanes, or complicated routing of lane markings;
- More than two lane markings on the left and right sides of the vehicle;
- Marks or objects similar to lane markings on roads;
- Isolation strips or other objects casting shadows on lane markings;
- Short-term change of lane marking, such as ramp or highway exit;
- Driving on steep slopes or bumpy roads;
- Close distance from the lead vehicle or lane markings blocked by the lead vehicle;
- Severe shaking of the vehicle;
- Passing by road guardrails, highway concrete walls, trees, shrubs, etc.;
- The vehicle passes over speed bumps or potholes;

Under the following conditions, the performance of the system may be affected while it intervening in turning of steering wheel for corrective steering adjustment:

- ♦ The vehicle is overloaded.
- ♦ Abnormal tire pressure.
- ♦ Uneven road.
- Strong crosswinds.
- Vehicle control-related parts are modified by the driver.
- Vehicle control-related parts are replaced with non-genuine parts.
- Vehicle control-related parts are improperly assembled.



### ▲ WARNING (Cont'd)

- The LKA system is only a driver assistance system, and cannot replace the driver's monitoring on the traffic conditions, and the driver should always be alert to the surrounding environment.
- The driver shall always hold the steering wheel to actively control the vehicle.
- When the road environment cannot meet the operating conditions of the lane departure assist system, it may not work properly.

### **NOTE**

When the system intervenes in turning of the steering wheel for assistance, the driver can still turn the steering wheel to control the vehicle. When the driver feels an implausible torque applied to the steering wheel by the system, the driver may take over control of the vehicle at any time to drive it at will.



### **Driving in fog**

In case of driving in fog, please read and observe the following.

### DANGER

- Before driving, check the lighting system, turn on the fog lamps, position lamps and low beams to improve visibility to avoid traffic accidents.
- In heavy fog, try to avoid driving a vehicle to avoid traffic accidents.
- When driving in fog, do not sharply step on or quickly release the accelerator pedal, and do not brake the vehicle or turn the steering wheel suddenly. If it is necessary to reduce the vehicle speed. first slowly release the accelerator pedal, and then lightly step on the brake pedal several times to control the vehicle speed and prevent rear-end collisions.
- Do not turn on high beams when driving in fog.

### WARNING

- When driving in fog, slow down and sound the horn if necessary to alert other pedestrians and vehicles. If any horns of other vehicles are heard, it is also necessary to respond by sounding the horn immediately, indicating the location of the ego vehicle.
- When driving in fog, try to drive the vehicle in the middle of the road to avoid colliding with vehicles temporarily parked on the side of the road waiting for the fog to disperse.

### **M** NOTE

 When driving in fog, please control the vehicle speed and obey the relevant laws and regulations.

### **Driving in rain**

In case of driving in rain, please read and observe the following.

### **DANGER**

When driving in rain, do not sharply step on or quickly release the accelerator pedal, and do not brake the vehicle or turn the steering wheel suddenly. If it is necessary to reduce the vehicle speed, first slowly release the accelerator pedal, and then lightly step on the brake pedal several times to control the vehicle speed and prevent rear-end collisions.

### WARNING

- When it starts to rain and the road becomes slippery, drive the vehicle at a reduced speed.
- When driving on cloudy or heavily rainy and foggy days with poor visibility, turn on the fog lamps and low beams in time
- When it rains, the visibility is reduced, it is liable to fog up on the windows and the road is slippery, so drive the vehicle with caution.
- When it rains, clean the exterior rearview mirrors in time to prevent the raindrops accumulated on the rearview mirrors from affecting the driver's sight.
- In case of driving failure due to heavy rain or lightning, it is necessary to park the vehicle in a place where there is no stagnant water to prevent the vehicle from being flooded, and turn on the hazard warning lamps to remind the vehicles behind.
- After driving out of a water-logged road section, depress the brake pedal lightly to check whether the brake function is normal. When the brake linings are wet, the braking efficiency will be significantly reduced, and accidents are likely to occur.



### CAUTION

- Before driving over a water-logged road section, determine the depth of water, and the water level shall not be high than the lower edge of the car body.
- The speed of the vehicle driven over the water-logged road section should not exceed the walking speed.
- After the rain, clean the vehicle in time to prevent the acid substance in the rainwater from corroding the body paint.

### **Driving in hot seasons**

In case of driving in hot seasons, please read and observe the following.

### **DANGER**

- Do not drive the vehicle when wearing slippers or high heels.
- In summer, the tire pressure will increase with the increase of temperature, and the tire is easily to burst. After driving for a certain distance, stop the vehicle to check the tire pressure and wait for the tire temperature to drop before driving.
- In hot summer, always check whether any vehicle circuit is short-circuited or aging, whether the connector is loose, whether the battery is in normal working condition, etc., to prevent the vehicle from spontaneous combustion.

### WARNING

- When parking, note to check whether there are dangerous objects and inflammables around.
- Try to avoid exposing the vehicle to the sun for a long time in the hot season. and do not place items such as lighters, paper scraps, cloth toys, perfumes, etc. on the instrument panel and its vicinity.



### **CAUTION**

If it is unavoidable to expose the vehicle to the sun, park the vehicle with its front not exposed to the sun or use an aluminum foil sunshade. At the same time, the wiper arm can be raised to prevent the wiper blade from aging or even being deformed in advance.



### **Driving in cold seasons**

### Precautions for driving in cold seasons

In case of driving in cold seasons, please read and observe the following.

### **▲** WARNING

- Before driving in cold seasons such as winter, carefully check the safety equipment in the vehicle such as steering wheel, brakes, lamps, instruments, horns, wipers, etc.
- The road is slippery after the snow in winter. During driving, be sure to keep stable speed and even operation. Do not perform unstable operations such as sudden acceleration, emergency braking, sudden steering, etc., and accelerate smoothly and keep driving the vehicle at medium or low speed.
- Be gentle when starting and accelerating to prevent tire slippage and sideslip.
- Always check the battery condition and keep the battery fully charged for starting.
- Use windshield washer fluid containing antifreeze, which can be purchased at the GAC AION sales store and ordinary auto parts stores.
- Have some equipment and tools available for use in an emergency. The following equipment is recommended: snow chains, window scrapers, sandbags, signal flashers, jumper cables, etc.

### **CAUTION**

- Park the vehicle in a place where there is no snow or water accumulation to prevent the water from freezing and tearing the wheels.
- Place wooden boards at the tires to prevent snow from accumulating.
- Avoid parking the vehicle under a tree to prevent ice cubes from falling and damaging the vehicle.
- The wiper arm can be raised during parking to prevent freezing on the windshield and avoid tearing the wiper blade or damaging the motor during use.

### Using tire chains

Tire chains can be installed to the front wheels for driving in harsh conditions such as snowy or icy roads in winter.

### **▲** WARNING

- Tire chains must be installed in pairs to the driving wheels.
- Do not install the tire chain to the emergency spare tire (if available). If the front wheel is equipped with a spare tire and the tire chain needs to be installed, be sure to change the positions of the spare tire and the rear wheel.
- For installation of tire chains on all tires, ensure that the vehicle can be driven in a balanced manner in all weathers. It shall be borne in mind that after installation of tire chains, the car power may be insufficient. Even if the road surface is in good condition, drive carefully.
- While driving, neither exceed the specified speed limit of tire chains nor exceed 50 km/h, whichever is lower. Do not overspeed, accelerate sharply, decelerate sharply, or make sharp turns.



### ♠ WARNING (Cont'd)

- When decelerating, operate the brake pedal reasonably. Emergency braking on snowy or icy roads will cause the vehicle to drift and slip. Maintain an appropriate safety distance from the lead vehicle, step on the brake pedal slightly, and bear in mind that installing tire chains to the tires can increase certain friction force, but can not prevent sideslip.
- Failure to do this will adversely affect the performance and safety of the vehicle.

### **CAUTION**

Do not use tire chains on dry ground. After driving to snow-free roads, remove tire chains.

### **MOTE**

 Various countries and regions have different regulations on tire chains. Before assembling tire chains, be familiar with the local laws and regulations.



### Reverse tilt-down\*

Some vehicles are designed with turning down of exterior rearview mirror when reversing. During reversing, the exterior rearview mirror will automatically fold down to a set angle, so that the driver can observe the surrounding environment.

The driver can turn on or off the folding down of the exterior rearview mirror through the center console display.

When the gearshift lever is moved out of the "R" position, the exterior rearview mirror will automatically reset.

### **M** NOTE

- Set the folding down angle of exterior rearview mirror when reversing through the center console display.
- The exterior rearview mirrors may reset automatically at high reversing speeds.

### Reversing parking aid (RPA)

The RPA uses the ultrasonic sensor on the rear bumper of the vehicle to detect the distance between the rear of the vehicle and obstacles, assisting the driver to park the vehicle and adjust the vehicle position.

### Using RPA

When the gearshift lever is moved into the "R" position, the RPA will automatically be turned on, and when the RPA recognizes an obstacle within the detection range, it will start to alarm.

When the gearshift lever is moved out of the "R" position, the RPA will automatically be turned off.

### Turning on and off RPA audible alarm

For some models, the RPA audible alarm can be turned on or off via the center console display.

### WARNING

- The RPA cannot take the place of the driver's observation of the surrounding environment. The driver shall focus on safe reversing and position adjustment according to the practical conditions.
- The RPA sensors have blind spots while they detecting obstacles. During reversing, the driver shall observe the surrounding environment carefully to avoid scratches or collisions.
- Please control the speed when reversing to avoid danger. When the RPA sends the continuous audible alarms, it indicates that the vehicle is extremely close to the detected obstacle, and reversing shall be stopped immediately to prevent an accident.



### **NOTE**

- When the reversing speed is too high, the RPA may not work.
- When the vehicle is reversing at a narrow place or on an uphill slope, the RPA sensors may not detect railings, trees or slope surfaces, which is normal.
- The surface of some materials cannot reflect the signal from the RPA sensor, so that the RPA sensor cannot detect such materials or people wearing the clothing made of such materials.
- Noise sources outside the car may interfere with the radar sensor, making it impossible to detect any target.
- Please refer to "Parking Parking Assist - SVM" for the precautions for using the RPA sensor.

## Surround view monitor (SVM)

The SVM processes the video signals collected by the front, rear, left and right panoramic cameras of the vehicle, and displays the panoramic image around the vehicle on the center console display to provide the driver with the information on the surrounding environment of the vehicle and to reduce blind spots during driving. It can also realize vehicle trajectory prediction, so that the driver can fully understand the running direction of the vehicle and ensure driving safety.

### **SVM** interface



- Function button area
- 2 2D panoramic image display area
- Single view /3D panoramic image display area

### **NOTE**

 The SVM interface is related to the vehicle configurations, so please refer to the actual vehicle configurations.



### **Turning on SVM**

The SVM can be automatically turned on when the gearshift lever is moved to the "R" position.

Click the button on the center console display to enter the quick control interface, so as to turn on the SVM.

### **Settings of SVM**

The SVM can be set in the function button area.

- Switching of turned down state of exterior rearview mirror when reversing
  - On the SVM interface when reversing the vehicle, click the icon to quickly switch between the turned down state and the normal state of the exterior rearview mirror, so that you can better observe the surrounding environment of the vehicle. (This function is only valid when the vehicle is reversed.)
- ♦ Panoramic image interface switching
  - Click the 2D/3D panoramic image button to change the SVM display effect.
- ♦ Radar audible alarm switch
  - Click the icon to enable or disable the radar audible alarm.
- Function settings
  - Click the icon to display the settings interface. Trajectory, time of moving out of "P" position, transparent chassis (if equipped), panoramic view after activation of radars (if equipped), and panoramic view after activation of turn signal lamps can be set as needed.

### ▲ WARNING

The SVM cannot take the place of the driver's observation of the surrounding environment. The driver shall focus on safe parking according to the practical conditions.

### **CAUTION**

- Keep the RPA sensor surface clean and not blocked. If the RPA sensor is dirty or blocked, that is, the RPA sensor area is covered by rain, snow, mud or others, its related functions may fail to work, and the instrument cluster may display related function disabled or fault information. To restore these functions to normal, clean the dirts.
- Do not attach accessories, stickers (including transparent stickers) or other objects on the RPA sensor, camera or surrounding area.
- If the RPA sensor is damaged or its direction changes, the instrument cluster will display the alarm information. In this case, please contact the GAC AION sales store for inspection in time.
- The RPA sensor, camera or the surrounding area should be free from strong impact. If the RPA sensor and camera are strongly impacted, please contact the GAC AION sales store for inspection.



### CAUTION (Cont'd)

- If the bumper needs to be repainted due to scratches or color modification, avoid the area where the RPA sensor is installed. The change of paint color may impair the performance of the RPA sensor
- Clean the RPA sensor surface with a piece of soft wet cloth to avoid scratching it.
- Keep the surface of the camera clean and not blocked at all times. Clean the camera with a piece of soft wet cloth to avoid scratching the camera.
- Clean the RPA sensor with a highpressure cleaner gently in snatches and the nozzle shall be at least 10cm away from the sensor.
- Clean the camera with a highpressure cleaner gently in snatches and the nozzle shall be at least 30cm away from the sensor.
- If water drops are on the surface of the RPA sensors, the sensitivity of the sensors will reduce. Wiping off them with a piece of soft cloth can restore the sensitivity of the sensors.

### **NOTE**

- When the SVM is activated in a gear position other than "R", the system will exit automatically after a period of time
- When the gearshift lever is moved from "R" to "D", and the vehicle is moving fast, the SVM will be turned off immediately.
- When the vehicle is in a gear position other than "R", clicking the exit button in the upper left corner of the SVM interface can exit the SVM.
- The RPA sensor and camera must be adjusted and calibrated after the RPA sensor or its mounting bracket or the camera or its mounting bracket is removed or installed, or the toe-in is adjusted, or a vehicle collision occurs.
- The adjustment and calibration of the RPA sensor and camera requires the use of special tools and equipment. It is recommended to contact the GAC AION sales store for related work
- Repair of the vehicle body or bumper may cause the direction of the RPA sensor to change and affect the functions related to the RPA sensor. It is recommended to contact the GAC AION sales store for inspection.
- The radar sensor is a precision component, which shall not be removed & refitted and repaired without authorization. Otherwise, GAC will not assume any responsibility for the damage arising therefrom.



### **Electric park brake (EPB)**

### Manually applying or releasing parking brake

When the vehicle is in a gear position other than "P", depress the brake pedal and manually apply or release the parking brake via the center console display.

### Automatic applying or releasing parking brake

When the seat belt is fastened, all the doors are closed, and the gearshift lever is moved out of the "P" position, the EPB will be automatically released, and the indicator lamp (P) on the instrument cluster will go out.

When the vehicle is in "D" position, the EPB is applied, and the accelerated pedal is depressed, the EPB will be automatically released, and the indicator lamp (P) on the instrument cluster will go out.

When the vehicle is stopped stably, and the gearshift lever is moved into the "P" position, the EPB will be automatically applied, and the indicator lamp (P) on the instrument cluster will come on.

### Application of dynamic emergency braking

If the service brake fails while the vehicle is running, you can try to continuously press the "P" button for emergency braking.

### **Towing mode**

Turning on towing mode

♦ When the vehicle is in the "N" position, the EPB is released, and the brake pedal is depressed, the towing mode can be turned on via the center console display.

### Turning off towing mode

♦ The towing mode can be turned off via the center console display.

### WARNING

- When the vehicle is running, do not apply the EPB for speed reduction unless necessary, as the EPB only applies braking force to rear wheels, which is likely to cause traffic accidents.
- Be sure to apply the EPB during parking.
- Do not use dynamic emergency braking unless necessary, as it is likely to cause traffic accidents. Moreover. the braking distance is longer than that generated during braking by depressing the brake pedal, and the service life of the parking brake system will be shortened.

### **CAUTION**

- When the battery power is low, the system cannot release the EPB. If conditions permit, you can connect a jumper cable for emergency start, and then release the EPB. It is recommended to contact the GAC AION sales store for operation.
- If the vehicle continues to slide after the EPB has been applied on the slope, please depress the brake pedal, drive the vehicle to a flat road, and contact the GAC AION sales store for inspection in time.



### **(** CAUTION (Cont'd)

- In the following cases, try to apply and release the EPB repeatedly. If the fault has not been eliminated, it is recommended to contact the GAC AION sales store for inspection.
  - If the EPB status indicator lamp
     (P) on the instrument cluster
     keeps flashing, it indicates that the
     EPB is faulty.
  - If the EPB status indicator lamp
     (P) on the instrument cluster
     comes on when EPB is not
     applied, it indicates that the EPB is
     faulty.
  - If the EPB fault indicator lamp on the instrument cluster comes on, it indicates that the EPB is faulty and its braking performance is degraded.

### **NOTE**

- If the EPB cannot be released when the gearshift lever is at "P" position, the instrument cluster will give an alarm to remind you.
- If the "P" button is pressed during driving, the instrument cluster will give an alarm message together with an audible beep alarm.
- When the EPB is applied or released, operation noise will be generated, which is normal.
- If the EPB has not been used for a long time, the system will perform automatic test, and motor running noise will be generated, which is normal.
- ◆ EPB will choose different application force strategies on different slopes. EPB can realize parking on a slope with a maximum gradient of 30%. If parking on a slope with a gradient greater than 30%, there will be a risk of slipping, and the EPB will be applied again, which is normal.
- After the EPB is applied, it can ensure that the vehicle does not slide on a slope with a gradient of 30% within 5min. If sliding occurs during this duration, the EPB will be applied again.
- To turn off the towing mode, if the center console display gets stuck and cannot be used, depress the brake pedal and long press (for more than 10s) the "P" button to turn off the towing mode.



### **Closing all windows**

# Closing window by left front door power window button

Before getting out of the vehicle, make sure all windows are closed. If any window is not closed, it can be closed by operating the left front door power window button.

#### Locking-sensitive window closing\*

After the locking-sensitive window closing is enabled through the center console display, leave and lock the vehicle with all the keys, so all the windows are automatically closed.

#### Remote window up

If you leave the vehicle with all the keys and find that the windows are not closed, you can close the windows via the remote window up function.

When all doors are closed, all the windows can be automatically closed by pressing and holding the smart key lock button within the effective range. Release the smart key lock button to stop closing of all windows.

### **▲** WARNING

- During operation on windows, make sure that no part of the driver and passenger's bodies will be pinched.
- The anti-pinch function may not work when the window is about to close completely.

### **CAUTION**

- It is forbidden to operate 2 or more windows at the same time. Otherwise, the vehicle may be damaged.
- It is prohibited to operate the same window in opposite directions by pressing the left front power window button and other passenger side power window buttons at the same time. Otherwise, the power window may stop working.

### **1** NOTE

◆ If the power of the vehicle is turned off, and all doors are closed, remote window down can be enabled by pressing and holding the smart key unlock button ...



### **Closing sunroof**

## Closing sunroof by operating sunroof button

Before getting out of the vehicle, make sure the sunroof has been closed. If it is not closed, it can be closed by operating the sunroof button.

#### Locking-sensitive sunroof closing\*

After the locking-sensitive window closing is enabled through the center console display, leave and lock the vehicle with all the keys, so the sunroof is automatically closed.

#### Remote sunroof closing

If you leave the vehicle with all the keys and find that the sunroof is not closed, you can close it via the remote sunroof closing function.

When all doors are closed, the sunroof can be automatically closed by pressing and holding the smart key lock button within the effective range. Release the smart key lock button to stop closing of the sunroof.

### **M** WARNING

- During operation on the sunroof, make sure that no part of the occupants' bodies will be pinched.
- The anti-pinch function may not work when the sunroof is to be closed completely.

### **NOTE**

If the power of the vehicle is turned off, and all doors are closed, remote sunroof closing can be enabled by pressing and holding the smart key unlock button

### **Follow Me Home**

The Follow Me Home provides light when you park at night and go home.

After the Follow Me Home function is turned on through the center console display, when the auto headlamp function is turned on and the low beams automatically come on, the low beams will be on for a period of time and then go out after you leave the vehicle.



# Unlocking doors inside the vehicle

#### Central unlocking



The locked door can be unlocked by pressing the unlocking end of the central locking switch inside the vehicle.

#### Unlocking by door inside handle



The locked door can be unlocked by pulling the door inside handle.

### **NOTE**

- ◆ Do not frequently operate the central locking switch in a short time. Otherwise, the central locking switch may temporarily fail. In this case, after the door lock motor cools down, the central locking can be used again.
- With the vehicle stationary and in "READY" mode, if the driver unfastens the seat belt and sets the shift lever to "P" position, the door is unlocked automatically.

# Opening doors inside the vehicle



After the vehicle is unlocked, the door can be opened by pulling the door inside handle.





# Safety notes before getting off the vehicle

Before the driver leaves the vehicle, if the doors or windows are not closed, the instrument cluster will give corresponding audible and visible prompts.



### Locking outside the vehicle

#### Locking by smart key button

The power of the vehicle is turned off, the driver and passengers leave the vehicle and all doors are closed, there is no effective key in the vehicle, and the lock button is pressed within the effective range of the smart key.

#### Intelligent active locking

The vehicle can be automatically locked after the intelligent active locking function is enabled through the center console display, the power of the vehicle is turned off, the driver and passengers leave the vehicle, all doors are closed, there is no effective key in the vehicle, and the smart key is carried away from the vehicle.

### **NOTE**

 The horn alarm for vehicle locking/ unlocking can be switched on/off in the center console display.

# **Exterior rearview mirror folding**

#### Electric folding and unfolding\*

Through the exterior rearview mirror adjusting interface in "My Car" menu on the center console display, the exterior rearview mirrors can be electrically folded or unfolded.

#### Automatic folding and unfolding\*

After enabling or disabling of the automatic folding and unfolding of the exterior rearview mirror through the center console display.

- If the vehicle is locked, the exterior rearview mirror will be folded automatically.
- If the vehicle is unlocked, the exterior rearview mirror will be unfolded automatically.

#### Manual folding and unfolding



Pull the exterior rearview mirrors toward the rear of the vehicle (arrow A) to manually fold them.

Pull the exterior rearview mirrors toward the front of the vehicle (arrow B) to manually unfold them





### WARNING

 Before driving, make sure the exterior rearview mirrors are unfolded, and adjust them to an appropriate angle.

## **CAUTION**

Do not manually fold the rearview mirrors with electric folding function frequently, otherwise the internal folding mechanism will be damaged and the electric folding function will fail.



### **Body anti-theft**

#### **Body anti-theft**

When the vehicle is locked, the vehicle will enter the anti-theft status.

#### Anti-theft alarm

When the vehicle is locked and any door is illegally opened, the alarm will be triggered, the left and right turn signal lamps will flash, and the horn will sound.

If the anti-theft alarm is triggered for a period of time and the vehicle is still not unlocked, the vehicle will temporarily deactivate the alarm function.

#### Alarm cancel

If the vehicle is unlocked or started using a valid key during alarming, the alarm will be automatically canceled.

#### Switching of alarm mode

There are two anti-theft alarm modes, that is, audible and visual alarm, and visual alarm, the former of which is the default mode

With the ENGINE START/STOP button in "OFF" position, you can press and hold the locking and unlocking buttons on the smart key at the same time to switch between these two modes. If the switching is successful, the left and right turn signal lamps will flash simultaneously several times.

### **CAUTION**

 Do not modify or disassemble the body anti-theft system, otherwise the system will not work properly.

### **NOTE**

- Do not leave the key in the vehicle but carry it with you when leaving the vehicle.
- The body anti-theft system cannot prevent all thefts or guarantee the absolute safety of the vehicle.
- In order to prevent accidental alarm triggering or vehicle theft, please ensure the followings:
  - No one is in the vehicle.
  - The windows are closed before the vehicle is armed.
  - There are no valuables or other personal belongings in the vehicle.
- An alarm may be triggered in the following cases.
  - Door unlocking using the mechanical key.
  - Vehicle unlocking from inside after the vehicle is locked.
  - Door opening from inside after the vehicle is locked



### **Charging instructions**


#### Charging methods

This vehicle has two charging methods: AC charging and DC charging.

You can use a home charger or an AC charging pile for AC charging of the vehicle.

#### Charging devices

- ♦ Home charger
  - The home charger can use AC power supply to charge the vehicle.



- ① Charger
- 2 Vehicle charging connector
- 3 Charge control box
- 4 Charge cable

### 🛕 WARNING

- Do not use the charging device in the sun, heavy rain, or in a closed environment
- Do not modify or repair the AC charging device without authorization, otherwise there may be a danger.

### ▲ WARNING (Cont'd)

- When the home charger is used for the AC charging, it is necessary to match the corresponding power socket according to the specification of the vehicle charging connector, use the dedicated standard 10A or 16A power socket, and avoid sharing the lines with other home appliances. Chargers below 10A use the 10A power socket, and 10~16A chargers must use the 16A power socket.
- The charging device must be well grounded when in use.

### **NOTE**

- The above-mentioned home charger is specially designed for GAC AION. If you need one, you can contact the GAC AION sales store for consultation and purchase.

### **NOTE**

- If you need a charging pile specially provided by GAC AION, you can contact the GAC AION sales store for consultation and purchase.
- Before use, you should read the accompanying instructions and precautions carefully and strictly abide by them.

#### **Charge limit setting**

According to your electricity needs, the charge limit can be set through the center console display.

### **NOTE**

 The charge limit cannot be set for some models. Please refer to the actual vehicle.



#### Charging status indication

The charging status of the vehicle can be known through the vehicle charging indicator lamp, instrument cluster, charging pile, home charger control box, etc.

- ♦ Vehicle charging indicator lamp
  - The vehicle charging indicator lamp is the turn signal lamp. The vehicle charging status is as follows:
    - When the charger is successfully connected, all the turn signal lamps will be on for a long time and then go out.

When charging starts, the turn signal lamp flashes twice.

- ♦ Indications on instrument cluster
  - After the charger is successfully connected to the charging inlet of the vehicle, the charger indicator lamp
    - on the instrument cluster will come on.
- ♦ Charging pile indication
  - If a charging pile is used, the charging status of the vehicle will be displayed on the large screen of the charging pile. Please refer to the actual indication of the charging pile.
- ♦ Home charger control box indication
  - If the GAC AION's dedicated home charger is used, the charge control box indicator lamp will show the charging status (see the detailed status description on the charge control box).

#### Charging precautions

Please read and observe the followings carefully before charging your vehicle.

### **▲ WARNING**

Please use the charging device that meet the regulatory requirements. Otherwise, it may result in charging failure, even causing vehicle damage or personal injury in severe cases. If necessary, please contact the GAC AION sales store.

### **▲ WARNING (Cont'd)**

- Do not modify or disassemble the charging device without authorization. When the charging device is faulty, please contact the manufacturer, and do not try to troubleshoot it by yourself.
- Do not use the charging device when it is damaged, rusted, wet, has foreign objects or is damaged in any way.
- ◆ Do not charge the vehicle when the surface of the charge cable or vehicle charging connector is cracked, the surface of the socket is damaged, rusted or cracked, or the connection is too loose.
- Do not use the charger and the vehicle charging inlet when they are deformed, blackened or ablated, otherwise the vehicle or charging device may be damaged, and in severe cases, personal injury may occur. If necessary, please contact the GAC AION sales store.
- ◆ The charging device must be well grounded when in use.
- Do not charge the vehicle in a place with flammable materials, and a ventilated place is recommended.
- Minors are prohibited from using the charging device or from approaching the vehicle being charged.
- Do not charge the vehicle in the open air in thunderstorms. Otherwise, it may result in charging failure, even causing vehicle damage or personal injury in severe cases.
- When you need to charge the vehicle exposed to the rain, please confirm whether there is water entering the charging inlet. It is forbidden to charge the vehicle when there are obvious water stains in the charging inlet. Otherwise, it may result in charging failure, even causing vehicle damage or personal injury in severe cases.
- During the charging, please ensure that the vehicle is properly connected to the charging pile, and it is forbidden to touch, unplug or insert the charger.
- Due to the danger of high voltage, it is recommended to keep a certain distance from the charging pile during charging, otherwise it may cause personal injury.



### ▲ WARNING (Cont'd)

- Keep a certain distance from the charging pile when charging the vehicle, otherwise it may cause personal injury.
- During the charging, users with implanted medical equipment such as pacemakers need to stay away from the vehicle being charged to avoid electromagnetic interference affecting the work of the medical equipment.
- During the charging, if you find any odor or smoke in the vehicle, please stop charging the vehicle immediately and contact the GAC AION sales store.
- After the charging, do not disconnect the charging device with wet hands or standing in water, otherwise it may cause electric shock and personal injury.

### **CAUTION**

- Do not directly pull the cable to move the charging device, and please handle it with care.
- Please do not charge the vehicle by AC charging and DC charging at the same time to avoid damage to the vehicle.
- When the instrument cluster shows a low battery, please charge the vehicle as soon as possible. Charge the battery before its battery power is completely exhausted, otherwise the service life of the traction battery system will be affected
- Before the charging, please check whether the charger and the vehicle charging inlet are clean and free of foreign objects. Otherwise the charging may fail or the vehicle charging inlet may be damaged.
- During the charging, do not use a highpressure washing device to wash the charging inlet. Otherwise, it may result in charging failure, even causing damage to the vehicle or charging device.
- Make sure that the charging device is disconnected and the charging inlet cap is closed before starting the vehicle.

### **NOTE**

- Please read and observe the use instructions and precautions related to the charging device carefully.
- ◆ The vehicle must be parked before the battery is charged.
- When the battery temperature is low, it may not be possible to charge the battery at full power at the beginning of charging. As the battery temperature increases during the charging, the charging power increases.
- Charging the vehicle in a hightemperature or low-temperature environment will reduce the charging power and prolong the charging time.
- ◆ The vehicle cannot be charged while the software is being upgraded.



### **AC** charging


General operation steps of AC charging are as follows:



 Unlock the vehicle, press the rear edge of the charging inlet cap located on the left side of the vehicle to open it.




2. Open the AC charging inlet dust cover.



3. While pressing the unlocking button of the charger in the direction of arrow A, insert the charger in the direction of arrow B. After the charger is successfully connected, all turn signal lamps are on for a long time and then go off, and the charger indicator lamp on the instrument cluster comes on.



- Make relevant settings on the charging pile (such as start via APP), and start the charging pile.
- Check the charging status through the instrument cluster.
- After charging, press and hold the charger unlocking button on the smart key to unlock the charger.



- While pressing the charger unlocking button in the direction of arrow A, unplug the charger in the direction of arrow B
- Close the charging inlet dust cover and the charging inlet cap, and insert the charger back into the charging pile to complete the charging.

### **▲** WARNING

MOIA

 During the charging, make sure that the vehicle is properly connected to the power supply, and it is forbidden to unplug the charger.

### **NOTE**

- When the vehicle starts to be charged, the charger will be locked automatically. After the charging, the charger will be unlocked automatically (except when the charger is in the anti-theft state).
- ◆ When the anti-theft state of charger is enabled through the center console display, the charger will not be unlocked automatically after the vehicle is fully charged or heat preservation ends. If the charger is not unplugged for a long time after being unlocked, the charger will be locked automatically again. In this case, to unplug the charger, it needs to be unlocked again.

### NOTE (Cont'd)

- During the AC charging, if the charger cannot be locked or the electronic lock is unlocked abnormally, the charging will be ended
- If the charger is connected for a long time but charging fails, please unplug the charger in time to avoid low battery.
- ◆ The charging thermal protection function can be activated on the center console display to maintain the battery temperature, improve the battery range and vehicle performance while driving, and prolong the service life of the traction battery. In the case of AC charging in a low-temperature environment, the charging thermal protection function will be activated automatically.
- For some models, you can set the thermal protection reminder function on or off through the center console display.
- If other AC charging piles on the market are used, the charging thermal protection function may not work properly. It is recommended to use GAC AION's dedicated charging pile or home power supply to charge the vehicle.
- If you encounter special circumstances and cannot unlock the charger, you can unlock it through the emergency unlocking device of the charger. For details, please refer to the "Emergency treatment - Owner emergency -Emergency unlocking/locking" section.
- The charging method of the home charger is basically the same as that of the AC charging pile.
- The above-mentioned charging method is a general method, which may be slightly different from the charging method indicated on the actual charging pile. Please follow the indications of the charging pile during actual charging.




### **DC** charging



 Unlock the vehicle, press the rear edge of the DC charging inlet cap located on the left side of the vehicle to open it.



2. Open the charging inlet dust cover.



 Insert the charger as arrowed. After the charger is successfully connected, all turn signal lamps are on for a long time and then go off, and the charger indicator lamp for on the instrument cluster comes on.



- Make relevant settings on the charging pile (such as scanning QR code or swiping a card), and start the charging pile.
- Check the charging status through the instrument cluster.
- You can actively stop the charging as desired, or the charging can be stopped automatically when the vehicle is fully charged.





- 7. Pull out the charger as arrowed.
- Close the charging inlet dust cover and the charging inlet cap, and insert the charger back into the charging pile to complete the charging.

### **▲** WARNING

- During the charging, make sure that the vehicle is properly connected to the power supply, and it is forbidden to unplug the charger.
- After the DC charging, please unplug the charger in time.

### **NOTE**

◆ The above-mentioned DC charging method of the charging station is a general method, which may be slightly different from the charging method indicated on the actual charging pile. Please follow the indications of the charging pile during actual charging.



### **External cleaning**

Washing the vehicle frequently helps to protect its appearance.

The following conditions are likely to cause peeling of the paint layer or cause corrosion of the body and parts, and the vehicle needs to be cleaned in time:

- ♦ After driving along the coast.
- ♦ After driving on saline-alkali roads.
- Paintwork contaminated with coal tar or tree sap.
- ♦ Dead insects, insect droppings or bird droppings fallen on the paintwork.
- ♦ After driving in areas contaminated with coal ash, oil fumes, mineral dust, iron dust or chemicals
- ♦ Liquids such as benzene and gasoline splashed on the paintwork.
- ♦ Severe dust or mud buildup on the vehicle.

#### Manual vehicle washing

After driving, it is necessary to wait for the vehicle to cool down sufficiently in a cool place before washing it. Perform the manual vehicle washing in the following steps:

- 1. Make sure all doors and windows are closed
- 2. Use a water pipe to clean the dirt on the vehicle surface, the mud and the salt and alkali on the vehicle bottom. and the recessed parts of the wheels.
- 3. Dip a sponge in the special detergent and wipe gently to remove the contaminants

### CAUTION

- Do not use the same sponge to wipe the whole vehicle, so please wipe the upper and lower parts of the vehicle with different sponges to avoid damage to the paintwork.
- 4. Clean tires with a special sponge and brush.

- 5. Thoroughly flush out the foam from the vehicle
- 6. Use a special absorbent towel to dry the water marks on the body surface. Do not wipe or press the body surface with force to avoid damage to the paintwork.
- 7. Use a blower to dry the accumulated water in the gaps of the vehicle, such as door sealing strips, exterior rearview mirrors, charging inlet cap, headlamp gaps, etc.

#### WARNING

Be careful not to cut your fingers when cleaning the carpet or chassis.

#### Automatic vehicle washing

Before the washing, you should fold your exterior rearview mirrors, close all doors and windows, and consult with the wash station staff to choose the safest wash procedures for the paintwork. Be sure to unfold the exterior rearview mirrors before driving.

### **MOTE**

 Certain types of brushes, unfiltered water, or machine-specific wash procedures in the automatic wash stations may scratch the paintwork and reduce its durability and gloss.

### Environmental protection:

The vehicle shall be cleaned at standard wash points to prevent sewage containing oil from being directly discharged into the sewer to pollute the environment.

#### High-pressure vehicle washing

The water sprayed by a high-pressure cleaner has a certain pressure. To avoid water entering or damaging the vehicle, do not keep the nozzle close to the following parts:

- Gaps around the doors.
- Window edges.



- Radar and camera areas.
- Connectors on the chassis.

### **CAUTION**

- When cleaning the vehicle with a high-pressure cleaner, pay special attention to the working pressure and spray distance.
- Do not allow the nozzle to continuously spray the same area.

#### Cleaning of special parts

- - Use a special cleaning agent and a soft brush to clean dirt and dust from the hub.
  - Rinse off stains and residual cleaning agent with clean water.
  - Dry the hub with a piece of soft dry cloth or let it dry naturally.

### **CAUTION**

- Do not use acidic, alkaline or abrasive detergents.
- Do not use a hard brush.
- Do not use cleaning agents on the wheels when the wheels are hot (for example, after driving or after parking in hot weather).

### ♦ Lamps

- Use a special cleaning agent to clean the lamps.
- Gently wipe the lamp shade with a piece of soft cloth.

### **CAUTION**

- Wash the lamps carefully to avoid scratching or crushing the lamp shade with force.
- Do not use organic substances or hard brushes to clean the surface of the lamp, otherwise the lamp shade may be damaged.
- Do not wax the lamp surface.
- ♦ Bumper

### **CAUTION**

 Do not scrub with abrasive detergents.



### Internal cleaning

# Cleaning of instrument panel and other interior trims

Wipe the instrument panel gently with a piece of moistened soft cloth during cleaning.

Please use mild neutral cleaners whenever possible, and avoid strong detergents or degreasing soaps.

## **CAUTION**

- Do not wet the interior trims when cleaning them.
- Do not use a blade or other sharp objects to remove dirt from the interior trim surfaces, otherwise it may damage the interior trim surfaces.
- Do not wipe with excessive force, otherwise the interior trims may be damaged.

#### Cleaning of leather

If the leather trims are not maintained or cleaned for a long time, the leather will become damp, moldy, dull, dry and cracked, which will affect both health and driving mood. Therefore, the leather trims must be carefully cleaned and maintained.

The leather cleaning steps are as follows:

- 1. Remove dirt and dust with a vacuum cleaner.
- Use a piece of soft cloth moistened with leather cleaner to wipe off any remaining dirt and dust.
- After cleaning, dry with a piece of soft dry cloth or let the leather dry naturally.

### **CAUTION**

Do not use ordinary detergents (such as washing powder, dish detergent, etc.) to clean the leather, otherwise it may damage the leather surface, resulting in corrosion or discoloration of the leather surface.

#### Cleaning of switches

Use a small and soft brush to remove dust from buttons and switches.

Use a piece of soft cloth dampened with disinfectant to wipe the surfaces of the buttons and switches, and then use a piece of clean soft cloth to wipe off any remaining liquid.

### **CAUTION**

 Do not use spray to clean the switch panel directly, otherwise the electrical consumers may be damaged.

## Cleaning of windows and rearview mirrors

Use a piece of soft cloth and special glass cleaner to clean the glass surfaces.

Dampen a piece of cloth with warm water and gently wipe the rear windshield in a direction parallel to the heating wires or antenna.

Clean the rearview mirrors with soapy water

## **CAUTION**

- Do not use glass cleaner to clean the rear windshield, as this may damage its antenna.
- Do not use abrasive cleaners to avoid damage to the glass and mirror surfaces

#### Cleaning of seat belt

Use a sponge or a piece of soft cloth dampened with mild soapy water or warm water to clean the seat belt. Regularly check whether the seat belt is free of excessive wear or cuts.

### **CAUTION**

 Please wait till the seat belt dries completely before retracting it, otherwise its retractor may be damaged.



### Cleaning of carpet

Clean the dust first with a vacuum cleaner. and then scrub the carpet in circular motions with a sponge or brush dampened with a foam cleaner.

### **M** NOTE

Do not use water, let the carpet dry after cleaning, and keep the carpet as dry as possible.

#### Precautions for internal cleaning

Please read and observe the followings when cleaning the interior of your vehicle.



#### DANGER

- Do not let the airbag components or wires in the vehicle get wet, otherwise the airbag may fail to deploy or malfunction, resulting in serious injury or even life-threatening danger.
- Do not use polishing wax or polishing cleaner to clean the instrument panel, otherwise the instrument panel may reflect light on the windshield, obstruct the driver's visibility, and cause serious injury or even life-threatening danger.

## **CAUTION**

- Do not spill liquids such as cleaners into the interior of the vehicle, otherwise it may cause the electrical components to get wet and malfunction. If any liquid is accidentally spilled, wipe it up immediately.
- Do not use strong acid or alkali cleaners.
- If you need to use a cleaning agent, please read the instructions of the cleaning agent carefully and follow them strictly.



#### External maintenance

The external maintenance shall be based on the external cleaning, and shall be carried out after the external cleaning.

#### Waxing

In order to maintain the gloss of the vehicle, it is recommended to polish and wax the body. The body waxing is required in the following cases:

- When the body surface does not repel water well
- ♦ When the body surface is exposed to water in a large area, and the water does not form droplets and adheres to the surface.

It is recommended to wax the body on a regular basis and contact the GAC AION sales store regularly (once a quarter) to maintain the vehicle, so as to restore the gloss of the body paintwork in time.

#### Cleaning of residual wax

After the body is waxed, use a special cleaner and a piece of clean cloth to remove the wax remaining on the glass so as not to affect the visibility.

#### Paintwork damage

If there is no obvious damage to the paintwork, please do not carry out secondary painting to prevent the paint color from being incompatible or not well matched.

For small areas of paintwork damage (such as scratches or stone impact marks). please cover them with paint as soon as possible before rust occurs.

If the damaged paintwork has been rusted, the rust must be completely removed, and the anti-corrosion primer and varnish shall be applied to the rusted position. It is recommended to contact the GAC AION sales store for treatment.

#### Maintenance of wheels

Regular maintenance of the wheels can keep the surface finish of the wheels and prolong their service life.

It is recommended to use high-quality hard wax on aluminum-alloy wheels every three months, or regularly clean steel wheels with a special sponge.

#### WARNING

- Do not treat the wheel surfaces with vehicle polish or other abrasive cleaners
- The wheels with damaged protective coating on surface must be repaired in time.

#### Maintenance of external plastic parts

External plastic parts are generally washed with clean water, soft cloth and soft brushes. If they cannot be cleaned, please use the special plastics cleaner.



#### **CAUTION**

Do not use abrasive cleaners to clean plastic parts, as this may damage the plastic parts.



### Internal maintenance

The internal maintenance shall be based on the internal cleaning, and shall be carried out after the internal cleaning.

#### Maintenance of instrument panel

After the instrument panel is cleaned, in order to slow down the aging of plastic parts such as the instrument panel, a layer of protective wax can be applied to the instrument panel to prolong the service life of the plastic material.

#### Maintenance of leather

Leather trims can be sprayed with a special leather wax and polished with a piece of dry cloth.

#### Maintenance of window glass

After the window glass is cleaned, glass coating products can be sprayed on it to prevent fogging of the windows in rain and snow or in winter

#### Maintenance of sealing strips

Regular maintenance of the rubber sealing strips of the doors, windows and other parts of the vehicle is intended to maintain their flexibility and prolong their service life. Such maintenance can also improve the tightness, make the door easy to open, reduce the impact sound of closing the door, and prevent freezing in winter. The maintenance steps of the sealing strips are as follows:

- 1. Use a piece of soft cloth to remove dust and dirt from the surfaces of the sealing strips.
- 2. Apply special protective agent to rubber sealing strips regularly.

#### Tire maintenance

Defective tires will increase the risk of driving, and you should get into the habit of checking your tires before driving.

#### Tire pressure

Check the tire pressure for this vehicle from the tire pressure sticker on the driver's side B-pillar (the listed pressure applies to both summer and winter tires).

According to the actual vehicle configuration and needs, you can choose the tire pressure inspection method that suits you from the following methods:

- ♦ For the vehicle equipped with an inflator pump, you can use the tire pressure gauge on the pump to check the tire pressure. (if available)
- ♦ Contact the GAC AION sales store to check the tire pressure.

If you find that the tire valve cap is missing, install a new one in time.



#### **DANGER**

 Insufficient tire pressure exacerbates tire deflection, and tires are extremely prone to overheating, which may lead to tread separation and tire burst. Too high or low tire pressure can accelerate tire wear, reduce vehicle maneuvering stability, and easily cause traffic accidents, injuries and even death.



#### WARNING

Take care to maintain proper tire pressure to prevent accidents.



### **M** NOTE

- For inspection of tire pressure, the tire must be in a cold state. When the temperature increases, the tire pressure can be slightly higher than the specified value, and it is not necessary to reduce the tire pressure.
- When checking the tire pressure or tire inflation, balance the weight of occupants and luggage, avoid slopes and adjust the tire pressure according to vehicle load
- After checking the tire pressure or tire inflation, be sure to put the tire valve cap back on the valve core.

#### Hidden damage

Damage to tires and rims often occurs in a hidden way, and abnormal vibration or deviation of the vehicle during driving may indicate tire damage. If you suspect that the tires are damaged, be sure to reduce the speed immediately and stop to check the tires for damage. If the damage is not visible from the outside, it is recommended to contact the GAC AION sales store to check the tires as soon as possible.

#### Precautions for wheel failure

When driving over curbs or similar obstacles, keep a slow speed in the vertical direction of the obstacles as much as possible.

Regularly check the damage of tires (such as splitting, abrasion, shedding, deformation or bulging).

Regularly remove debris embedded in the grooves of the tire pattern.

#### New tires and wheels

Make sure that the dimensions, load range, rated speed and structure type of new tire are the same as those of original one.

Replace at least two tires on the same axle at the same time, rather than only one tire individually.

Do not use tires of different dimensions or types, and do not mix summer tires, all season tires and winter tires in use.

Once wheels are installed, check whether the tightening torque of the wheel bolts meets the requirements.

#### WARNING

Never use tires that do not meet the specifications of this vehicle and have not passed the national product certification, otherwise it may cause accidents.

#### Winter and summer tires

- Winter tires
  - Winter tires have good grip performance on icv roads and in lowtemperature environments, and have excellent braking ability, which can improve driving safety in winter.
  - It is recommended to use winter tires while driving in icy or snowy days in winter or when the temperature is below 7°C.
  - Use only radial winter tires of same dimensions, load range and rated speed as original ones and approved for this vehicle.



- The tread depth of winter tires shall not be less than 4mm.
- After installation of tires, check the tire inflation pressure.

#### ♦ Summer tires

- Summer is a rainy season. The tire tread depth directly affects the driving safety in rainy days. The tread depth of summer tires shall not be less than 3mm
- Winter and summer tires are designed according to their respective typical lane conditions under the corresponding seasonal conditions. It is recommended to use winter tires in winter and summer tires in summer, otherwise the adhesion and braking ability will be poor.
  - If summer tires are used in severe cold conditions, cracks may appear on the tires, resulting in tire damage, increased tire noise, and loss of balance.
  - Winter tires may lead to decreased traction force of the vehicle on dry roads, increased road noise and shortened service life of tread. Please pay attention to the performance change of the vehicle in terms of maneuvering and braking after the winter tires are used.
  - The maximum speed for winter tires is relatively low. Do not exceed the allowable maximum speed for the tires during driving.
  - When driving in atmospheric temperature rising above 7°C, in order to ensure driving safety and performance, please replace the winter tires with summer tires in time.

#### Service life of tires

Service life of tires depends on tire pressure, driving style and tire assembly conditions.

If the front tires are worn more serious than the rear tires, it is recommended to perform tire rotation for the front and rear wheels, so as to make the service life of all tires about the same. (For tire rotation, please refer to the "Emergency treatment - Owner emergency - Tire rotation" section)

#### Wheel balance

The wheels of the new vehicle have been dynamically balanced, but during the driving, various influences may cause the wheels to appear unbalanced; when the steering wheel shakes during driving, the wheels may be unbalanced, and the wheels need to be dynamically balanced.

The unbalanced wheels may cause excessive wear on the steering system, wheel suspension mechanism and tires.

The dynamic balance must be performed after installation of new tires or repair of tires

#### Wheel alignment

Wheel misalignment will cause uneven and excessive wear of the tires, affecting driving safety. If uneven and excessive wear of the tires is found, please go to the GAC AION sales store to check the wheel alignment as soon as possible. Four-wheel alignment is required in the following cases:

- There are defects in driving performance, such as deviation.
- Chassis is damaged in accidents and related parts are replaced.
- Suspension parts are removed or replaced.
- Uneven and excessive tire wear occurs.



### Tires marked with rolling direction

Some tires are marked with arrows or characters indicating the rolling direction on the sides, so these tires must be installed in the marked rolling direction. If the tire rolling direction is reversed, there may be dangers such as tire jitter, increased noise, accelerated wear, and significantly weakened grip during driving.

#### Instructions for storing tires

If there is no rolling direction mark on the side of the tire, before removing the tire, make a mark on the tire to indicate the rolling direction, and refit the tire according to the mark to ensure the rotation direction and the dynamic balance of the wheel are unchanged.

The removed wheels or tires shall be stored in a dry place, preferably in a dark place.

The tires mounted on the rims shall not be stored upright, and the tires not mounted on the rims shall be stored upright (the tread surfaces shall touch the ground).

#### Precautions for use of tires

Please read and observe the followings when using and maintaining your tires.

#### WARNING

- Within the first 500km, the road adhesion of new tires is unlikely to reach the best condition. Therefore. the vehicle shall be driven carefully at a moderate speed to prevent accidents.
- If tires burst or leak when the vehicle is running, it is very easy to cause serious traffic accidents.

### WARNING (Cont'd)

- Never use damaged tires and wheels. or use tires of which the treads have been worn to the wear indicators
- Do not use old tires that have been used over six years.
- Do not use old wheels and tires. of unknown origin under any circumstances, otherwise, the driver may lose control of the vehicle and cause traffic accidents when driving.
- Do not use recycled tires. The carcass of these tires may degrade as the service time passes, and the durability may also be restrained. impairing the driving safety.

## CAUTION

- Be careful not to expose the tires to chemicals, oil, grease, fuel and brake fluid.
- If it is found that the vehicle is abnormally vibrating or deviating, stop the vehicle immediately and check whether the tires are damaged.
- Inadequate road adhesion of tires not subject to running-in period or excessively worn can directly affect the braking effect. If uneven and excessive wear of the tires is found, please go to the GAC AION sales store for inspection as soon as possible.



# Corrosion protection measures

The vehicle has effective corrosion protection. However, in order to reduce the risk of corrosion, please observe the followings:

- Perform regular vehicle washes to keep the body clean and prevent corrosion.
  - If you drive on salty roads in winter, or live by the sea, please have your vehicle be carefully cleaned at least once a month to reduce corrosion.
  - Please carefully clean the chassis on a regular basis to remove mud and dirt adhering to the chassis and wheelhouses.
  - Clean the chassis in time after driving on icy and snowy roads to prevent the residual deicing salt from corroding the vehicle.
- ♦ Check the paint and trims of the body.
  - If the paint layer is found to be chipped or cracked, it is recommended to contact the GAC AION sales store for repairs to prevent corrosion.
- Keep the interior of the compartments dry.
  - Moisture and dust tend to accumulate under the carpet, so the underside of the carpet shall be checked frequently to ensure it is dry and clean to prevent corrosion.
  - When chemicals, detergents, fertilizers, salts and others are transported, they must be stored in appropriate containers, and if spills or leaks are found, they must be cleaned immediately and the compartment must be kept dry.

- ♦ Use mudguards.
  - When the vehicle runs in salinealkali areas or on gravel roads, the mudguards can be used to prevent the adhesion of saline-alkali substances and the impact of gravels on the vehicle components.
- Park the vehicle in a well-ventilated garage or a roofed area, and do not park it in a damp and airtight environment.



### Long-term storage of vehicle

A good parking environment helps prevent deterioration and makes it easy to reoperate the vehicle. If possible, park the vehicle indoors. If the vehicle needs to be stored for a long time, please make the following preparations:

- ♦ Before parking, make sure that the SOC of the vehicle is 50%~70%.
- Carry out the maintenance every three months, and before parking, charge the traction battery by slow charge and then discharge it to 50%~70%.
- Keep the vehicle parking environment as dry and ventilated as possible, away from heat sources.
- Thoroughly wash and dry the outer surface of the body.
- Clean the interior of the vehicle to make sure carpet, interior trims, etc. are completely dry.
- Open the windows on one side slightly (in the case of indoor storage).
- Disconnect the negative terminal of the low voltage battery.
- Pad the front wiper blades with a towel or a piece of cloth so that they do not come into contact with the windshield.
- Cover the body with a car cover made of a "porous material" such as cotton. Non-porous materials such as plastic sheeting may trap moisture and damage the body paintwork.
- If possible, start the vehicle for a short period on a regular basis (preferably once a month).
- If the vehicle has been parked for more than three months, please confirm whether the instrument cluster has any alarm before using it again, and if any, contact the GAC AION sales store for inspection and repair.



### **Opening and closing hood**


### **Opening hood**



 Pull up the hood release lever in the cab, and then the hood 'clicks' and pops up slightly.




Stand in front of the vehicle (facing the front end of the vehicle), put your hand into the area to turn the secondary release lever as arrowed in the figure, and then lift the hood upward at the same time



Take out the stay bar and insert it into the position as shown in the figure to fix the hood.

### **Closing hood**



- Hold the hood by hand, and take away the stay bar to fix it to the position as shown in the figure.
- Lower the hood to a height of about 30cm above the front grille, and release both hands to let the hood fall freely so as to be locked.



### WARNING

- After opening the hood, make sure that the stay bar firmly supports the hood to prevent the hood from being closed suddenly.
- Before driving, ensure that the hood is closed and locked, otherwise, it may suddenly open during driving. resulting in accidents.


### **CAUTION**

Before closing the hood, be sure to fix the stay bar with the retaining clips. If the hood is closed and the stay bar is not properly returned to the original position, the hood may be deformed.

### **M** NOTE

 Before closing the hood, make sure that no tools, waste cloth, etc. are left in the motor compartment.

### Adding windshield washer fluid



Open the hood, open the washer fluid reservoir cap as arrowed, and check the washer fluid in the reservoir. If the washer fluid level is too low, please add the washer fluid or a mixture of washer fluid and water

### WARNING

- Do not add any additives to the windshield washer fluid, otherwise oil stains or other debris will be left on the windshield during cleaning, which will affect the driver's visibility.
- If the windshield washer fluid spills on your hands or eyes, rinse immediately with clean water.

### **CAUTION**


- Do not use other liquids in place of washer fluid, as this may cause streaks on the vehicle paintwork.
- Do not mix windshield washer fluid. and cleaning agent, as this may block the windshield washer nozzle.

### **M** NOTE

It is difficult to wash the windshield thoroughly with pure water.



### **Checking coolant**



Open the hood, and check the coolant level in the expansion tank in the area marked with frame as shown. If it is below the "MIN" mark, please fill the expansion tank with coolant to the level between the "MIN" and "MAX" marks in time.

### **▲** WARNING

- Do not remove the filler cap when the vehicle is hot to avoid burns.
- The coolant must be stored in marked containers out of the reach of children.
- If the coolant spills on your hands or eyes, rinse immediately with clean water.

### **OCCUPION**

- If the coolant is spilled during refilling, wipe it off with a rag to prevent damage to the parts or paintwork.
- It is recommended to go to the GAC AION sales store to add or change the coolant.
- Use the same coolant as the original one, and do not mix different types of coolant.

### **NOTE**


- The status of the expansion tank and the number of access panels depend on the model, and the figure is for reference only.
- Make sure that the level in the expansion tank is between "MIN" and "MAX" marks after refilling.

### Environmental protection:

Always dispose of the coolant in compliance with environmental laws and regulations, and do not dump it directly into garbage heaps, sewers, or on the ground.



### Checking brake fluid



Open the hood, and check the brake fluid level in the brake fluid reservoir. If it is below the "MIN" mark, please fill the brake fluid reservoir with brake fluid to the level between the "MIN" and "MAX" marks in time

### WARNING

- The brake fluid must be stored in marked containers out of the reach of children.
- If the brake fluid spills on your hands or eyes, rinse immediately with clean water. If you still feel unwell, seek medical attention.

### **CAUTION**

- Do not spill the brake fluid on the paintwork. If the brake fluid is spilled on the paintwork, please wash it with water immediately.
- It is recommended to go to the GAC AION sales store to add or change the brake fluid.
- Use the same brake fluid as the original one, and do not mix different types of brake fluid.

### **M** NOTE

The status of the brake fluid reservoir depends on the vehicle configuration, so please refer to the actual vehicle configurations.

### 🚯 Environmental protection:

Always dispose of the brake fluid in compliance with environmental laws and regulations, and do not dump it directly into garbage heaps, sewers, or on the around.



### A/C filter

The A/C filter is located behind the glove box. Regular cleaning of the A/C filter can keep the air in the compartments fresh.

### **CAUTION**

To clean the A/C filter, you need to remove the glove box first. In order to avoid damage to the vehicle by yourself, it is recommended to contact the GAC AION sales store for operation.

### **NOTE**

- Clean the A/C filter element according to the "Maintenance instructions -Regular maintenance" section in the Warranty and Maintenance Manual. In dusty or heavy traffic areas, the cleaning interval shall be shortened accordingly.
- Before using the A/C system, make sure that the A/C filter element is properly installed.




### Checking and replacing fuse

All circuits on the vehicle are fused to prevent damage to electrical consumers due to short circuits or overloading. These fuses are installed in two fuse boxes, that is, the motor compartment fuse box and the instrument panel fuse box.

If any electrical component fails to work, a fuse may be blown. If this happens, check and replace the fuse if necessary.

Check and replace the fuse in the following steps:

- 1. Turn off the vehicle power switch.
- 2. Open the fuse box cover.
  - Motor compartment fuse box



The motor compartment fuse box is located at the right rear of the motor compartment (facing the front end of the vehicle). You can open the hood, and press the buckles on both sides of the fuse box while pulling up the fuse box cover to check the motor compartment fuse.

Instrument panel fuse box



The instrument panel fuse becomes accessible after the driver side lower quard plate assembly is removed.

- 3. Remove the fuse from the fuse box.
- 4. Check the wire inside the fuse and replace it if it is blown.
- If the fuse is blown, replace it with a spare fuse of the same amperage rating (indicated on the motor compartment fuse box cover).
- After replacing the fuse, check whether the electrical components restore normal work. If the operation returns to normal, install the motor compartment fuse box cover or the driver side lower quard plate assembly.



### **CAUTION**

- Never use a fuse higher than the amperage rating, or substitute any other item for the fuse, as this may result in the vehicle damage, fire or personal injury.
- Do not replace the fuse with a wire, even temporary replacement is not allowed.
- Do not modify the fuse or fuse box.
- Keep the inside of the fuse box clean and protect it from moisture.
- If the correct fuse is installed but the fuse is still blown within a short time or the electrical components do not restore normal work, it indicates that the vehicle may have an electrical system failure, and it is recommended to contact the GAC AION sales store for repair.



### Low voltage battery maintenance

#### Checking low voltage battery

Frequently check the battery surface and the positive and negative terminals, ensuring that the positive and negative terminals of the battery are not loose or corroded.

Check the appearance of the battery for cracks, swelling, etc. If there is the above symptom, it is recommended to contact GAC AION sales store for repair as soon as possible.

For more inspection and maintenance items, please refer to the "Maintenance instructions - Regular maintenance" section in the Warranty and Maintenance Manual.

#### Replacing low voltage battery

Always use the battery of the same type and specification to replace the battery. It is recommended to contact the GAC AION sales store to remove, replace or install the battery.

### Environmental protection:

◆ The recycling of the battery must be carried out by a qualified unit to avoid pollution to the environment and damage to the operator.

#### Vehicle storage

Due to natural discharge and the wearout effect of certain electrical consumers. the power stored in the battery is gradually depleted even when the vehicle is not in use. If the vehicle is not in use for a long time, the battery power may be exhausted and the vehicle may fail to be started. Therefore, the negative terminal of the battery should be disconnected, and the battery power should be checked regularly. If necessary, start the vehicle to charge the battery.

### WARNING

- When removing the battery terminals, be sure to remove the negative terminal first. If the positive terminal is removed and it touches any metal in the surrounding area, it may spark and cause a fire, and possibly an electric shock, resulting in serious injury or even death.
- Before reconnecting the battery, turn off all electrical consumers on the vehicle. Connect the positive terminal first and then the negative terminal. Never install the terminals in the wrong order, as there will be a risk of
- The battery shall be kept away from heat sources and open flames, and ventilation shall be maintained during charging and use, otherwise it may cause fire or personal injury.
- Always check whether the battery terminal clamps are firm and in good contact to avoid sparks and battery explosions.
- The hydrogen gas generated when the battery is charged is flammable and explosive, so when using a charger to charge the battery, be sure to remove the battery.
- Always wear safety goggles when working on the battery and be careful not to let any battery electrolyte come into contact with your skin, clothing or bodv.
- If the battery electrolyte comes into contact with your skin or eyes, rinse immediately with water and seek medical attention. The contact area shall always be covered with a damp sponge or a piece of damp cloth until you see a doctor.



### 🛕 WARNING (Cont'd)

- Always wash your hands after working on the battery bracket, terminals, and other battery-related parts.
- Do not lean over the battery.
- Keep children away from the battery.

### **CAUTION**

- Avoid battery overcharging or longterm power loss.
- Avoid long-term high-current discharge of the battery.
- Firmly install the battery on the vehicle to avoid vibration.
- The oxides and sulfates produced by the battery terminal clamps must be cleaned up, and Vaseline shall be applied to avoid re-corrosion.
- When the vehicle runs in a cold region, do not discharge the battery completely to avoid freezing of the battery electrolyte.

### **NOTE**

- The automatic battery charging function can be activated, provided that the vehicle is stationary, the antitheft system of vehicle is activated, all the doors are locked, etc.
- Try to avoid using electrical consumers for a long time when the vehicle is not started, so as not to cause the battery power loss.

# Maintenance of traction battery

Precautions for use and maintenance of traction battery



#### **DANGER**

- It is strictly forbidden to remove, disassemble or modify the traction battery, or use the traction battery for other purposes.
- The traction battery shall be placed out of the reach of children.
- The traction battery shall be kept away from fire sources to avoid fires or explosion.
- It is forbidden to spray, trample, hit or destroy the traction battery to avoid leakage, fires or explosion of corrosive chemicals.
- It is strictly forbidden to touch the positive and negative poles of the traction battery case with both hands at any time.
- It is strictly forbidden to perform operations such as squeezing, piercing or burning that damage the battery system for the traction battery.
- If the traction battery suffers severe mechanical damage, resulting in the exposure of internal high-voltage components, there is a risk of violent combustion and electric shock, which may cause serious casualties and environmental pollution.
- ◆ The traction battery damage or electrolyte leakage may cause a fire. If it happens, it is recommended to contact the GAC AION sales store immediately. Do not touch the leaked electrolyte with hands. If the skin or eyes come into contact with the electrolyte accidentally, rinse the skin or eyes immediately with plenty of water, and seek medical attention immediately.



### DANGER (Cont'd)

 Since the traction battery pack is a high-voltage component, it is strictly prohibited to open or repair the traction battery pack by nonprofessional personnel without authorization.

### **CAUTION**

- The traction battery is located at the bottom of the vehicle. During driving, take care not to have the traction battery impacted or flooded.
- The vehicle not used for a long period of time shall be subjected to scheduled maintenance; otherwise, the performance degradation of the traction battery will occur.
- In order to give full play to the performance of the traction battery, try to avoid full charging and full discharging.
- The operating environment of the vehicle shall be dry, free of corrosive, explosive or destructive insulation gases or conductive dust, and away from heat sources.
- Avoid frequently using the high-power DC fast charge method to charge the vehicle, because it will affect the life of the traction battery.

### **MOTE**

The vehicle uses the traction battery to store electric energy and can be charged repeatedly. Ensure that the traction battery is fully charged before driving. During driving, the traction battery is discharged gradually. When the traction battery is low, it must be charged; otherwise, the vehicle cannot be driven.

### NOTE (Cont'd)

- The time required to charge the traction battery is affected by the charging power, battery SOC, battery temperature, vehicle service time, ambient temperature and other conditions
- For a new vehicle, when the traction battery is in the normal state, due to driving styles (such as frequent acceleration and deceleration), road conditions (such as long-time continuous climbing) and temperature (such as low temperature), the range of this vehicle will be appropriately reduced, which is normal.
- In summer, park the vehicle in a cool environment and try to avoid direct sunlight.
- When the chassis area of the vehicle is bumped, it is recommended to contact the GAC AION sales store for inspection and maintenance.

#### Precautions for LFP traction battery

If your vehicle is equipped with a LFP traction battery, please read and observe the followings.

### NOTE

- To keep the vehicle traction battery in the best condition, please fully charge the traction battery at least once a week, and fully charge it after deep discharge once every 3~6 months. (Deeply discharge the battery to make its SOC below 10%)
- When the vehicle detects that you have not performed full charge operation for a long time, it may automatically perform a self-test, and the self-test process will consume some power.



#### Recycling of traction battery

The traction battery is a safety component. For maintenance, repair, removal, installation, reuse or disposal of the traction battery, it is recommended to consult the GAC AION sales store

When the traction battery needs to be replaced or scrapped, it is recommended to contact the GAC AION sales store for recycling and disposal. The sales store will record the vehicle and owner traceability information through the traceability system.



#### / DANGER

If the traction battery is not handled correctly, electric shock and serious injury or even death may be caused. The removal, disassembly and discarding of the traction battery without authorization will cause pollution to the environment, and the vehicle owner shall bear the corresponding responsibility for the resulting environmental pollution or safety accidents.



#### WARNING

 When the vehicle must be scrapped, it is recommended to contact the GAC AION sales store for recycling and disposal. If you come into contact with high-voltage parts, cables and their connectors and other high-voltage components when removing the traction battery without authorization during vehicle scrapping, there may be a serious risk of electric shock.



# Emergency unlocking/ locking

The emergency unlocking/locking features of this vehicle include emergency unfolding of flush-fit door handle, emergency unlocking/locking by mechanical key, emergency locking of passenger's door, automatic unlocking program in case of collision, emergency unlocking device of liftgate, and emergency unlocking device of charger.

## Emergency unfolding of flush-fit door handle

When the flush-fit door handle is frozen by rain or snow or stuck by foreign objects and cannot be unfolded after the vehicle is unlocked, emergency unfolding of the flush-fit door handle can be achieved by the following methods:



- Press the front side of the door handle in the direction of arrow A to uplift the rear side.
- 2. Pull the handle to open the door.

### **NOTE**


 All four flush-fit door handles support emergency unfolding. The above content is introduced with the left front door as an example.

## Emergency unlocking/locking by mechanical key

The mechanical key is inside the smart key. When the door cannot be unlocked/ locked by the smart key, the mechanical key can be used to perform the operation. The specific steps are as follows:



- Press the mechanical key in the direction of arrow A shown in the figure, and push out the mechanical key cover in the direction of arrow B to take out the mechanical key.
- 2. Unfold the flush-fit door handle.



Insert the mechanical key into the keyhole, and turn the mechanical key to unlock or lock the door.



#### Emergency locking of passenger's door

Open the passenger's door to be locked.



 Insert the mechanical key into the keyhole in the door lock, turn the key clockwise to the locked position, pull out the mechanical key, and close the door to lock the door.

### **NOTE**

- All passenger's doors support emergency locking.
- After the vehicle is locked with the smart key, the anti-theft alarm will be triggered if you use the mechanical key to unlock the door. In this case, enter the vehicle, place the smart key at the mark, depress the brake pedal and power on the vehicle to release the anti-theft alarm.


#### Collision-sensitive unlocking

When a collision is detected, all doors will be unlocked automatically and the locking function of the vehicle will be disabled temporarily.

#### **Emergency unlocking of liftgate**

When you cannot open the doors and liftgate normally inside the vehicle in an emergency, the liftgate can be unlocked with the emergency unlocking device of liftgate. The specific steps are as follows:

1. Enter the trunk.



Remove the liftgate emergency unlocking port cover from the liftgate guard plate.




3. Pull the liftgate manual unlocking cable to unlock the liftgate.



#### **Emergency unlocking of charger**

If the charger cannot be unlocked by the charger unlocking button on the smart key, it can be unlocked by the emergency unlocking device of charger. The specific steps are as follows:

1. Open the hood and support it firmly with the stay bar.



2. Pull the charger manual unlocking cable to unlock the charger.

#### Window initialization

If the express-up & down function and antipinch function of power window fail, or the anti-pinch function fails because it is triggered multiple times in a short period of time, the power window needs to be initialized again.

#### Window initialization operation

After starting the vehicle, pull the window button (of the window needing initialization) until the window is completely closed, and then hold the button pulled for 2~3s to complete the initialization.

#### WARNING

 During the initialization, the anti-pinch function of the window is disabled. Therefore, please do not use any part of your body or other objects to hinder the closing of the window; otherwise, it may lead to initialization failure or window damage, or even personal injuries.

### **MOTE**

- ◆ If the button is released during the window movement, reinitialize the window.
- If the express-up & down function and anti-pinch function of power window are still not recovered after the initialization, contact the GAC AION sales store for repair.



#### Initialization of sunroof

In some cases (such as sudden battery loss. long-term stop or repeated malposition of sunroof/sunshade), the sunroof/sunshade may need manual initialization and self-learning.

#### Sunroof initialization operation

After starting the vehicle, keep the sunroof closed, press and hold the CLOSE button to make the sunroof move to the fully open position, and then continue the closing operation, and after the sunroof is completely closed, release the CLOSE button to complete initialization and selflearning.

#### Sunshade initialization operation

After starting the vehicle, keep the sunshade open, press and hold the sunshade close button to move the sunshade to the fully closed position until a click is heard, indicating that the initialization and self-learning are completed.

#### WARNING

The anti-pinch function of the sunroof is disabled during the initialization and learning; therefore in this process, do not try to hinder the closing of sunroof by stretching any body part or placing any obstacles, otherwise, damage may be caused and the initialization result may be affected.

### **MOTE**

- If the button is released during the sunroof/shade movement, reinitialize the sunroof/shade.
- ◆ If the automatic opening/closing function and anti-pinch function of the sunroof/sunshade are still not recovered after the initialization. contact the GAC AION sales store for repair.

### **Turning on hazard warning** lamp



If the vehicle is faulty or involved in a traffic accident, please turn on the hazard warning lamp to alert other vehicles.

The hazard warning lamp can be turned on or off by pressing the switch.

### **CAUTION**

When the vehicle is powered off, do not turn on the hazard warning lamp unless necessary, so as to prevent the battery from running out of power.

### **M** NOTE

If the hazard warning lamp cannot work properly, other methods that comply with the relevant traffic rules and regulations must be taken to draw the attention of other drivers to vour vehicle.



### Wearing reflective vest



The vehicle is equipped with a reflective vest, which you can put in the cabin for use when needed

#### WARNING

If you need to get out of your vehicle to check or handle vehicle faults during driving, regardless of the lighting conditions, be sure to wear a reflective vest to attract the attention of passersby or other drivers.

### **MOTE**


◆ If the reflective vest is seriously damaged or dirty, it will affect the reflection effect. It is recommended to replace the reflective vest with a new one in time.

### Setting up warning triangle

#### Location of warning triangle

The vehicle is equipped with a warning triangle, which is placed under the trunk carpet and can be used after taking it out and unfolding it.

#### Placement distance of warning triangle



Item	Ordinary road	Highway
	Day: L≥50m Night: L≥80m	
Placement distance L	Special circumstances (rain or bend, etc.): L≥150m	L≥150m


#### **M** NOTE

- The value provided here is for reference only.
- Please use the warning triangle correctly according to the corresponding national laws and regulations.



#### Introduction to driver's tools

The driver's tools are located under the trunk carpet.



- 1 Warning triangle
- 2 Towing hook
- 3 Inflator pump
- 4 Tire sealer

### **NOTE**

- In order to deal with various emergencies, you shall be familiar with the locations and usage of tools such as towing hooks.
- The used tools shall be cleaned in time and placed back to their original positions.
- Depending on vehicle configurations, the driver's tools may vary.
   For specific driver's tools, the configuration of the actual vehicle shall prevail.

#### Tire inflation

When the tire pressure is insufficient, the tire can be inflated timely with an inflator pump (if equipped).

#### Introduction to inflator pump




- 1 Power line
- 2 Power plug
- 3 Power switch
- 4 Connector
- (5) Air pipe
- 6 Tire pressure gauge

### **CAUTION**

- Do not disassemble or modify the inflator pump.
- The inflator pump can only be used with a 12V DC power supply instead of other power supplies.
- Do not operate the inflator pump for more than 30min.
- Do not operate the inflator pump in water when it rains.
- Do not use the inflator pump on sandy or dusty roads as suction of sand and dust may cause a fault.




#### Inflation method




1. Park the vehicle in a flat and safe place, and remove the tire valve cap.




2. Screw the connector of the inflator pump into the tire valve.



3. Insert the power plug into the power outlet.



4. Start the vehicle, and turn on the power switch of the inflator pump to start inflation.



5. Observe the change in the indicated pressure on the tire pressure gauge. When the indicated pressure reaches the standard tire pressure, power off the inflator pump to stop inflating the tire.



- 6. Screw off the connector of the inflator pump, and screw on the valve cap.
- 7. Remove the power plug of the inflator pump, take away the inflator pump and place it properly.

#### **M** NOTE

The standard tire pressure sticker is attached to the B-pillar on the driver's side.

#### Tire repair

#### Tire leaks

If a tire is punctured by a sharp object, the tire will not necessarily incur obvious leakage. When a tire leak is found, decelerate slowly by depressing the brake pedal gently, keep driving in a straight line and drive the vehicle to a safe area away from heavy traffic. After parking, repair or replace the tire as needed.

#### WARNING

- Turn on the hazard warning lamp timely, and place a warning triangle behind the vehicle as specified to avoid secondary accidents.
- Never use a flat tire; otherwise, even for a short distance, it may cause damage to the tire beyond repair.

#### Introduction to tire sealer



Situations suitable for tire sealer:

- Tire leaks caused by a nail in the tire tread.
- Tire tread cut with a diameter less than 6mm.



#### Situations unsuitable for tire sealer:

- ♦ Tire side damage.
- Tire punctured by a sharp object of 6mm or above.
- ♦ Exposed hub.
- ♦ Damaged hub.
- Multiple tires punctured by nails.


### **▲** WARNING

- Inhalation of tire sealer may endanger personal health. If the tire sealer is swallowed accidentally, seek medical attention immediately.
- If the tire sealer enters an eye or comes into contact with the skin, rinse the eye or skin with plenty of water, and seek medical attention immediately.

#### **NOTE**

- The tire sealer can only be used once. If the tire is not leaking too fast, the tire sealer can be left unused.
- One bottle of tire sealer can only be used to repair one tire.
- The warranty period of the tire sealer is 5 years, and its operating temperature is -30~70°C.

#### Tire repair method




1. Park the vehicle in a flat and safe place, and remove the tire valve cap.




2. Shake the tire sealer, and screw the tire sealer connector into the tire valve.





Connect the connector of the inflator pump to the bottle opening of tire sealer.



4. Insert the power plug of the inflator pump into the power outlet.



Start the vehicle, and turn on the power switch of the inflator pump to start tire repair.

#### **NOTE**

- ◆ Observe the change in the indicated pressure on the tire pressure gauge. The tire pressure is high (about 280~400kPa) when the tire sealer is being added; the tire pressure drops (about 70~140kPa) after the tire sealer is added.
- After the tire sealer is added, continue to inflate the tire to the standard tire pressure.

### **NOTE**

- If the tire cannot be inflated to the standard tire pressure within 10min, it means that the tire cannot be repaired.
- Power off the inflator pump to stop inflating the tire.
- Remove the connectors of the inflator pump and tire sealer, and refit the valve cap.
- Remove the power plug of the inflator pump, take away the inflator pump and place it properly, and recycle the tire sealer bottle reasonably.
- Drive at a speed of 20-60km/h for 5km, to distribute the tire sealer evenly on the inner side of the tire and solidify it.



- 11. Park the vehicle on a safe road, place a warning triangle, and check the tire pressure with the inflator pump. If the tire pressure is normal, the driving can continue; if the tire pressure is insufficient, the tire can be inflated with the inflator pump so that the tire pressure returns to the standard value.
- 12. Check the tire pressure after driving again for a period of time. If the tire pressure still drops, it means that the tire repair fails; in this case, park the vehicle safely and then call for rescue.

### **CAUTION**

- Do not drive the vehicle at a speed higher than 80km/h when the tire has been repaired with the tire sealer.
- The repair with tire sealer can only be used as temporary emergency treatment. After that, contact the GAC AION sales store for tire repair or replacement as soon as possible.
- Do not place the tire sealer upside down.

#### Tire rotation

#### Inspecting the wear pattern of tire



There is a raised "tread wear indicator" ① on the front of the tire. If the tread pattern wears to the indicator surface, the tire can no longer be used safely and must be replaced immediately.

The position of the tread wear indicator is indicated by the pattern ② on the sidewall of each tire

There is a raised "tread wear indicator" ① on the front of the tire. If the tread pattern wears to the indicator surface, the tire can no longer be used safely and must be replaced immediately.

The position of the tread wear indicator is indicated by the pattern ② on the sidewall of each tire.

#### Tire rotation

Regular tire rotation is recommended to avoid uneven tire wear and extend the service life of tires.

After tire rotation, adjust the tire pressure to the standard value.

Emergency treatment



#### Tire burst

If a tire burst occurs during driving, operate as follows:

- Hold the steering wheel with both hands, and do not allow it to rotate freely.
- 2. Decelerate slowly by depressing the brake pedal gently at the same time.
- 3. Ensure that the vehicle runs straight ahead in the original direction.
- 4. After the vehicle speed drops, drive the vehicle slowly to park it in a safe area.
- Replace the tire or make a rescue call as needed

### **▲** WARNING

- Do not depress the brake pedal sharply; otherwise, the vehicle may lose balance and thus turn over.
- Turn on the hazard warning lamp timely, and place a warning triangle behind the vehicle as specified to avoid secondary accidents.

#### Jump start

If the low voltage battery has been depleted, you can try to start your vehicle via jumper cables and a low voltage battery of another vehicle.

#### Connecting jumper cable

Connect the jumper cable in the following steps:

- Connect one end of the red positive (+) cable to the positive (+) terminal of the dead battery of the vehicle being rescued.
- Connect the other end of the red positive (+) cable to the positive (+) terminal of the live battery of the rescue vehicle.

### **CAUTION**

- Do not let the cable clamp on the other end of the black negative (-) cable come into contact with anything before performing Step 4.
- Connect the other end of the black negative (-) cable to a suitable grounding point (clean and unpainted solid grounded metal component) of the vehicle being rescued.

### **CAUTION**

- Keep away from the negative (-) battery terminal.
- Do not connect the other end of the black negative (-) cable to a dead battery.
- Start the rescue vehicle for a period of time, then try to start the vehicle being rescued and hold it for a period of time to charge the vehicle fully.



### **NOTE**

 If the vehicle being rescued cannot be started after several attempts, it is recommended to contact the GAC AION sales store for treatment.

#### Disconnecting jumper cable


Disconnect the jumper cable in the following steps:

- Disconnect the black negative (-) cable from the vehicle being rescued (vehicle with dead battery).
- Disconnect the black negative (-) cable from the rescue vehicle (vehicle with live battery).
- 3. Disconnect the red positive (+) cable from the rescue vehicle (vehicle with live battery).
- Disconnect the red positive (+) cable from the vehicle being rescued (vehicle with dead battery).

### **▲** WARNING

- If the jumper cable is connected or disconnected in the wrong order, a short circuit in the electrical load may occur, causing vehicle damage or personal injury. The resulting repair is outside the warranty coverage.
- Be sure to connect and disconnect the jumper cables in the correct order and make sure that the cables do not come into contact with each other or other metals to prevent accidents.
- Not batteries of all vehicles can be used. Only batteries with a rated voltage of 12V can be used for jump start.

### **Emergency start of vehicle**



When the battery of smart key runs out or is low, enter the vehicle, place the smart key at the mark, depress the brake pedal and power on the vehicle, and then move the gearshift lever as soon as possible start the vehicle.

### **NOTE**

 After power on, move the gearshift lever as soon as possible start the vehicle; otherwise, power on the vehicle again.



# **Emergency poweroff of vehicle**

When the vehicle is stopped, if poweroff cannot be achieved in the vehicle for some special reasons (such as crash/ black screen of center console), the vehicle power supply can be switched off by pressing and holding the "P" position switch for a period of time.

### **NOTE**

During emergency power-off by pressing and holding the "P" position switch, relevant prompts will pop up on the instrument cluster. In this case, the vehicle power supply can be switched off by pressing and holding the "P" position switch for a period of time.



### Getting out of a trap

If the vehicle is stuck on a soft road such as sandy, muddy or snowy road, follow the steps below to get out of a trap:

- Power off the vehicle, and remove mud, snow or sand around the front wheels.
- Place wooden blocks, stones or other objects under the front wheels to help increase the adhesion and friction.
- Start the engine and accelerate the vehicle slowly to get the vehicle out of the trap.

### **▲** WARNING


If the vehicle is to be driven out of the trap by pushing the vehicle from the front and rear, make sure that the surrounding area is spacious and unimpeded to avoid colliding with other vehicles, objects or people. When the vehicle is driven out of the trap, it may suddenly rush forward or backward, so extra care shall be taken.

### **NOTE**

 If the vehicle still cannot get out of the trap after several attempts, it is required to have a tow truck for rescue.

#### Vehicle towing

If the vehicle needs to be towed, it shall be towed by the GAC AION sales store or a professional towing company.



It is recommended to use a flatbed trailer.

### **CAUTION**

- Keep the front and rear wheels off the ground during vehicle towing.
- Towing with a hoist trailer is prohibited; otherwise, the vehicle may be damaged.

### **NOTE**

◆ For towing, be sure to use the safety chain system and comply with the relevant national/provincial (municipal) and local laws and regulations.



#### Installing a towing hook



1. Open the towing cover at the lower right of the front bumper.



Insert the towing hook into the towing port, turn it clockwise and tighten it.

### **▲** WARNING

- When installing a towing hook, make sure to tighten it. If the towing hook is loose, it may fall off during towing, causing serious personal injuries or vehicle damage.
- ♦ If the vehicle is stuck in mud or sand, or if it is required to pull the vehicle out with a towing hook due to other circumstances, make sure to observe the precautions related to getting the vehicle out of a trap; otherwise, the towing rope or chain may break due to the excessive tension applied, thus causing serious personal injuries or vehicle damage.
- During vehicle towing, the driver must sit in the vehicle to control the steering wheel and brake pedal to avoid personal injuries and vehicle damage during towing.



### **CAUTION**

- Before towing, check whether the towing hook is broken or damaged.
- Straight-line towing shall be kept as much as possible. Do not tow the vehicle from one side or at a vertical angle to avoid damaging the towing hook and the vehicle.
- Do not yank the towing hook. The force application shall be smooth and balanced.
- Do not fix the towing rope or chain to a suspension component.
- If the vehicle is difficult to move, do not continue the towing, and contact the GAC AION sales store for towing.
- Towing with a towing hook is only used to help get the vehicle out of the poor road. Driving by towing is prohibited; otherwise, it may cause damage to the vehicle.



# Rescue in case of driving through water

If water may enter the vehicle during driving through water, follow the steps below:

- Drive the vehicle away from the waterlogged road section, park it in a safe place, and check whether there is water inside the vehicle. If so, clear it.
- If the vehicle cannot be driven away from the water-logged road section, switch off the vehicle power supply immediately.
- 3. Disconnect the negative battery terminal if conditions permit.
- Call the GAC AION's customer service hotline for rescue.
- If the vehicle is flooded severely, all occupants should be evacuated to a safe place immediately.

### **M** WARNING

If the vehicle is soaked in water or falls into water accidentally for weather or special reasons, it is forbidden to power on the vehicle; otherwise, it may cause accidents or secondary damage to the vehicle.

# Rescue in case of battery leakage

### $\Lambda$

#### WARNING

- If a vehicle collision causes the traction battery fluid leakage, a professional rescuer shall wear a protective mask and solvent isolation gloves, and shall not touch the fluid directly.
- ♦ If the leaked fluid is touched accidentally, try to remove the contaminated clothes and immediately rinse the related part with soap and plenty of water for 15min until no chemicals remain. In case of an uncomfortable symptom, seek medical attention immediately.



### Rescue in case of vehicle fire

After the vehicle catches fire, immediately leave the vehicle and evacuate to a safe place, and call the police and rescue phone number.

After the vehicle fire is extinguished, it is recommended to contact the GAC AION sales store for treatment: in this case, do not touch the vehicle subjected to the fire accident to avoid accidents such as electric shock and burns



#### /I\ DANGER

 When the instrument cluster displays a message "Safe parking, emergency leaving" and sends a buzzer sound, it means that the internal temperature of the battery rises sharply and an accident of thermal runaway (overheating, fire, explosion) will occur. In this case, immediately park the vehicle safely and stay away from the vehicle.

#### In order to prevent vehicle fires timely and effectively, pay attention to the followings during use:

- Never store flammables or explosives in the vehicle.
  - In hot summer days, if flammables or explosives such as lighters, cleaning agents and perfumes are stored in the vehicle, fire and even explosion is likely to occur.
- ♦ Never modify the electrical circuits or install additional electrical components.
  - Installation of additional electrical consumers (such as high-power audio device) will cause excessive load on the electrical line, causing overheating and even fire of harnesses.


- inspection and maintenance regularly.
  - Check for oil leakage regularly, and remove grease and oil stains from the motor timely to avoid fires caused by volatilization of the grease and oil stains under high temperature conditions.
  - Regularly check all electric lines of the vehicle, and check whether the electrical devices and harness connectors are insulated and fixed normally.
- It is recommended to equip the vehicle with a fire extinguisher and know its operation method.
  - An onboard fire extinguisher is recommended to be prepared on the vehicle to ensure the driving safety. Check and replace the fire extinguisher regularly and be familiar with its operation method.
- Precautions for driving.
  - During parking, especially in summer, ensure that there are no flammables (such as hay, dry branches, leaves and wheat stalks) under the vehicle; otherwise, fire may be caused.
  - During driving, try to avoid road sections with flammable materials such as dry leaves, wheat straw. and weeds, or stop to check whether there are any of such flammable materials attached to the bottom of the vehicle after driving through such road sections. Try to park the vehicle in a place without sun exposure.




### Vehicle identification number (VIN)

#### Location of vehicle identification number (VIN)

The vehicle identification number (VIN) is the ID code of a vehicle and has uniqueness.



♦ The VIN is pasted at the reserved groove on the lower left of the front windshield




♦ The VIN is engraved at the floor in front of the front passenger's seat.

### **NOTE**


The location and quantity of vehicle identification number (VIN) are not complete. Please refer to the actual vehicle.

#### Composition of vehicle identification number (VIN)



The VIN is composed of 17 characters and contains information such as the country of manufacture, manufacturer, year and vehicle characteristic code

#### Vehicle identification number (VIN) read with a diagnostic scan tool



The OBD DLC is located at the lower left rear of the instrument panel. Data such as the vehicle identification number (VIN) and vehicle status information can be read by connecting a special diagnostic scan tool to the OBD DLC.

### **NOTE**

If you need to diagnose whether the vehicle data is normal, contact the GAC AION sales store for data diagnosis.



### Vehicle nameplate and sticker


#### Manufacturer's nameplate



The manufacturer's nameplate is pasted near the front door lock catch of B-pillar on the front passenger side.

The manufacturer's nameplate is marked with the country of manufacture, date of manufacture, vehicle identification number (VIN), drive motor parameters, traction battery parameters and other information.

#### Motor model and number



The motor model and number are engraved on the motor housing.

#### Vehicle sticker

Vehicle stickers include the child safety lock sticker, airbag warning sign, cooling fan warning sticker, high-voltage component warning sticker, etc. Be sure to read and follow the instructions on the stickers

♦ Airbag warning sign




- The airbag warning signs are located on the front and back of sun visor on the front passenger's side.
- Cooling fan, coolant warning sticker



The cooling fan, coolant warning sticker is located on the motor compartment guard plate.



♦ High-voltage component warning sticker



- The warning sticker for high-voltage components such as MCU is located on the housing of concerning highvoltage component.



- The automotive energy consumption sign is located on the front windshield.
- The automotive energy consumption sign contains information such as the manufacturer, vehicle model, energy type, vehicle mass and electric energy consumption.

### **MOTE**

 To prevent the sign from affecting the field of vision, remove the sign after purchasing the vehicle. ♦ Charging warning sticker



- The charging warning sticker is located on the charging inlet cap.



## **Technical parameters of vehicle**

Item		Parameter
Overall dimensions (mm)	Length	4535
	Width	1870
	Height	1650
Mh a al tra alc (mana)	Front	1600
Wheel track (mm)	Rear	1600
Wheelbase (mm)		2750
Front/rear overhang (mr	m)	898/887
Kerb mass (kg)		1770/1825
As I also I discolate a service (Iso)	Front	989/1000
Axle load (kerb mass) (kg)	Rear	781/825
Gross vehicle weight rating	g (kg)	2180
Axle load (gross vehicle weight	Front	1095
rating) (kg)	Rear	1085
Min. ground clearance under full load (mm)		≥150
Minimum turning diameter (m)		11
Maximum speed for 1km (km/h)		150
Combined range (km)		500
Power consumption in combined driving cycle (kWh/100km)		13.8
Maximum gradeability (%)		30
Approach angle (°)		≥18
Departure angle (°)		≥27
Seating capacity		5



### **Technical parameters of motor**

ltem	Parameter
Motor model	TZ184XYA2001
Drive motor type	Permanent magnet synchronous motor
Drive mode	FF
Rated power (kW)	38
Rated speed (r/min)	4270
Rated torque (N•m)	85
Peak power (kW)	150
Peak speed (r/min)	14000
Peak torque (N•m)	225



## **Technical parameters of traction battery**

Item	Parameter
Type of battery	LFP battery
Rated voltage (V)	374.4
Rated capacity (A•h)	169
Cooling method	Liquid cooling
Charging temperature (°C)	-20~55
Storage temperature (°C)	-40~60
IP rating	IP67



## Wheel and tire parameters

ltem		Parameter
Tire specification		215/55R17
Standard tire pressure (kPa)		240~270
Front wheel toe-in		5'±3'
	Front wheel camber	-13'±30'
Four-wheel alignment Kingpin caster angle of front wheel front wheel	7°14'±45'	
		13°23'±45'
	Rear wheel camber	-1°15±30'
	Rear wheel toe-in	-6'±18'
Dynamic balance of wheels		Single-sided residual unbalance ≤8g
		Total weight of balance weight on both sides ≤120g



## **Technical parameters of brake system**

ltem		Parameter
Type of service brake system		Hydraulic brake, disc brake
Ту	pe of parking brake system	EPB
Po	ower mode of brake booster	Vacuum
Fre	e travel of brake pedal (mm)	5.6
Max	x. travel of brake pedal (mm)	106.4
	Total thickness of front brake lining (mm)	12
Allow	Allowable wear thickness of front brake lining (mm)	10
	Total thickness of front brake disc (mm)	25
Reasonable usable	Allowable wear thickness of front brake disc (mm)	2
range of brake lining pairs	Total thickness of rear brake lining (mm)	10
_	Allowable wear thickness of rear brake lining (mm)	8
	Total thickness of rear brake disc (mm)	10
	Allowable wear thickness of rear brake disc (mm)	1



## Type and dosage of vehicle fluids

Item	Specification	Dosage	Remarks
Brake fluid	DOT4	0.7~0.9L	1
Refrigerant	HFC-134a	530~570g	1
A/C system coolant	G30, -35°C	1.9~2.3L	1
TGW system coolant	G30, -35°C	4.2~5.6L	1
Motor coolant	G30, -35°C	3.6~4.2L	1
Windshield washer fluid	44% methanol with freezing point of -30°C, and 56% water with hardness not more than 205g/t	1.8~2.2L	1
Differential & reducer gear oil	IDEMITSU MOTFTS-1	1.33~1.43L	I



### Index

(Arrangement in sequential order of Chinese phonetic alphabets)

Number	Checking brake fluid 130
12V power outlet 44	Checking coolant129
Α	Child safety lock24
A/C control38	Closing all windows 102
A/C filter131	Closing of liftgate9
AC charging112	Closing sunroof103
Acoustic vehicle alerting system of	Correct sitting posture 13
electric vehicle running at low speed65	Correct use of seat belts 14
Adaptive cruise control*76	Corrosion protection measures125
Adding windshield washer fluid 128	Cruise control74
Adjustment of exterior rearview mirror	D
Adjustment of interior rearview	DC charging114
mirror	Door opening from outside 10
Airbag deployment20	Driving in cold seasons 94
Applicability of child seats 25	Driving in fog 92
AUTO HOLD 66	Driving in hot seasons 93
Autonomous emergency braking	Driving in rain92
(AEB)*72	E
В	Electric park brake (EPB) 100
Bluetooth connection46	Emergency poweroff of
Body anti-theft 108	vehicle 151
Brake assist control system 63	Emergency start of vehicle 150
С	Emergency unlocking/locking 138
Charging instructions 109	Exterior rearview mirror folding 106
Checking and replacing fuse 132	External cleaning116



External maintenance 120	L
F	Lane departure assist system * 86
Follow Me Home103	Lane keeping assist (LKA)
Forward collision warning	system *90
system*71	LATCH child restraint system 24
G	Light control 67
Gearshifting 61	Locating of vehicle6
Getting out of a trap 152	Locking doors from inside of vehicle37
How does a pregnant woman	Locking outside the vehicle 106
correctly fasten the seat belt? 15	Long-term storage of vehicle 126
1	Low voltage battery maintenance
Indicator lamps on instrument	
panel49	M
Information display 55	Maintenance of traction battery 135
Initialization of sunroof 141	
Instrument panel54	MirrorLink*46
Instrument panel warning	N
lamps52	Notices for children22
Integrated cruise assist * 82	О
Interior lighting11	Opening and closing hood 127
Internal cleaning118	Opening doors inside the
Internal maintenance 121	vehicle 104
Introduction to airbag 17	Opening liftgate 7
Introduction to driver's tools 143	Р
Introduction to seat belt12	Pedal 62
ISOFIX child restraint system 24	Pre-drive check3
J	Precautions for multimedia use 47
Jump start149	R
Jump start149	Rescue in case of battery



leakage155	Technical parameters of vehicle160
Rescue in case of driving through water155	Tire inflation
Rescue in case of vehicle fire 156	Tire maintenance121
Reverse tilt-down*	Tire pressure monitoring system 57
S	Tire repair145
Safety handrail42	Tire rotation 148
Safety notes before getting off the vehicle105	Turning on hazard warning lamp 141
Seat adjustment29	Type and dosage of vehicle
Seat belt reminder 16	fluids 165
Setting up warning triangle 142	Unlocking doors inside the
Smart key4	vehicle 104
SRS warning lamp19	Unlocking outside the vehicle 6
Steering wheel adjustment 36	USB port44
Steering wheel control 35	V
Storage space40	Vanity mirror and vanity mirror
Sun visor43	lamp43
Sunroof control33	Vehicle identification number (VIN)157
Surround view monitor (SVM) 97	Vehicle nameplate and sticker 158
Switch-on/off of vehicle power supply28	Vehicle start
Switching of driving modes 59	Vehicle towing 152
T	W
Technical parameters of brake	Wearing reflective vest 142
system 164	Wheel and tire parameters 163
Technical parameters of motor . 161	Window control 32
Technical parameters of traction	Window initialization 140
battery 162	Wiper control69

